



SigVSA

Vector Signal Analysis Software

User Manual

EN01F



SIGLENT TECHNOLOGIES CO., LTD.

Copyright and Declaration

Copyright

©2024 Shenzhen Siglent Technologies Co., Ltd. All rights reserved.

Trademark Information

SIGLENT® is a registered trademark of Shenzhen Siglent Technologies Co., Ltd.

Declaration

The products of this company are protected by patents granted and pending in the People's Republic of China.

The company reserves the right to change specifications and prices.

The information provided in this manual replaces all previously published materials. Any changes will not be notified separately.

The content of this manual may not be reproduced, adapted, or photocopied in any form or by any means without the consent of the company.

Product Certification

SIGLENT certifies that this product complies with the national and industry product standards of China and further certifies that this product meets the relevant standards of other international standard organizations.

Contact Us

Shenzhen Siglent Technologies Co., Ltd.

Address: Antongda Technology Park, Liuxian 3rd Road, Bao'an District, Shenzhen, Guangdong, China

Service Hotline: 400-878-0807

E-mail: support@siglent.com

Website: <https://www.siglent.com>

Contents

1	QUICK GUIDE	5
1.1	Product Introduction	5
1.2	Software Installation	6
1.2.1	Software Installation Steps.....	6
1.2.2	Version Option Application.....	10
1.3	Function Introduction.....	13
1.4	Application Wizard.....	14
1.4.1	Software Interface	14
1.4.2	Demo	16
1.4.3	Parsing via offline files.....	18
1.4.4	Analysis via remote host	19
2	SOFTWARE MENU	23
2.1	File.....	23
2.1.1	Save&Recall.....	23
2.1.2	Preset.....	25
2.2	Control.....	27
2.3	Input Output	27
2.4	Meas Setup	28
2.4.1	New Measurement.....	28
2.4.2	Remove Measurement	29
2.4.3	Measure Management	30
2.4.4	Current Measurement	30
2.4.5	Measurement Type.....	31
2.5	Trace	32
2.6	Markers.....	32
2.6.1	Marker Setting	32
2.6.2	Peak Search.....	33
2.7	Window	34
2.8	Utilities.....	38

3	MEASUREMENT	40
3.1	IQA	40
3.1.1	Configuration	40
3.1.2	Measurement Results	40
3.2	OFDM	42
3.2.1	Configuration	42
3.2.2	Measurement Result	49
3.3	Digital Modulation(DMA)	50
3.3.1	Configuration	50
3.3.2	Measurement Results	56
3.4	NR	66
3.4.1	Properties	66
3.4.2	Measurement Result	116
3.5	LTE	120
3.5.1	Configuration	120
3.5.2	Measurement Result	141
3.6	NB-IoT	145
3.6.1	Configuration	145
3.6.2	Measurement Results	149
3.7	WLAN	152
3.7.1	Configuration	152
3.7.2	Measurement Results	163
3.8	Bluetooth	168
3.8.1	Configuration	168
3.8.2	Measurement Results	176
3.9	UWB	180
3.9.1	Configuration	180
3.9.2	Measurement Results	188
3.10	FHSS	201
3.10.1	Configuration	201
3.10.2	Measurement Results	204

3.11 FMCW.....	206
3.11.1 Configuration.....	206
3.11.2 Measurement Results.....	211
ORDERING INFORMATION	213

1 Quick Guide


1.1 Product Introduction

SigVSA vector signal analysis software is a professional vector signal analysis application software that can run on Windows and Linux operating systems.

With SigVSA, users can repeatedly analyze the signals under test, quickly troubleshoot issues, covering a range from simple BPSK to complex broadband signals, such as FHSS, IQA, UWB, DMA, OFDM, 4G LTE, 5G NR, IEEE802.11b/a/g/n/ac/ax/be, and 4096QAM.

- SigVSA has rich measurement functions, convenient operation experience and the same user interface as vector analyzer, providing high efficiency and ease of use.
- Comprehensive local analysis functions, supporting offline analysis of vector analyzer raw waveform files.
- SigVSA can perform remote vector signal analysis and debugging on the computer, can control multiple instruments to run in parallel, and can centrally process recorded data or simulation files, thus saving time going to the laboratory.

Offline waveform data analysis



Export the specified waveform file from the measuring instrument and put it on the computer hard disk via a USB flash drive or network server. Then use the SigVSA import function to import the waveform data for vector analysis.

Simultaneously control multiple instruments to collect waveform data and send it to the computer for centralized analysis



In this scenario, SigVSA vector signal analysis software performs cloud control functions, automatically searches for instruments in the network, selects instruments as needed, and performs remote control and acquisition. After SigVSA acquires data, it reads the remote waveform data online and then performs local data analysis, which does not rely on the instrument vector analysis option.

1.2 Software Installation


Minimum system requirements	
Operating System	Windows 10 or higher 64-bit operating system
CPU	Intel® Core™ i5 Processor or better
Memory	8 GB RAM or better
Harddisk	At least 16GB of free space
Display Resolution	Minimum 1280x720, recommended 1920x1080
Virtual Memory	More than 1G of available virtual memory

1.2.1 Software Installation Steps


1.2.1.1 Windows Version Installation

Step 1 : Double-click the SigVSA software. Users can select the installation path of the SigVSA software according to their own arrangements and click Next;

Note: Please make sure that the disk to be installed has 1144.2MB of storage space.




Step 2: If you need to create a desktop shortcut for the SigVSA software, please check "Create a desktop shortcut" and click Next;



Step 3: Click Install to start software installation. The installation process will last for 30 seconds to 1 minute until the installation is completed.

Note: The default installed software does not have a license option. If you want to use it normally, you also need to load the corresponding measurement option.



1.2.1.2 Linux Version Installation

Taking Ubuntu as an example, there are two installation methods: command-line installation and graphical installation.

- Command-line Installation (Recommended)

Step 1: Open the Ubuntu terminal and navigate to the folder containing the .deb file.

Step 2: Enter the installation command along with the package name: `sudo dpkg -i UbuntuVSA_1.1.1.1.8R1.deb`

Step 3: Enter your user password to obtain the necessary permissions for installation.

```
test@SZ-U-0001:~/zhaolu$ sudo dpkg -i UbuntuVSA_1.1.1.1.8R1.deb
[sudo] test 的密码:
正在选中未选择的软件包 siglent-vsa。
(正在读取数据库 ... 系统当前共安装有 243703 个文件和目录。)
准备解压 UbuntuVSA_1.1.1.1.8R1.deb ...
正在解压 siglent-vsa (1.1.1.1.8RT6275) ...
正在设置 siglent-vsa (1.1.1.1.8RT6275) ...
┆
SigVSA 安装完成!
启动方式:
  1. 命令行: vsa
  2. 桌面图标: SigVSA


正在处理用于 gnome-menus (3.36.0-1.1ubuntu3) 的触发器 ...
正在处理用于 desktop-file-utils (0.27-2build1) 的触发器 ...
正在处理用于 hicolor-icon-theme (0.17-2) 的触发器 ...
test@SZ-U-0001:~/zhaolu$
```

- Graphical Installation (Optional)

Step 1: Right-click the .deb file and select "Open with App Center."

Step 2: Click the "Install" button.

Step 3: Enter your user password when the permission request window automatically appears.




Note

- Software installed on the Ubuntu system is fixed to the /usr/bin/siglent/ directory.
- After installation, you can launch the software by entering vsa in any directory within the Ubuntu terminal, or by clicking the desktop icon.

```
test@SZ-U-0001:~/zhaolu$ vsa
VSA 需要 root 权限, 请输入密码...
[sudo] test 的密码:
[DEBUG] SIGVSA_ROOT env = /usr/bin/siglent
[INFO] Using SIGVSA_ROOT: /usr/bin/siglent
[INFO] Final root path: /usr/bin/siglent

==== [ lib_ssa_dir_route ] The path of the function: ====
lib_ssa_dir_route::root_path()           : /usr/bin/siglent
lib_ssa_dir_route::mass_storage_path()   : /usr/bin/siglent/usr/mass_s
storage
lib_ssa_dir_route::emmc_mass_storage_path() : /usr/bin/siglent/usr/emmc_f
tp/mass_storage
lib_ssa_dir_route::usr_path()            : /usr/bin/siglent/usr
lib_ssa_dir_route::usr_usr_path()        : /usr/bin/siglent/usr/usr
lib_ssa_dir_route::conf_path()           : /usr/bin/siglent/config
lib_ssa_dir_route::firmdata_path()       : /usr/bin/siglent/firmdata0
lib_ssa_dir_route::factory_data_path()   : /usr/bin/siglent/firmdata0/
factory_data
lib_ssa_dir_route::log_path()             : /usr/bin/siglent/log
lib_ssa_dir_route::upgrade_path()        : /usr/bin/siglent/usr/usr/up
grade
lib_ssa_dir_route::emmc_upgrade_path()   : /usr/bin/siglent/usr/emmc_f
```




1.2.2 Version Option Application


The SigVSA software needs to load the measurement option to perform measurement analysis normally. The process is the same for both the Windows and Ubuntu versions; the SigVSA version option application requires the user to first generate an .id file containing the user's device information, and pass this file to the software development or market, which will generate the corresponding option license and complete the option loading.

Id File Generation

1. Open the SigVSA software and select **Utilities** -> **Option Management**.



- Click Generate Identification, select the path to save the ID file, and name the ID file to be saved (here we assume that the saved file is VSA.id).




- Pass the generated VSA.id file to software development or marketing to obtain the corresponding license.


Option License Loading

The option license obtained from software development or the market is a .lic file, which is placed in a directory on the computer, such as D:\license.

1. Select **Utilities** -> **Option Management**, click Install from Local, select D:\license (the directory where the .lic file is stored) in the pop-up window, and click Select Folder.









2. After clicking, the window will close automatically. After a few seconds, it will prompt Install Success. At this time, the installation status of the corresponding standard signal analysis option will be displayed as YES, which means that these measurement modes can be used normally.



1.3 Function Introduction

SigVSA Features and Benefits

-  Offline waveform data analysis on PC:
 - Specify IQ data format;
 - Supports waveform data up to 16M Byte;
 - Supports maximum 2G analysis bandwidth.
-  Supports online control of multiple instruments and acquisition of waveform data for PC analysis.
-  The software is based on the same platform as the Siglent vector analyzer vector analysis software. Users do not need to worry about the subsequent maintenance of the software. It has similar measurement and analysis functions and UI interactions, as shown below:
 - Support Windows and Linux operating systems;
 - Independent cloud control interface and analysis application interface;
 - Support general digital/analog signal analysis;
 - Support Custom OFDM signal analysis;
 - Supports 4G LTE, 5G NR and other cellular protocol standard signal analysis;
 - Support WLAN standard signal analysis such as IEEE802.11b/a/g/n/ac/ax/be (under development and debugging);
 - Supports more than ten measurement indicators, such as signal power, reference power, frequency offset error, clock error, delay offset, RMS EVM, Peak EVM, single channel EVM, etc.;
 - Supports more than ten measurement functions, such as time domain diagram, frequency domain diagram, vector error frequency domain curve, vector error time domain curve, constellation diagram, MIMO, etc.;
 - Supports simultaneous control of multiple instruments and equipment for parallel vector analysis, and independent display of multiple applications, which is convenient and clear.
-  Multi-window display, more flexible observation.
-  The interactive interface is similar to the Siglent vector analyzer operating interface and is easy to use.
-  Supports trigger, marker, trace and other functions.

1.4 Application Wizard

1.4.1 Software Interface

SigVSA has a variety of windows and status bars, including menu bar, toolbar, measurement management window, trace window, and marker information window, etc. This chapter mainly introduces each window and status bar briefly to help increase your understanding of the software.



Menu bar: The menu bar provides a full-function entrance to the SigVSA software, including file management, measurement status control, trigger control, measurement management, Trace, cursor, multi-window management functions and some practical tools. Through the menu bar, you can complete the full function of spectrum analysis.

Toolbar: In addition to the menu bar, SigVSA fixes some commonly used functions, such as measurement status control, measurement window layout, peak search, etc., on the toolbar through shortcut icons. During actual measurement, there is no need to open the menu bar additionally, and you can directly operate the toolbar buttons.


Control the measurement, including start, pause, continuous, single, Auto Range and other functions;


Start: After loading file data or connecting to a remote device, click Start to start the analysis;

Pause: When analyzing data, click Pause to pause the current measurement. Click Pause or Start again to continue the measurement.

Continuous/Single: Click the Continuous/Single button to change the measurement cycle state;

Auto Range: Click Auto Range to automatically set the optimal amplitude of the signal.

: Displays the currently working window. You can change the current measurement window by clicking the drop-down menu.

: Change the layout of the Trace window. The three buttons represent single window, Stack 2, and Grid 2x2 respectively.

: The four icons represent peak search, left peak, right peak, and minimum peak.


Peak search: Set the current cursor position to the position of the peak with the largest amplitude in the trace being searched; if the cursor is not currently turned on, turn on cursor 1 and set it to the position of the peak with the largest amplitude.

Left peak: The current cursor jumps to the point whose horizontal distance is closest to the current cursor among the peak points whose horizontal position is smaller than that of the current cursor.

Right peak: The current cursor jumps to the point whose horizontal distance is closest to the current cursor among the peak points whose horizontal position is greater than that of the current cursor.

Negative peak: Set the current cursor position to the position with the minimum amplitude of the trace being searched.

Measurement Management Window: Measurement Management is a window for adding, deleting and controlling all measurements of SigVSA.




Add Group: To facilitate the management of different measurements, we have added the concept of Group. Each measurement must belong to a Group, that is, there must be a Group before a Measurement. A maximum of 10 Groups are supported, and each Group can be renamed.

Each Group also has control buttons, which support operating the Group's control buttons to start measurement, pause measurement, and modify measurement cycle configuration for all measurements in the Group. If the measurements in the Group are not needed, all measurements in the Group can be quickly deleted by deleting the Group.

New Measurement: When you need to add a new measurement, you can use this button to quickly add the measurement. When adding a measurement, you need to first add a Group or select an existing Group, and then add the measurement.

Trace window: The Trace window is mainly a window that displays measurement data. It supports multiple data types, such as 5G Raw Main Time, IQ Meas Time, Frame Summary, Spectrum, Error Summary, RMS Error Vector Spectrum, etc.


Marker window: used to display the markers in all trace windows; here the markers are displayed based on different measurements and different trace windows.




1.4.2 Demo

The SigVSA software comes with a Demo.


Step 1: Open the SigVSA software (make sure the certificate has been installed).




Step 2: Select File -> Recall -> Recall Demo. The Demo file is in the SigVSA installation directory Help/Demo. Select and load any Demo file.




Note: When you open the software, there is no Group by default. When you directly add a measurement or recall a measurement/Demo, a Group 1 will be automatically created.



After loading is complete, as shown in the figure, the corresponding Demo storage path can be displayed under the measurement management.




Step 3: Click the Restart button of the loaded Demo measurement , the Demo file is automatically parsed.




1.4.3 Parsing via offline files


Step 1: Open the SigVSA software (make sure the license has been installed).




Step 2: In the Measurement Management window, add a measurement.



Step 3: Select File under Measurement and click ..., select the ARB file to be loaded in the opened file window.




Step 4: Click the start button to start the analysis.




1.4.4 Analysis via remote host

Step 1: Open the SigVSA software (make sure the license has been installed).




Step 2: Click **Utilities** -> **Remote Device Management**, a configuration box pops up, click Add Device to add a lower-level device IP (currently supports remote control resolution of Prime devices),




After adding, select the added device and click Connect Device to complete the communication connection between the software and the device.


Step 3: Click Add Group to add Group 1, and click New Measurement to add a measurement.



Select the added measurement, click Remote Device or click Utilities -> Data Source Settings, in the pop-up window, select the spectrum analyzer device to be bound to the slave computer, and click OK.



After the binding is completed, as you can see in the figure, there will be an icon similar to a computer monitor on the right side of the measurement name.



Click the Restart button of the measurement, and you can see the normal connection display of the lower computer signal in the Trace window.



2 Software Menu

2.1 File

2.1.1 Save&Recall

SigVSA software requires the configuration of one or more measurement attributes and parameters during measurement analysis, including the type of measurement, cursors, traces, triggering, and numerous other parameters. To simplify the configuration process, SigVSA software utilizes the Save & Recall feature to store such common configurations. These can be recalled and loaded when needed, facilitating rapid application and use.

2.1.1.1 Save


The Save function in SigVSA is categorized into two types: full save and single measurement save.

Save Setup	Save All Measurement Configurations	File -> Save -> Save Setup
Save Measurement	Save Single Measurement Configuration	File -> Save -> Save Measurement

The content saved includes:

Full Save:

Example: To save the configuration for all current measurements, select: File -> Save -> Save Setup.



Single Measurement Save: Select an individual measurement and save the configuration for that measurement;

Example: To save the configuration for a measurement named OFDM1: **File** -> **Save** -> **Save Measurement** -> **OFDM1**.



2.1.1.2 Recall

Replace	Full Replacement	File -> Recall -> Recall Setup -> Replace
Append	Incremental Loading	File -> Recall -> Recall Setup -> Append
Recall Demo	Recall Demo	File -> Recall -> Recall Demo
Recall Last Power-down Setup	Load Last Power-off Configuration	File -> Recall -> Recall Last Power-down Setup


Replace: Close the existing measurements and fully load the saved measurements.

The Replace function will close all current measurements and substitute them with the measurement set to be loaded. Therefore, before clicking Replace, please ensure that the current measurement set configuration does not need to be retained. Otherwise, use the Append function for incremental loading.

Append: Retain the existing measurements and incrementally load the saved measurements.

The new configuration group will be appended in sequence after the existing configuration groups; if the configuration group is not renamed, it will incrementally increase based on the current Group.


For example: If the current configuration group is Group1, and the appended configuration groups are Group1 and Group2, the final display will be Group1, Group2, and Group3.



Note: The total number of incremental loaded configuration Groups and the current Groups cannot exceed 10. If it exceeds 10, a load failure will be prompted.

Recall Demo: Load Demo File.

SigVSA software provides Demo files for different measurement modes by default. Users can go to the Demo file storage directory (under the installation directory's help\Demo path) to load and apply them according to their own needs.

After loading, you can start the demonstration by selecting Control -> Restart from the menu or by clicking the  button, to start the demonstration.




Recall Last Power-down Setup: Load the configuration that was automatically saved at the last shutdown.

2.1.2 Preset

Preset Setup	Restore the software to its initial configuration.	File->Default Preset -> Preset Setup
--------------	--	--------------------------------------

Measurement	Restore the initial configuration of the measurements.	File ->Default Preset -> Measurement->..
-------------	--	--

Preset Setup: Restore the software to its initial configuration state. Regardless of the current number of measurements and configurations, upon clicking, the software will revert to its most initial state with configurations reset to default values; that is, only a default 5G NR1 measurement will be displayed.



Measurement: To restore the configuration parameters of a single measurement only, select Measurement -> Measurement 1 (for example, 4G LTE1), and the configuration parameters for 4G LTE1 will be restored to their default values.

2.1.2.1 Preset







SigVSA offers a Preset function to restore measurements to an initial state, providing a convenient starting point for new measurements with initial state configurations. Currently, two methods are supported: Preset Setup and Measurement Preset.

File -> Default Preset -> Preset Setup: This interface deletes all Groups and measurements and simultaneously adds a default 5G NR measurement.

File -> Default Preset -> Measurement: Select the measurement you wish to restore, and with a click, all configurations for the current measurement will be restored, including trigger, Marker, Trace, measurement attributes, and other related parameters.

2.2 Control

The control menu offers various ways to start and stop measurements, with these control buttons displayed individually or repeatedly on both the control menu page and the toolbar.

Control Keys	Entry	Function
 Restart	Control Menu/Toolbar	Start a measurement or restart a paused measurement. Clicking this button will discard all current measurement data.
 Pause / Single	Control Menu/Toolbar	Pause a running measurement. A second click will either step through the measurement (when the scan is set to single) or continue the measurement (when the scan is set to continuous).
 Stop	Control Menu	Stop the measurement. Unlike pausing, stopping the measurement will clear all measurement results.
 Sweep/continuous	Control Menu/Toolbar	Toggle between single or continuous sweep modes.
 Sweep/Single	Control Menu/Toolbar	Toggle between single or continuous sweep modes.
 Auto Range	Toolbar	Perform an Auto Range on the selected measurement and restart the measurement.

2.3 Input Output

SigVSA provides a Trigger function similar to that of the underlying hardware. Through Trigger, it is possible to capture time data blocks around specific events. Currently, SigVSA supports three types of triggers: free trigger, external trigger, and periodic trigger.

Free Run

Free trigger is the default mode used by the analyzer, where the spectrum analyzer cycles and scans continuously.

External

External trigger offers users a more extensive triggering functionality. If users wish to achieve periodic triggering or delayed triggering of the spectrum analyzer, they can opt for the external trigger mode. In this mode, the trigger control is governed by the rising or falling edge of an external input signal. Inputting a square wave signal of a certain frequency can serve the purpose of periodic triggering, and the trigger delay time can be adjusted by setting the Trigger Delay option.

Period

When Periodic is selected, the analyzer uses a built-in periodic timer signal as the trigger. The trigger event is set by the periodic timer parameters, which are modified by the offset and the periodic synchronization source. This trigger is used when there is a periodic signal but no reliable signal to trigger upon. You can synchronize the periodic signal with an external event (using the periodic synchronization source) to approximate a reliable trigger signal. If no synchronization source is selected (off state), then the internal timer will not synchronize with any external timing events.


Note: External triggering and periodic triggering are not supported when the data source is a File, and are only supported in Remote connection mode.

2.4 Meas Setup

Meas Setup menu provides all the options for setting up measurements.

2.4.1 New Measurement

SigVSA supports adding new measurements by clicking on New Measurement. There are two entry points for adding new measurements: one is through the Measurement Management window, where you select the corresponding Group and then click New Measurement to add a measurement.



The other method is through Meas Setup -> New Measurement to add a measurement.

Currently, SigVSA supports the addition of three types of measurements: 5G NR, OFDM, and 4G LTE.

Note 1: Before adding a new measurement, it is necessary to confirm which Group the measurement to be added should belong to. If it needs to be added to a new Group, you must first click Add Group in the Measurement Management window to add a new window, and then select the newly added window to proceed with the measurement addition.

Note 2: Currently, a maximum of 10 Groups can be added, and each Group can have a mix of different

measurements added to it, with a single Group supporting up to 32 measurements; among these, each type of measurement supports a maximum addition of 10, for example, a maximum of 10 5G NR measurements can be added across all Groups.


Note 3: By default, without a license, up to 3 measurements are supported; if more measurements are needed, the corresponding license must be applied for, with a maximum support of 32 measurements.

2.4.2 Remove Measurement


Currently, SigVSA supports two methods for deleting measurements.

Method 1: In the Measurement Management window, you can quickly select the measurement you wish to delete and click the × in the upper right corner of the measurement to complete the deletion.

Note: If none of the measurements in the entire Group are needed, you can also click the × on the right side of the Group to delete the entire Group along with all the measurements inside it.




Method 2: **Select Meas Setup -> Remove Measurement**, and at the location indicated by the red box in the image below, click on the measurement you wish to delete.



2.4.3 Measure Management

SigVSA supports the manual addition of a Measurement Management window. When you click on **Meas Setup** -> **Measurement Management**, a Measurement Management window will be added to the left of the Trace. In this window, you can quickly perform operations such as adding or deleting measurements and controlling measurements.




2.4.4 Current Measurement

When performing operations such as cursor and trace functions, it is necessary to first specify which measurement the operation is targeting. Currently, there are two methods to quickly change the current measurement:

Method 1: In the Measurement Management on the left side, click on the measurement you wish to operate on;


Method 2: Select the menu **Meas Setup** -> **Current Measurement**, and then click on the measurement you wish to operate on;

After selecting the current measurement, the information of the current measurement will be displayed in the small window to the right of the toolbar control buttons.



2.4.5 Measurement Type

SigVSA supports rapid conversion between different measurement types. Simply click on **Meas Setup** -> **Measurement Type**, and then select the desired measurement type to switch to. Currently, eight measurement types are supported for conversion: **5G NR**, **4G LTE**, **OFDM**, **WLAN**, **DMA**, **UWB**, **FHSS**, and **IQA**.



2.5 Trace

SigVSA, by default, displays 6 Trace windows for each measurement. When more windows are needed, they can be added through the Trace menu, with each measurement supporting a maximum of 50 Trace windows. Currently, Trace addition is supported through two methods: Format and Y scale.

Format: When Format is selected, it can be used to modify the type of Trace.

Y scale: When Y scale is selected, it allows setting the reference level and the scale of the Y-axis for the Trace.

When adding a Trace, you can freely choose either Format or Y scale. The default Trace type added is Raw Main Time. If you wish to change the Trace type, select this Trace window and then click on **Trace** -> **Format** to modify the Trace type; if you want to modify the reference level and Y-axis scale, choose Y scale for adjustments.


To quickly delete a Trace window, open the Trace menu, freely select either Format or Y scale, choose the Trace you wish to delete, and click "Delete Trace."

2.6 Markers

2.6.1 Marker Setting

The cursor is a waveform measurement tool that reads data from trace points and, by combining multiple cursors, can easily measure quantitative information such as signal frequency, amplitude, and bandwidth. SigVSA supports various types of cursor functions, which can be accessed from **Marker** -> **Position** to enter the cursor setup interface.

SigVSA supports three types of cursors: Normal, Delta, and Fix. The selection of cursor types can be completed within the cursor setup interface, and it also supports cursor coupling, allowing for coupled cursor movement across different Traces.



Note: The cursor coupling function is effective for all cursors within a single measurement mode.

2.6.2 Peak Search


SigVSA provides a peak search function, which refers to a series of maximum points on the trace that are searched and filtered according to certain conditions.

The peak search conditions include peak threshold and peak offset:



Peak Threshold: Specifies the minimum value of the peak amplitude; only extremum points with an amplitude greater than the peak threshold are identified as peaks. If the peak threshold is turned off, the actual threshold used for determination is -200 dBm.




Peak Offset: Specifies the difference in amplitude between a peak and the minimum points on its left and right sides. Except for the two peak points at the far left or far right, a peak point must have two minimum points on either side with an amplitude difference greater than the peak offset, and between the two nearest qualifying minimum points on either side of this peak point, this peak point must be the one with the maximum amplitude. If the peak offset is turned off, the actual offset used for determination is 0 dB.

Peak Threshold and Peak Offset Entry: **Marker** -> **Position**.



The peak search function supports the following features:

Control Key	Entry	Function
 Peak	Control Menu/Toolbar	Move the current Marker to the highest Y-value point on the current Trace; if the polar (IQ) data format is selected, the highest point is the one with the greatest magnitude.
 Next Peak	Control Menu	Move the current Marker to the next highest Y-value point on the current Trace.

	Peak Left	Control Menu/Toolbar	Move the current cursor to the left to the next valid peak point on the current Trace.
	Peak Right	Control Menu/Toolbar	Move the current cursor to the right to the next valid peak point on the current Trace.
	Peak Minimum	Control Menu/Toolbar	Move the current Marker to the lowest Y-value point on the current Trace.

Note: To perform peak operations on a specific cursor, you must first select the corresponding cursor through the menu bar.

2.7 Window

In addition to the conventional Trace windows, SigVSA also supports additional Marker windows and Measurement Management windows to facilitate quick operations.




Marker Window: Used to display all Markers associated with the current Traces.

Measurement Management Window: The measurement management window is used to view all current measurements, allowing for the management of measurements through grouping.

In addition to incremental windows, SigVSA also supports a wealth of auxiliary functions for existing windows:


Only Display Current Measurement: When multiple measurements exist, the concentration of Traces from different measurements can make observation inconvenient. Selecting this interface will display only the Traces corresponding to the current measurement.



Trace Window Layout

Window Layout	Description
Single	All Traces are displayed within a single Tab Group.
Stack N	N Trace windows are displayed stacked on top of each other.
Grid NxM	A grid of Trace windows with N rows and M columns.
Custom	A customizable layout dialog can be invoked to define the number of rows and columns in the grid to be displayed.


Singe




Stack N




Grid NxM




Custom



Trace Window Resize: SigVSA supports the addition of multiple windows for display. Windows added via the Trace method are displayed side by side. To better view different Trace windows, you can click on Trace Window Resize to tile all windows for display.



Delete All Empty Window: When a Trace window shows No Data, you can quickly close all windows without data by clicking on Delete All Empty Window.




2.8 Utilities

SigVSA supports two functionalities: file analysis and real-time analysis through connection to the underlying hardware. The Utilities feature allows for convenient configuration of the underlying hardware information.

Remote Device Management:

Used for adding, deleting, and connecting to the underlying hardware, among other functions. After entering the IP address of the underlying hardware to add and connect the device, you can associate the measurement window through the Data Source Setting interface. Once associated, the information is displayed as follows:




Data Source Setting :

The data source can be set through two entry points:

- ① Under the measurement management directory, select the measurement to be associated, and choose to connect and analyze either through File or a remote underlying hardware.
- ② Select Utilities -> Data Source Setting, and in the pop-up window interface, choose to connect and analyze through File or a remote underlying hardware. Typically, method one is simpler and faster.

Note: When using method two for association, it is necessary to explicitly select the measurement to be associated, otherwise, the associated measurement may not match the expectation.




3 Measurement

3.1 IQA

3.1.1 Configuration

The path to access the IQA configuration interface is: **Meas Setup** -> **IQA Properties**.



3.1.1.1 Meas

1. Meas Time

Set the measurement duration.

2. Sample Rate


Set the sampling rate.

3. Center Freq

Set the center frequency.

3.1.2 Measurement Results


The path to set IQA measurement results is: **Trace** -> **Format**.



Setup Steps:

- 1) Select the display window.
- 2) Choose Result to switch the measurement result data to be displayed.

Example of Measurement Results:



1. Real

Displays the time-domain waveform of the I-channel data.

2. Q-Imag

Displays the time-domain waveform of the Q-channel data.

3. RF Envelop

RF envelope diagram, showing the time-domain waveform of IQ data.

4. Wrap Phase

Wrapped phase diagram.

5. Unwrap Phase

Unwrapped phase diagram.


6. Spectrum

Frequency spectrum diagram.


3.2 OFDM

3.2.1 Configuration

The path to enter the OFDM configuration interface is: **Meas Setup** -> **OFDM Properties**.



3.2.1.1 Meas Time



1. Search Length

Specify the amount or length of input data to include in the measurement burst search.

Range: 0 ~ 100 s, Default: 512 us for WLAN 802.11a; 20ms for LTE DL/UL.

Unit options: ns | s | μ s | s, Default: μ s.

Note: The minimum value of Search Length is also limited by the value of Result Length, and the actual minimum value of the sampling time for each OFDM symbol is greater than 0.

2. Result Length

Used to specify the amount of collected time data (in symbols) available for measurement analysis. For OFDM, the result length data includes the preamble and payload data symbols starting from the first preamble symbol in the measurement burst.

Default: 64.

Range: 1 - The number of OFDM symbols corresponding to Search Length.

3. Meas Interval

Specify the length of time (in integer symbols) for the data measurement range in Result Length, used to calculate and display tracking data results.

The Meas Offset parameter is used to locate the starting point of the measurement interval data, related to the first symbol in the measurement burst. The sum of Meas Interval and Meas Offset must fit within the range of the measurement Result Length, with the Result Length and Result Length Selection properties determining the maximum length of time (in symbols) that Meas Interval can locate.

Default: 64.

Range: 1 - Result Length.

4. Meas Offset

Set the time offset (in symbols) for the measurement range. Specifies the starting position of Meas Interval relative to the first symbol within Result Length.

Default: 0.

Range: 0 - (Result Length - Meas Interval).

5. Down Sampling Ratio

Specify the downsampling factor for the received signal.

Default: 1,

Range: Positive integer. Data type: Integer.

3.2.1.2 Format

1. FFT Length

The FFT length used for OFDM transmission, must be a power of 2.

Default: 64.

Range: 4 to 65536. Data type: Integer.

2. Sys Sample Freq

System sampling rate, in Hz. Data type: Float.

3. Guard Lower Subcarriers

Set the number of lower guard subcarriers.

Default: 0 - FFT Length/2.

4. Guard Upper Subcarriers

Set the number of upper guard subcarriers.

Default: 0 - (FFT Length - Guard Lower Subcarriers - 1).

5. Half Subcarrier Shift

This parameter is needed for demodulating LTE OFDM. Enables or disables the half subcarrier shift of

phase reset at each OFDM symbol (i.e., LTE uplink signal). Data type: Boolean.

6. DFT Spread

Demodulate SC-OFDM, LTE uplink signal. Data type: Boolean.

7. Transmitter Window Beta

Set how much windowing is used at the transmitter to smooth transitions between symbols. Specified as a fraction of the OFDM FFT length. This value is unitless (not a percentage).

Default: 0.005.

Range: 0 - GuardInterval. Data type: Float.

This parameter specifies the window filter Beta value. Beta is the amount of windowing used by the transmitter to smooth transitions between symbols.

3.2.1.3 Mapping

1. Pilot IQ

Pilot data IQ values.

2. Preamble IQ

Preamble data IQ values.

3. Resource Mapping

Resource grid distribution, the resource mapping file defines the function of each subcarrier in each symbol, describing whether the subcarrier is Preamble, Pilot, Data, or null subcarrier type. The resource mapping file must contain one value for each valid (i.e., non-guard) subcarrier, including the "DC" center subcarrier. Therefore, a mapping for an 802.11a/g signal (FFT size of 64, with 11 guard subcarriers) will contain 53 values per symbol. If the number of pilots in the pilot value array is insufficient to fill the resource mapping, the pilot values are repeated to fill the remaining resource mapping pilot positions.

4. Guard Interval

Set the guard interval (also known as cyclic prefix) for each symbol individually. Each is specified as a fraction of the OFDM FFT length. This value is unitless (not a percentage). Guard Interval is typically between 1/16 to 1/4, entered in decimal form.

Default: 0.25.

Range: 0 – 1. Data type: Float.

Note: Ensure that the result of $\text{FFTLength} \times \text{GuardInterval}$ is an integer based on the FFT Length.

5. Guard Interval Repeat Index

If the Guard Interval array is at least as long as the measurement result length, it provides a guard interval value for each symbol. If the array is shorter than the measurement result length, the array is cycled (and continues to cycle each time the end of the array is reached again). The position cycled back to in the array is determined by the Guard Interval Repeat Index.

Default: 0.

Range: 0 – (array length – 1).

6. Time Gap

Set the time gap before the start of each OFDM symbol. Each is specified as the number of samples at the OFDM system sampling frequency.

Default: 0.

Range: Non-negative integer.

7. Time Gap Repeat Index

If the Time Gaps array is at least as long as the measurement result length, it provides a time gap value for each symbol. If the array is shorter than the measurement result length, the array is cycled (and continues to cycle each time the end of the array is reached again). The position cycled back to in the array is determined by the Repeat Index. This repeat index works in the same way as the Guard Interval Repeat Index and Guard Interval array.

3.2.1.4 Equalizer

1. Use Data

Enable/disable the use of data subcarriers to assist in training the equalizer.

Default: Off.

2. Use DC Pilot

Specify whether the pilot subcarrier on the DC is used for channel estimation. This only applies when Equalizer Use Pilots is enabled and the resource mapping specifies that the DC subcarrier is a pilot.

3. Use Pilot

Enable/disable the use of pilot subcarriers to assist in training the equalizer. Note: The DC subcarrier is ignored; to include the DC subcarrier, enable Equalizer Use DC Pilot.

4. Use Preamble

Enable/disable the use of preamble subcarriers to assist in training the equalizer. After initialization, the equalizer coefficients remain unchanged while demodulating the rest of the OFDM burst.

5. Initial Mode

Set the mode used to construct the initial equalizer. When creating the initial channel equalizer, the Custom OFDM analysis attempts to use any available information from known pilot and preamble subcarriers. The initial equalizer mode controls which symbols are included when searching for known pilot and preamble subcarriers. It can be set to Automatic or Manual.

Default: Automatic.

Automatic: Custom OFDM analysis attempts to use all symbols containing known pilot or preamble subcarriers.

Manual: The user specifies the number of symbols to use. The number of symbols is specified by the Initial Equalizer Symbols property. Manual mode may be useful for signals without a preamble and with known pilots in many symbols. If there is significant frequency drift, an initial equalizer built with fewer symbols may be more accurate.

6. Initial Symbol

Specify the number of symbols used when the initial equalizer mode is set to manual. Data type: Integer.

Default: 4Symbol.

3.2.1.5 Tracking

1. Include Data Subcarriers

Enable/disable the use of data subcarriers in phase, amplitude, and timing tracking. When enabled, the VSA uses pilot and data subcarriers in phase, amplitude, and timing tracking. When disabled, the VSA only uses pilot subcarriers for tracking (default is disabled).

Some signal formats (e.g., LTE and LTE-related formats) do not include pilots in every symbol. In such cases, selecting this setting will improve EVM by ensuring tracking for symbols without pilot subcarriers.

2. Track Amplitude

Enable/disable tracking and compensation of pilot subcarrier amplitude. The VSA applies pilot subcarrier amplitude error correction to pilot and data subcarriers (default is enabled).

3. Track Phase

Enable/disable tracking and compensation of pilot subcarrier phase. The VSA applies pilot subcarrier phase error correction to pilot and data subcarriers (default is enabled).

4. Track Timing

Enable/disable tracking and compensation of pilot phase ramp (symbol clock timing). The VSA applies pilot subcarrier timing error correction (frequency offset correction) to pilot and data subcarriers (default is enabled).

3.2.1.6 Advanced

1. Filter Type

Filter type.

Default: None.

2. Meas Standard

Preset demodulation OFDM standard signal types.

Default: WIFI.

3. Timing Adjust

Set the symbol timing adjustment. This value is a percentage of the OFDM FFT length. The value is negative because it represents an adjustment from the end of the OFDM symbol.

Default: -12.5%.

Range: 0 - GuardIntervalPerSymbol.

4. Sync Mode

Set the synchronization mode used for signal synchronization.

Time Correlation: The VSA uses time correlation between the user-defined preamble and the

measured signal to synchronize to the start of the OFDM burst.

Cyclic Prefix: Synchronizes the start of the OFDM burst to the cyclic prefix.

5. Center Frequency

Signal center frequency.

Default: 1GHz.


6. Report Evm In db

Enable switch for converting EVM to dB units.

Default: Off.

3.2.2 Measurement Result

The path to set OFDM measurement results is: **Trace** -> **Format**.



Setup steps:

- 1) Select the display window;
- 2) Select Group, different measurement results are placed in different groups;
- 3) Select the measurement result data to display.

1. Raw Main Time

Display the magnitude of raw data input from hardware or read from a playback file, with time on the x-axis and amplitude on the y-axis.

2. Spectrum

Display the spectrum of raw data input from hardware or read from a playback file, with frequency on

the x-axis and amplitude on the y-axis.

3. IQ Meas Time

IQ Measurement Time displays the constellation diagram of data within the measurement length, with amplitude (normalized amplitude) on both the x-axis and y-axis.

4. Error Summary

Error Summary includes the following error items of the measurement results:

EVM: Average EVM value of all Pilot, Preamble, Data;

EVM Peak: Peak EVM value of all Pilot, Preamble, Data;

Pilot EVM: Average EVM value of all Pilot;

Data EVM: Average EVM value of all Data;

Preamble EVM: Average EVM value of all Preamble;

SNR/MER: Signal-to-noise ratio;

Freq Error: Frequency offset relative to the carrier center;


Sync Corr: Correlation between measured synchronization signal and reference synchronization signal;

Tx Power: Transmit signal power.

3.3 Digital Modulation(DMA)

3.3.1 Configuration

The path to enter the DMA configuration interface is: **Meas Setup** -> **DMA Properties**.



3.3.1.1 Frame

1. Search Length

Set the data length of the collected Raw Data, with units in us/ms. The adjustable range depends on the device's IQ acquisition capability, with a default value of 610 us.

2. Segment Number

Set the number of segments per frame of data. This is an integer value without units, ranging from 1 to 6, with a default value of 1.

3. Segment Selected

Select the segment, with Segment 0 as the default.

4. Burst Search

Pulse Search Switch: On/Off, default setting is Off.

5. Burst Search Threshold

Pulse search threshold, default value: -15 dB, minimum: -200.0, maximum: 200.0.

6. Sync Search

Synchronization search switch, On/Off, default is Off.

7. Sync Offset

Specify the time (in symbols) between the start of the measurement data and the start of the synchronization word. If the value is positive, the synchronization word starts after the beginning of the measurement data. If the value is negative, the synchronization word starts before the beginning of the measurement data.

8. Sync Pattern

Set the input synchronization sequence format.

9. Sample Rate

Set the demodulation sampling rate mode, default is Auto.

3.3.1.2 Meas Time

1. Meas Interval Symbol

Measurement length refers to the data length used for calculating EVM, measured in symbols (Symbols).

2. Meas Offset Symbol

Measurement offset, relative to the Meas Offset Ref, unit: symbols (Symbols).

3. Meas Offset Reference

Set the reference point for the offset, with two options available.

- **Relative To Capture:** Specifies that the offset of the segment is relative to the start of the captured data.
- **Relative To Sync Pattern:** The offset of the segment is relative to the starting position of the synchronization pattern.

3.3.1.3 Demod

1. Modulation Type

Set the modulation format category of the signal to be demodulated, with the default parameter being PSK.

2. PSK Formats

Set the subcategory of the PSK modulation format for the signal to be demodulated. The default parameter is BPSK.

3. QAM Formats

Set the subcategory of the QAM modulation format for the signal to be demodulated, with the default parameter being 16QAM.

4. FSK Formats

Set the subcategory of the FSK modulation format for the signal to be demodulated, with the default parameter being 2FSK.

5. MSK Formats

Set the modulation format subclass for the demodulated MSK signal, with the default parameter as MSK Type1.

6. ASK Formats

Set the subcategory of the MSK modulation format for the signal to be demodulated, with the default parameter being MSK Type1.

7. APSK Formats

Set the subcategory of the APSK modulation format for the signal to be demodulated, with the default parameter being 16-APSK.

8. OQPSK Formats

Set the subcategory of the OQPSK modulation format for the signal to be demodulated, with the default parameter being Offset QPSK.

9. DPSK Formats

Set the subcategory of the DPSK modulation format for the signal to be demodulated, with the default parameter being DBPSK.

10. Points

Set the number of points displayed per symbol in the time-domain representation of the demodulated data.

11. Symbol Rate

Set the symbol rate (symbols per second) for the digital demodulator. Max BW represents the selected bandwidth; for PC-segment VSA, the maximum bandwidth is 20 GHz.

12. Bandwidth

Set the multicarrier filter bandwidth.

13. Meas Filter

Set the measurement filter type, with the default parameter being Root Raised Cosine.

14. Ref Filter

Set the reference filter type, with the default parameter being Raised Cosine.

15. Alpha

The shape and bandwidth of the filter are defined by alpha (for cosine filters) or BT (for Gaussian filters).

16. Filter Length

Set the length of the instrument equalization filter.

17. Equalizer

Enable or disable the adaptive equalization filter. Adaptive equalization uses the measured signal to determine the coefficients of the equalization filter.

18. Equalizer Filter Length

Set the length of the instrument equalization filter in symbols.

19. Hold

Enable or disable filter coefficient updates. Typically, the adaptive algorithm updates the filter coefficients after each scan. When Hold is enabled, the coefficients of the equalization filter are frozen—meaning the adaptive filter becomes fixed. Disabling Hold again will allow the coefficients to resume adaptation from their current positions.

20. Coefficient

Setting the adaptive filter convergence factor higher results in faster convergence speed.

21. FFT Window

Set the window function used for calculating the spectrum with FFT.

22. Multi-Carrier Filter

Specify whether to apply a filter to the acquired IQ data to filter out adjacent carriers.

23. Spectrum

Set the spectrum to Normal or Invert for demodulation-related measurements. If set to Invert, the upper and lower spectra are swapped.

24. Gain Imb/Quad Skew Couping

Control the measurement data included in the calculation of quadrature tilt error and IQ gain imbalance error.

Off (default value): Calculates using one point per symbol.

On: Calculations use the value displayed in the "Points per Symbol" parameter box.

25. Clock Adjust

Adjust the symbol clock timing in fractional multiples of symbols.

26. IQ Normalize

Enable or disable IQ Normalize. When enabled, measurement errors will be normalized, with the normalization coefficient determined based on the setting of EVM Normalization Reference.

27. IQ Rotation

Rotate the IQ Meas/Ref Time data and the corresponding ideal constellation points by a user-defined amount, specified in degrees, ranging from -360 to 360 degrees. The Rotation parameter affects the IQ Gain Imbalance and Quadrature Skew error data results.

28. IQ Normalize

Enable or disable IQ Normalize. When enabled, measurement errors will be normalized, with the normalization coefficient determined based on the EVM Normalization Reference setting.

29. Low SNR Enhancement

Enhance the demodulator's ability to lock onto low SNR signals.

30. EVM Normalization Reference

The EVM normalization reference has two possible values:

Constellation Maximum (Default): Sets the normalization value to the maximum constellation amplitude. For "cross-QAM" constellations (32QAM, 128QAM, 512QAM), the normalization value will be set to the magnitude of the outer corners of the square containing the constellation, even if the constellation itself does not actually use those outer corners.

Reference RMS: Sets the normalization value to the RMS level of the IQ reference symbol points. If the only impairment in the input signal is additive white Gaussian noise, using Reference RMS will make the average EVM approximately equal to the reciprocal of the signal's signal-to-noise ratio. Using Reference RMS also makes it easier to compare EVM values between signals with different modulation formats.

31. IQ Offset Compensation

Before calculating metrics such as EVM, select whether to compensate for IQ offset during parameter estimation and compensation timing.

Applicable only to IQ modulation formats other than FSK, ASK, CPM (FM), and DVB QAM.

It automatically turns on if the modulation format is changed to any format other than MSK Type1. For the MSK Type1 format, it automatically turns off.

32. Average Move Length

Average move length.


3.3.1.4 Ber

Ber State

Enable or disable Tx BER. When Tx BER is enabled, the results for bit error rate, error bits, and total bits will be displayed in the Demodulated Bits window.

3.3.2 Measurement Results


The DMA measurement result settings path is: **Trace -> Format**.



Setup Steps:

- 1) Select the display window.
- 2) Choose a Group to organize different measurement results into separate categories.
- 3) Select Result to switch the measurement result data to be displayed.
- 4) Choose Format to switch the format of the displayed measurement results.

Example of Measurement Results (1024QAM):



1. Raw Main Time

Displays the magnitude of the captured raw IQ data, with the demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

2. Spectrum

Displays the spectrogram of IQ data before demodulation, which is the FFT of Raw Main Time. The horizontal axis is in frequency units (Hz, kHz, MHz, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

3. Time

The magnitude of the resampled IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

4. IQ Meas Time

Displays the time-domain representation of the measured IQ data. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

- 1) **LogMag:** The logarithmic magnitude of the measured data, calculated using the formula: $20 * \log_{10}(|a(n)|)$.
- 2) **LineMag:** The linear magnitude of the measured data, calculated using the formula: $|a(n)|$, supports only normalized amplitude.
- 3) **Real/Imag:** Displays the real or imaginary part of the data. Requires marking the decision point positions and supports only normalized amplitude.
- 4) **Wrap Phase:** Displays the phase of the data, with the phase folded into the range of $-\pi$ to π . The decision point positions must be marked. The calculation formula is: $\text{angle}(a(n))$.
- 5) **UnWrap Phase:** Displays the unwrapped phase of the data. Decision point positions must be marked. The calculation formula is: $\text{angle}(a(n))$, followed by phase unwrapping.
- 6) **I-Q:** Displays the IQ values of the data as a two-dimensional image. Decision point positions must be marked. Only normalized amplitude is supported.
- 7) **Constellation:** Displays the data in a constellation diagram format, which shows only the values at the decision points. Decision point positions must be marked. Only normalized amplitude is supported.

- 8) **I-Eye/Q-Eye:** Displays the real or imaginary part of the data in an eye diagram format. By default, the horizontal axis shows the overlay of 3 symbols, but more symbols can be configured. The eye diagram is implemented by plotting multiple symbols together and overlaying them, with the default being 3 symbols. Only normalized amplitude is supported.
- 9) **Group Delay:** Displays the group delay of the data. The calculation formula is: $\text{diff}(\text{angle}(a(n)))$, where diff represents the difference calculation.

5. IQ Ref Time

Displays the time-domain representation of the reference IQ data. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

6. IQ Meas Spectrum

Displays the spectrum of the measured IQ data, calculated by performing FFT on the measured data. The horizontal axis is in frequency units (Hz, kHz, MHz), and the vertical axis is in dB.

7. Error Vector Time

The magnitude of the vector error. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

8. Error Vector Spectrum

The spectrum of the vector error. The horizontal axis is in frequency units (Hz, kHz, MHz), and the vertical axis is in logarithmic percentage units (dB%).

9. Mag Error

The amplitude error between the measured and reference signals. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

10. Phase Error

The phase error between the measured and reference signals. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

11. Error Summary

Display the demodulated data table:


Parameters for QAM:

- 1) **EVM:** RMS and peak, unit: %m%n%ldB.
- 2) **Mag Error:** RMS and peak, unit: %m%n%.
- 3) **Phase Error:** RMS and peak, unit: deg|mdeg.
- 4) **Freq Error:** Carrier frequency offset, unit: mHz|Hz|kHz|MHz.
- 5) **Clock Error:** Sampling clock deviation, unit: mHz|Hz|kHz|MHz.
- 6) **IQ Offset:** IQ offset, unit: dB.
- 7) **SNR (MER):** Signal-to-noise ratio, unit: dB.
- 8) **Quad Error:** Quadrature error, unit: deg.
- 9) **Gain Imbalance:** IQ imbalance, unit: dB.

12. Demod Bits

Display the demodulated bits. Mark the synchronization results when the synchronization function is enabled. When BER is enabled, this table includes BER results.

Example of Measurement Results (32APSK):



1. Raw Main Time

Displays the magnitude of the captured raw IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

2. Spectrum

Displays the spectrogram of IQ data before demodulation, which is the FFT of Raw Main Time. The horizontal axis is in frequency units (Hz, kHz, MHz, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

3. Time

The magnitude of the resampled IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

4. IQ Meas Time

Displays the time-domain representation of the measured IQ data. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

- 1) **LogMag:** The logarithmic magnitude of the measured data, calculated using the formula: $20 * \log_{10}(|a(n)|)$.
- 2) **LineMag:** The linear magnitude of the measured data, calculated using the formula: $|a(n)|$, supports only normalized amplitude.
- 3) **Real/Imag:** Displays the real or imaginary part of the data. Requires marking the decision point positions and supports only normalized amplitude.
- 4) **Wrap Phase:** Displays the phase of the data, with the phase folded into the range of $-\pi$ to π . The decision point positions must be marked. The calculation formula is: $\text{angle}(a(n))$.
- 5) **UnWrap Phase:** Displays the unwrapped phase of the data. Decision point positions must be marked. The calculation formula is: $\text{angle}(a(n))$, followed by phase unwrapping.
- 6) **I-Q:** Displays the IQ values of the data as a two-dimensional image. Decision point positions must be marked. Only normalized amplitude is supported
- 7) **Constellation:** Displays the data in a constellation diagram format, which shows only the values

at the decision points. Decision point positions must be marked. Only normalized amplitude is supported.

- 8) **I-Eye/Q-Eye:** Displays the real or imaginary part of the data in an eye diagram format. By default, the horizontal axis shows the overlay of 3 symbols, but more symbols can be configured. The eye diagram is implemented by plotting multiple symbols together and overlaying them, with the default being 3 symbols. Only normalized amplitude is supported.
- 9) **Group Delay:** Displays the group delay of the data. The calculation formula is: $\text{diff}(\text{angle}(a(n)))$, where diff represents the difference calculation.

5. IQ Ref Time

Displays the time-domain representation of the reference IQ data. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

6. IQ Meas Spectrum

Displays the spectrum of the measured IQ data, calculated by performing FFT on the measured data. The horizontal axis is in frequency units (Hz, kHz, MHz), and the vertical axis is in dB.

7. Error Vector Time

The magnitude of the vector error. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

8. Error Vector Spectrum

The spectrum of the vector error. The horizontal axis is in frequency units (Hz, kHz, MHz), and the vertical axis is in logarithmic percentage units (dB%).

9. Mag Error

The amplitude error between the measured and reference signals. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

10. Phase Error

The phase error between the measured and reference signals. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

11. Error Summary

Display the demodulated data table:


Parameters for QAM:

- 1) EVM: RMS and peak, unit: %|m%n%|dB.
- 2) Mag Error: RMS and peak, unit: %|m%n%|.
- 3) Phase Error: RMS and peak, unit: deg|mdeg.
- 4) Freq Error: Carrier frequency offset, unit: mHz|Hz|kHz|MHz.
- 5) Clock Error: Sampling clock deviation, unit: mHz|Hz|kHz|MHz.
- 6) IQ Offset: IQ offset, unit: dB.
- 7) SNR (MER): Signal-to-noise ratio, unit: dB.
- 8) Quad Error: Quadrature error, unit: deg.
- 9) Gain Imbalance: IQ imbalance, unit: dB.

12. Demod Bits

Display the demodulated bits. Mark the synchronization results when the synchronization function is enabled. When BER is enabled, this table includes BER results.

Example of Measurement Results (16FSK):



1. Raw Main Time

Displays the magnitude of the captured raw IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

2. Spectrum

Displays the spectrogram of IQ data before demodulation, which is the FFT of Raw Main Time. The horizontal axis is in frequency units (Hz, kHz, MHz, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

3. Time

The magnitude of the resampled IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

4. IQ Meas Time

Displays the time-domain representation of the measured IQ data. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

- 1) **LogMag:** The logarithmic magnitude of the measured data, calculated using the formula: $20 * \log_{10}(|a(n)|)$.
- 2) **LineMag:** The linear magnitude of the measured data, calculated using the formula: $|a(n)|$, supports only normalized amplitude.
- 3) **Real/Imag:** Displays the real or imaginary part of the data. Requires marking the decision point positions and supports only normalized amplitude.
- 4) **Wrap Phase:** Displays the phase of the data, with the phase folded into the range of $-\pi$ to π . The decision point positions must be marked. The calculation formula is: $\text{angle}(a(n))$.
- 5) **UnWrap Phase:** Displays the unwrapped phase of the data. Decision point positions must be marked. The calculation formula is: $\text{angle}(a(n))$, followed by phase unwrapping.
- 6) **I-Q:** Displays the IQ values of the data as a two-dimensional image. Decision point positions must be marked. Only normalized amplitude is supported.

- 7) **Constellation:** Displays the data in a constellation diagram format, which shows only the values at the decision points. Decision point positions must be marked. Only normalized amplitude is supported.
- 8) **I-Eye/Q-Eye:** Displays the real or imaginary part of the data in an eye diagram format. By default, the horizontal axis shows the overlay of 3 symbols, but more symbols can be configured. The eye diagram is implemented by plotting multiple symbols together and overlaying them, with the default being 3 symbols. Only normalized amplitude is supported.
- 9) **Group Delay:** Displays the group delay of the data. The calculation formula is: $\text{diff}(\text{angle}(a(n)))$, where diff represents the difference calculation.

5. IQ Ref Time

Displays the time-domain representation of the reference IQ data. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

6. IQ Meas Spectrum

Displays the spectrum of the measured IQ data, calculated by performing FFT on the measured data. The horizontal axis is in frequency units (Hz, kHz, MHz), and the vertical axis is in dB.

7. Error Vector Time

The magnitude of the vector error. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

8. Error Vector Spectrum

The spectrum of the vector error. The horizontal axis is in frequency units (Hz, kHz, MHz), and the vertical axis is in logarithmic percentage units (dB%).

9. Mag Error

The amplitude error between the measured and reference signals. The horizontal axis is in units of symbols (depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

10. Phase Error

The phase error between the measured and reference signals. The horizontal axis is in units of symbols

(depending on the data format), and the vertical axis units are determined by the data format.

The definitions of various data formats are the same as those for IQ Meas Time.

11. Error Summary

Display the demodulated data table:

FSK parameters:

- 1) FSK Error: RMS and peak, unit: %|m%|n%|dB.
- 2) Mag Error: RMS and peak, unit: %|m%|n%.
- 3) Freq Error: Carrier frequency offset, unit: mHz|Hz|kHz|MHz.
- 4) Clock Error: Sampling clock deviation, unit: mHz|Hz|kHz|MHz.
- 5) Deviation: Frequency deviation, unit: mHz|Hz|kHz|MHz.

12. Demod Bits


Display the demodulated bits. Mark the synchronization results when the synchronization function is enabled. When BER is enabled, this table includes BER results.

3.4 NR

5G NR demodulation is compatible with the 5G NR standard: 3GPP TS38 V17.3.0 (2022-09).

3.4.1 Properties

The path to enter the 5G NR configuration interface is: **Meas Setup** -> **5G NR Properties**.




3.4.1.1 Config Carrier

3.4.1.1.1 Carrier

NR supports a maximum of 16 carrier measurements, which are managed in a tabular format, with only one carrier available by default. The number of carriers is managed through the following two buttons:

Add Carrier: Adds a carrier at the last row of the table, with the total number that can be added ranging from 1 to 16;

Remove Carrier: Removes the currently selected carrier from the table.



The list displays all carrier information, and by selecting a row, you can modify the parameters of the chosen carrier.

1. CCn Enabled

Optional: On | Off; Default: On.

This option is used to set the enable state of the current carrier. By default, carrier CC0 is displayed, and by selecting a different carrier CCn from the list, the current parameter name changes accordingly to CCn Enabled.

2. Phase Compensation

Optional: Off | Auto | Manual; Default: Auto.

Sets the phase compensation switch and the frequency for phase compensation.

- Off: Turn off phase compensation.

- Auto: The phase compensation frequency is obtained from the center frequency.
- Manual: Manually set the phase compensation frequency.

3. Carrier Type

Optional: Downlink | Uplink;

Default: Downlink.

This option is used to switch between the configuration of uplink or downlink carriers.

4. Center Frequency

Configurable range: 0 Hz ~ 100 GHz, Default value: 1 GHz.

Unit options: Hz | kHz | MHz | GHz, Default unit: GHz.

Set the center frequency of the current carrier.

5. Frequency Range

Optional: FR1 | FR2-1 | FR2-2, Default: FR1.

Select the frequency band of the current carrier, with specific frequency ranges detailed in Table 3-1.

Table 3-1 Operational Frequency Band Ranges

Frequency range designation		Corresponding frequency range
FR1		410 MHz - 7125 MHz
FR2	FR2-1	24250 MHz - 52600 MHz
	FR2-2	52600 MHz - 71000 MHz

6. Spectrum

Optional: On | Off, Default: Off.

Toggle the spectrum inversion state; turning it on inverts the Q-path in the signal IQ data.

7. Bandwidth

Optional:

FR1 5MHz | FR1 10MHz | FR1 15MHz | FR1 20MHz | FR1 25MHz | FR1 30MHz

FR1 35MHz | FR1 40MHz | FR1 45MHz | FR1 50MHz | FR1 60MHz | FR1 70MHz

FR1 80MHz | FR1 90MHz | FR1 100MHz

FR2-1 50MHz | FR2-1 100MHz | FR2-1 200MHz | FR2-1 400MHz

FR2-2 100MHz | FR2-2 400MHz | FR2-2 800MHz | FR2-2 1600MHz | FR2-2 2000MHz

Default value: FR1 100MHz.

Set the channel bandwidth, with different bandwidths corresponding to the three frequency ranges (Frequency Range) FR1, FR2-1, and FR2-2 in the 3GPP protocol, and the specific constraints related to subcarrier spacing (SCS) and the number of resource blocks (RB) are detailed in Table 3-2, Table 3-3, and Table 3-4.

Note: This parameter is constrained by the Frequency Range parameter, and the configurable bandwidth displayed varies depending on the frequency band.

Table 3-2 (Table 5.3.2-1) Transmission bandwidth configuration NRB for FR1

SCS (kHz)	5 MHz	10 MHz	15 MHz	20 MHz	25 MHz	30 MHz	35 MHz	40 MHz	45 MHz	50 MHz	60 MHz	70 MHz	80 MHz	90 MHz	100 MHz
	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}
15	25	52	79	106	133	160	188	216	242	270	N/A	N/A	N/A	N/A	N/A
30	11	24	38	51	65	78	92	106	119	133	162	189	217	245	273
60	N/A	11	18	24	31	38	44	51	58	65	79	93	107	121	135

Table 3-3 (Table 5.3.2-2) Transmission bandwidth configuration NRB for FR2-1

SCS (kHz)	50 MHz	100 MHz	200 MHz	400 MHz
	N _{RB}	N _{RB}	N _{RB}	N _{RB}
60	66	132	264	N/A
120	32	66	132	264

Table 3-4 (Table 5.3.2-3) Transmission bandwidth configuration NRB for FR2-2

SCS (kHz)	100 MHz	400 MHz	800 MHz	1600 MHz	2000 MHz
	N _{RB}	N _{RB}	N _{RB}	N _{RB}	N _{RB}
120	66	264	N/A	N/A	N/A
480	N/A	66	124	248	N/A
960	N/A	33	62	124	148



8. Cell ID

Configurable range: 0 ~ 1007, default 0.

Set the cell ID number of the current carrier.

3.4.1.1.2 Test Model

When the carrier type is Downlink, click on the DL Test Model at the top right corner of the Configs CCs menu to enter the demodulation settings for the downlink test mode.



1. Enabled

Optional: On | Off, Default: Off.

This option is used to switch the EVM statistics for the QPSK modulation scheme of test modes TM3.2 and TM3.3.

Note: This parameter only takes effect when the Test Model is set to TM3.2 | TM3.3. For specific constraints, please refer to the physical layer related content of the 3GPP protocol.

2. Frequency Range

Optional: FR1 | FR2-1 | FR2-2, Default: FR1.

Select the frequency band required for the test mode, with specific frequency ranges detailed in Table 3-1.

3. Bandwidth

Optional:

FR1 5MHz | FR1 10MHz | FR1 15MHz | FR1 20MHz | FR1 25MHz | FR1 30MHz

FR1 35MHz | FR1 40MHz | FR1 45MHz | FR1 50MHz | FR1 60MHz | FR1 70MHz

FR1 80MHz | FR1 90MHz | FR1 100MHz

FR2-1 50MHz | FR2-1 100MHz | FR2-1 200MHz | FR2-1 400MHz

FR2-2 100MHz | FR2-2 400MHz | FR2-2 800MHz | FR2-2 1600MHz | FR2-2 2000MHz

Default value: FR1 100MHz.

Select the channel bandwidth required for the test mode. Different bandwidths correspond to the three frequency ranges (Frequency Range) FR1, FR2-1, and FR2-2 in the 3GPP protocol, and the specific constraints related to subcarrier spacing (SCS) and the number of resource blocks (RB) are detailed in Table 3-2, Table 3-3, and Table 3-4.

4. Test Model

Optional:

NR-FR1-TM1.1 | NR-FR1-TM1.2 | NR-FR1-TM2 | NR-FR1-TM2a | NR-FR1-TM2b

NR-FR1-TM3.1 | NR-FR1-TM3.1a | NR-FR1-TM3.1b | NR-FR1-TM3.2 | NR-FR1-TM3.3

NR-FR1-TM11 | NR-FR1-TM1.2 | NR-FR1-TM2 | NR-FR1-TM2a | NR-FR1-TM2b

NR-FR1-TM3.1 | NR-FR1-TM3.1a | NR-FR1-TM3.1b | NR-FR1-TM3.2 | NR-FR1-TM3.3

NR-FR2-TM1.1 | NR-FR2-TM2 | NR-FR2-TM2a | NR-FR2-TM3.1 | NR-FR1-TM3.1a

Default value: NR-FR1-TM1.1.

Select the test mode you require.

Note: The options for this parameter are constrained by the **Frequency Range**.

5. Duplex Mode

Optional: TDD | FDD, Default: TDD.

Choose between different duplex types.

Note: The options for this parameter are constrained by the **Frequency Range**, with the FR2 band supporting only TDD.

6. SCS

Options:

FR1: $\mu = 1:30\text{KHz}$ | $\mu = 2:60\text{KHz}$

FR2-1: $\mu = 2:60\text{KHz}$ | $\mu = 3:120\text{KHz}$ | $\mu = 4:240\text{KHz}$

FR2-2: $\mu = 3:120\text{KHz}$ | $\mu = 5:480\text{KHz}$ | $\mu = 6:960\text{KHz}$

Default: $\mu = 1:30\text{KHz}$.

Set the subcarrier spacing for the current test mode.

Note: The options and display of this parameter are constrained by **Frequency Range** and **Test Model**.

7. Modulation

Options: QPSK | 16QAM | 64QAM, Default: QPSK.

This option is used to display or select the modulation scheme for the current test mode.

Note: The options and display of this parameter are constrained by **Frequency Range** and are configurable only in certain test modes (FR2 TM2 | FR2 TM3.1).

8. Port

Options: Port 0 | Port 1, Default: Port 0.


This option is used to display or select the antenna port for the current test mode.

Note: The options and display of this parameter are constrained by **Frequency Range** and **Duplex Mode** and are configurable only in certain test modes (TM1.1).

3.4.1.1.3 Resource Grid

Each carrier corresponds to a resource grid list, with each row in the list corresponding to a resource grid with a different parameter set. By default, all supported parameter sets are displayed, but only

one parameter set can be activated at a time.



1. Component Carrier

Options: C0 ~ currently existing carriers, Default: CC0.

Select the carrier for which the parameter set needs to be configured currently. When this option switches to a different carrier, the parameter configuration on the current page also switches to the configuration of the current carrier, without changing the parameters on other pages.

2. Carrier Type

Options: Downlink | Uplink, Default: Downlink.

This option is used to switch between the configuration of uplink or downlink carriers.

3. μ Enabled

Options: On | Off, Default: On.

Toggle the subcarrier spacing for the current subcarrier spacing. You can select the desired subcarrier spacing from the list above, and the parameter name will change according to the currently enabled subcarrier spacing.

Note: Multiple subcarrier spacings can be enabled simultaneously, but it is not allowed to disable all of them.

4. N_grid_start

Configurable range: 0 ~ maximum number of RBs for the numerology – 1, Default: 0.

Set the starting position of the resource blocks for the parameter set corresponding to the current carrier. For specific constraints, please refer to the physical layer related content of the 3GPP protocol.

5. N_grid_size

Configurable range: 6 ~ maximum number of RBs for the numerology - 1, Default: 0.

Set the number of resource blocks for the parameter set corresponding to the current carrier. For specific constraints, please refer to the physical layer related content of the 3GPP protocol.

6. K0


Displays the offset of the resource grid center relative to the carrier center for the parameter set corresponding to the current carrier.

3.4.1.1.4 BWP

The number of BWPs per carrier is managed through the BWP table, with a maximum limit of 100 BWPs. The number of BWPs is controlled by the following buttons:

Add BWP: Adds a BWP at the end of the list, with the default list containing 1 BWP.

Remove BWP: Removes the currently selected BWP.



The list displays all BWP information, and by selecting a BWP, you can modify the parameters of the chosen BWP.

1. Component Carrier

Options: CC0 ~ currently existing carriers, Default: CC0.

Select the carrier for which demodulation parameters need to be configured currently. When this option switches to a different carrier, the parameter configuration on the current page also switches to the configuration of the current carrier, without changing the parameters on other pages.

2. SCS

Options:

FR1: $\mu = 1:30\text{KHz} \mid \mu = 2:60\text{KHz}$

FR2-1: $\mu = 2:60\text{KHz} \mid \mu = 3:120\text{KHz} \mid \mu = 4:240\text{KHz}$

FR2-2: $\mu = 3:120\text{KHz} \mid \mu = 5:480\text{KHz} \mid \mu = 6:960\text{KHz}$

Default: $\mu = 1:30\text{KHz}$.

Set the subcarrier spacing for the current BWP, constrained by Frequency Range and Channel Bandwidth.

3. Cyclic Prefix

Options: Normal | Extended, Default: Normal.

Set the cyclic prefix type for the current BWP. When SCS is 60kHz, both Normal and Extended are available; for other SCS values, only Normal is displayed, and Extended is not configurable.

4. CORESET Number

Configurable range: 1 ~ 3, Default: 1.

Set the number of CORESETs included in the current BWP.

5. N BWP Start

Configurable range: current N_grid_start value ~ maximum number of RBs for the numerology - 1,

Default: N_grid_start value.

Set the starting position of the BWP offset relative to PointA, constrained by N_grid_start.

6. N BWP Size

Configurable range: 6 ~ current N_grid_start value, Default: N_grid_start value.

Set the size of the BWP, constrained by N_grid_start.

7. Max RB Number

Displays the maximum number of RBs that can be set for the current BWP.

Set the RB offset value for the current CORESET. When set to -1, it indicates no configuration, aligning with pointA.

5. Duration

Configurable range: 1~3, Default: 1.

Set the number of symbols for the current CORESET.

6. Freq Domain Resources

Setting content: One bit represents one RBG, checking indicates activation of that bit.

Set the frequency domain resources allocated to PDCCH for the current CORESET, configured via Bitmap, with each bit representing 6 consecutive RBs (REG), supporting up to 45 bits. Checking the corresponding bit position indicates activation of the corresponding group of 6 RBs.

7. CCE-REG-Mapping Type

Options: Interleaved | Non-Interleaved, Default: Non-Interleaved.

Set the mapping method from CCE to REG.

8. REG-Bundle Size

Options: 2 | 3 | 6, Default: 6.

When the parameter CCE-REG Mapping Type is set to interleaved mapping, this parameter is used to set the parameter L for interleaved mapping, see 3PPG protocol for specific constraints; for non-interleaved mapping, L defaults to 6.

Note: Only displayed when CCE-REG Mapping Type is set to Interleaved.

9. Interleaver Size

Options: 2 | 3 | 6, Default: 3.

Set the interleaver size for interleaved mapping.

Note: Only displayed when CCE-REG Mapping Type is set to Interleaved.

10. Shift Index

Configurable range: -1 ~ 274, Default: 0 (set to -1 to use CellID).

Set the n_{shift} parameter for interleaved mapping.

Note: Only displayed when **CCE-REG Mapping Type** is set to Interleaved.

11. Precoder Granularity

Options: Reg Bundle Size | CORESET Size, Default: Reg Bundle Size.


Set the precoding granularity. When this parameter is set to Reg Bundle Size, DMRS is only mapped to REGs with PDCCH; when set to CORESET Size, DMRS is mapped to all RBs of the CORESET.

Note: Only displayed when **CCE-REG Mapping Type** is set to Interleaved.

3.4.1.2 Channel(Downlink)

3.4.1.2.1 SSB

Currently, only one SSB setting is supported per carrier. Select the carrier through the **Component Carrier** parameter, and the SSB page displays the SSB of the current carrier, allowing for parameter configuration.



1. Enable

Options: On | Off, Default: Off.

SS/PBCH Block channel enable switch.

2. Numerology

Options:

FR1: $\mu = 1:30\text{kHz} \mid \mu = 2:60\text{kHz}$;

FR2-1: $\mu = 2:60\text{kHz} \mid \mu = 3:120\text{kHz} \mid \mu = 4:240\text{kHz}$;

FR2-2: $\mu = 3:120\text{kHz} \mid \mu = 5:480\text{kHz} \mid \mu = 6:960\text{kHz}$.

This parameter is the subcarrier parameter set μ , used to describe waveform characteristics, supporting 7 different subcarrier spacings, as detailed in Table 3-2 to Table 3-4 and Table 3-5. Related parameters for Numerologies include: Subcarrier Spacing and μ , Cyclic Prefix type (CyclicPrefix: normal and Extended), starting RB (RB Start), and RB count (RB Size).

Table 3-5 Supported transmission parameter set settings

μ	$\Delta f = 2^\mu \cdot 15[\text{kHz}]$	Cyclic prefix
0	15	Normal
1	30	Normal
2	60	Normal, Extended
3	120	Normal
4	240	Normal
5	480	Normal
6	960	Normal

3. SS/PBCH Block Pattern

Options:

15kHz: Case A ;

30kHz: Case B | Case C ;

120kHz: Case D ;

240kHz: Case E .

Default: Case B.

Set the synchronization broadcast block pattern.

3.4.1.2.2 PDSCH


The number of PDSCH is operated by the following keys: Currently, a maximum of 20 PDSCH settings are supported per carrier. Select the carrier through the **Component Carrier** parameter, and the PDSCH page displays the configuration of the current carrier, allowing for parameter configuration and modification. The number of PDSCHs is controlled by the following buttons:

Add PDSCH: Adds a PDSCH at the end of the list, with the default list containing 1 PDSCH.

Remove PDSCH: Removes the currently selected PDSCH.

Remove PDSCH: Removes the currently selected PDSCH.

Clear All: Keeps only the first PDSCH, removing all others.



1. General Settings

1) PDSCH Enable

Options: On | Off, Default: On.

PUSCH channel enable switch.

2) Power Boosting

Configurable range: -40 dB ~ 40 dB, Default: 0 dB.

Set the power of PUSCH data relative to other channels.

3) RNTI

Configurable range: 0 ~ 65535, Default: 0.

Set the scrambling sequence n_{RNTI} for PDSCH data, used to distinguish different UEs.

4) n_{ID}

Configurable range: -1 ~ 65535;

Default: -1 (set to -1 to use CellID).

Set the nID for the PDSCH data scrambling sequence.

2. Resource Allocation

1) Symbol Start

Configurable range: 0 ~ 13, Default: 0.

Set the position of the first symbol for the current PDSCH.

2) Symbol Number

Configurable range: 0 ~ 14 (Normal) | 0 ~ 11 (Extended)

Default: 14 | 11.

Set the number of symbols available for the current PDSCH, with the maximum value related to the CP type.

3) Resource Allocation Type

Options: Type0 | Type1, Default: Type1.

Select the frequency domain resource allocation type for the current PDSCH, as detailed in the 3GPP protocol physical layer related content.

4) RB Offset

Configurable range: 0 ~ current BWP RB count - 1;

Default: 0.

Set the offset RB count relative to the start of the BWP when the current PUSCH is Type1.

Note: Only displayed when the Resource Allocation Type parameter in this section is Type1.

5) RB Number

Configurable range: 0 ~ current BWP RB count - RB Offset;

Default: maximum RB count.

Set the number of RBs when the current PUSCH is Type1.

Note: Only displayed when the Resource Allocation Type parameter in this section is Type1.

6) Allocated Slots

Set the Slot number for PDSCH transmission within a frame.

7) BWP

Use the dropdown list to select the BWP sequence number for the current CORESET, with specific options constrained by the number of BWPs.

8) VRB-to-PRB Mapping Type

Options: Interleaved | Non-Interleaved;

Default: Non-Interleaved.

Set the mapping method from VRB to PRB.

9) Bundle Size

Options: 2 | 4, Default: 2.

Set the Bundle size for interleaved mapping.

3. Code & Modulation

1) MCS Table

Options: QAM64 | QAM256 | QAM64Low SE | QAM1024;

Default: QAM64.

Select the table for calculating TB size, as detailed in the 3GPP protocol physical layer protocol.

2) MCS

Default: 0.

Set the corresponding MCS index, with the specific range related to the corresponding table in the 3GPP protocol.

3) Coding Rate

Display the coding rate, obtained according to the MCS Table parameter.

4) Transport Block Size

Display the channel transport block size, automatically changing with the MCS value.

5) xOverhead

Options: 0 | 6 | 12 | 18, Default: 0.

Set the high-level parameter xOverhead in the 3GPP protocol, used to set the parameter N_{oh}^{PRB} for calculating TBS.

6) TB Scaling Factor S

Options: 1 | 0.5 | 0.25, Default: 1.

Set the Scaling Factor S for calculating TBS, with specific values detailed in the 3GPP protocol TS38.214 Table 5.1.3.2-2.

7) Modulation

Display the modulation method, obtained according to the MCS Table parameter.

8) RV Index

Configurable range: 0 ~ 3, Default: 0.

Set the redundancy version RV index for rate matching.

4. DMRS

1) DMRS-r16

Options: On | Off, Default: Off.

Set whether to provide the high-level parameter *dmrsUplink-r16*.

2) n_SCID

Configurable range: 0 ~ 1, Default: 0.

Set the parameter n_{SCID} for sequence generation.

3) Scramble ID 0

Configurable range: -1 ~ 65535, Default: -1 (set to -1 to use CellID).

Set the N_{ID}^0 for DMRS sequence generation.

4) Scramble ID 1

Configurable range: -1 ~ 65535;

Default: -1 (set to -1 to use CellID).

Set the N_{ID}^1 for DMRS sequence generation.

5) PDSCH Mapping

Options: TypeA | TypeB, Default: TypeA.

Set the PDSCH mapping type.

6) PDSCH TypeA Position

Options: 2 | 3, Default: 2.

Set the high-level parameter dmrs-TypeA-Position in the 3GPP protocol.

7) DMRS Power Boosting

Configurable range: -40 dB ~ 40 dB;

Default: 0 dB.

Set the power of PDSCH DMRS relative to the PUSCH channel.

8) DMRS Configuration Type

Options: Type1 | Type2, Default: Type1.

Set the DMRS configuration type.

9) DMRS Length

Options: Single Symbol | Double Symbol,

Default: Single Symbol.

Set the symbol length for DMRS.

10) DMRS Additional Position

Options:

- Single symbol DMRS:
pos0 | pos1 | pos2 | pos3;
- DMRS Length is Double Symbol or Single symbol with intra-slot frequency hopping enabled:
pos0 | pos1.

Default: pos0.

Set the high-level parameter dmrs-AdditionalPosition in the 3GPP protocol.

11) DMRS Mapping Reference

Options: CRB | RRB;

Default: CRB.

Select the reference point for DMRS mapping.

5. PTRS

1) PTRS Enable

Options: On | Off, Default: On.

PTRS enable switch.

2) PTRS K (Frequency Density)

Options: 2 | 4, Default: 2.

Set the frequency domain density.

3) PTRS L (Time Density)

Options: 2 | 4, Default: 2.

Set the number of points per PT-RS group.

4) PTRS Power Boosting

Configurable range: -40 dB ~ 40 dB;

Default: 0 dB.

Set the power of PTRS data relative to PUSCH data.

5) PTRS RE Offset

Options: 00 | 01 | 10 | 11;

Default: 00.

Set the RE offset for PTRS.

6. Antenna Port

1) DMRS Port

Configurable range: 0 ~ 3, Default: 0.

Set the port number for DMRS.

2) Layers Number

Configurable range: 1 ~ 4;

Default: 1.

The number of layers for PDSCH, calculated based on the number of DMRS ports.

3) Antenna Port

Options: Port_0 | Port_1 | Port_2 | Port_3;

Default: Port_0.

Specify the data for each antenna, used to allocate PDSCH layers to antennas. The number of antenna ports is determined by the antenna data in the Waveform Setup.

4) DMRS CDM Groups w.o. Data

Configurable range: 1 ~ 3;

Default: 1.

Set the number of CDM groups for DMRS that do not allow mapping PDSCH data, with configuration Type1 having 2 CDM groups, setting range 1~2, and configuration type2 having 3 CDM groups, setting range 1~3.

7. Lmax

Options:

- CaseA / CaseB, CaseC: 4 | 8;
- CaseD / CaseE: 64.

Set the number of SS/PBCH blocks, with specific choices constrained by the SS/PBCH Block Pattern.

8. Periodicity

Options: 5ms | 10ms | 20ms | 40ms | 80ms | 160m,

Default: 10ms.

Set the synchronization broadcast period.

9. Active Indices

Set the active SS/PBCH blocks within a half-frame, with the maximum value constrained by L_{max} . For example, when the SS/PBCH block supports a maximum of 4, you can set the active indices to any one or more of 0~3.

10. Half Frame Index

Configurable range: 0 ~ 1 (0: first half-frame, 1: second half-frame),

Default: 0.

When the Periodicity parameter (SSB period) is not 5ms, this parameter is used to specify which half-frame the SSB is in.

11. SSB Power Boosting

Configurable range: -40dB~40dB;

Default: 0dB.

Set the relative power of the synchronization broadcast block, allowing for individual power settings for each active synchronization broadcast block.

12. RB Offset

Configurable range: -1 ~ maximum RB count for numerology - 1,

Default: -1.

Set the offset of the synchronization broadcast block (SSB) center relative to CRB0 (PointA).

13. PSS Power Boosting

Configurable range: -40 dB ~ 40 dB;

Default: 0 dB.

Set the power of PSS relative to SSS or PBCH, with SSS and PBCH power being the same.

14. kSSB

Configurable range: 0 ~ 23 (u=0 and u=1) | 0 ~11 (u=3 and u=4),

Default: 0.

Set the kSSB parameter size for SS/PBCH.


3.4.1.2.3 PDCCH

Currently, a maximum of 10 PDCCH settings are supported per carrier. Select the carrier through the **Component Carrier** parameter, and the PDCCH page displays the configuration of the current carrier, allowing for parameter configuration and modification. The number of PDCCHs is controlled by the following buttons:

Add PDCCH: Adds a PDCCH at the end of the list, with the default list containing 1 PDCCH.

Remove PDCCH: Removes the currently selected PDCCH.

Clear All: Keeps only the first PDCCH, removing all others.



1. General Settings

1) Enable

Options: On | Off, Default: On.

PDCCH channel enable switch.

2) Power Boosting

Configurable range: -40 dB ~ 40 dB. Default: 0 dB.

Set the relative power of PDCCH data.

3) DMRS Power Boosting

Configurable range: -40 dB ~ 40 dB.

Default: 0 dB.

Set the power of PDCCH DMRS relative to the PDCCH channel.

4) DMRS Scrambling ID

Configurable range: -1 ~ 65535;

Default: -1 (set to -1 to use CellID).

Set the nID for DMRS sequence generation.

5) RNTI

Configurable range: 0 ~ 65535;

Default: 0.

Set the scrambling RNTI for CRC.

6) Aggregation Level

Options: 1 | 2 | 4 | 8 | 16;

Default: 4.

Set the aggregation level for PDCCH, with the optional maximum aggregation level constrained by CORESET.

7) Candidate Index

Configurable range: 0 ~ number of PDCCH candidates - 1;

Default: 0.

Set the search space candidate index for the current PDCCH aggregation level.

8) CCE Offset

Display the CCE offset, indicating the starting position of the DCI.

Default: 0.

2. Search Space

1) BWP

Use the dropdown list to select the BWP sequence number for the current CORESET, with specific options constrained by the number of BWPs.

BWP and CORESET are interrelated.

2) Search Space Type

Options: UE Specific | Common,

Default: UE Specific.

Set the search space type for DCI.

3) Allocated Slots

Set the Slot number for PDCCH transmission within a frame.

4) Start Symbol Within Slot

Configurable range: 0 ~ 13, Default: 0.

Set the starting symbol position for the current PDCCH within a slot.

5) Number of Candidates

Options: 1 | 2 | 3 | 4 | 5 | 6 | 8, Default: 1.

Set the number of search space candidates used to calculate the CCE Offset.


3.4.1.2.4 CSI-RS

Currently, a maximum of 10 CSI-RS settings are supported per carrier. Select the carrier through the Component Carrier parameter, and the CSI-RS page displays the configuration of the current carrier, allowing for parameter configuration and modification. The number of CSI-RSs is controlled by the following buttons:

Add CSI-RS: Adds a CSI-RS at the end of the list, with the default list containing 1 CSI-RS.

Remove CSI-RS: Removes the currently selected CSI-RS.

Clear All: Keeps only the first CSI-RS, removing all others.



1. CSI-RS Enable

Options: On | Off, Default: On.

CSI-RS channel enable switch.

2. Power Boosting

Configurable range: -40 dB ~ 40 dB. Default: 0 dB.

Set the power of CSI-RS data relative to other channels.

3. n_ID

Configurable range: 0 ~ 65535, Default: 1000.

Set the parameter n_{ID} for generating the CSI-RS sequence.

4. Slot Allocation

Configurable range: 0 ~ $10 \cdot 2^{\mu}$, Default: 0.

Set the Slot number for CSI-RS transmission within a frame. It can be set in the following three ways:

- If you need to configure by individual slots, use "," as a separator, e.g., 0,1,2,3.
- If you need to configure by slot range, use 2:7 to indicate the start index and the last index, for

example, 2:7 represents 2,3,4,5,6,7.

- If you need to configure by different steps, use two ":" to indicate the starting slot, step, and the last slot, for example, 0:2:8 represents 0,2,4,6,8.

All three configuration methods can be combined.

5. Starting RB

Configurable range: 0 ~ current BWP RB count + BWP RB start number - 4, Default: 0.

Set the offset RB number for the current CSI-RS relative to the start of the BWP.

Note: The set RB number must be a multiple of 4.

6. RB Number

Configurable range: 4 ~ current BWP RB count - RB Offset, Default: maximum RB count.

Set the number of RBs for the current CSI-RS.

Note: The set RB number must be a multiple of 4.

7. Frequency Domain Bitmap

Setting content: One bit represents one RBG, checking indicates activation.

Set the frequency domain position of CSI-RS via bitmap, with the number of bits constrained by the CSI-RS Locations Table Index.

Note: When the CSI-RS Locations Table Index is 1, 4 bits can be set; when it is 2, 12 bits can be set; when it is 4, 3 bits can be set; for other values, 6 bits can be set.

8. Density

Options: 1 | 0.5, Default: 1.

Set the density of CSI-RS, constrained by the location table, as detailed in 3GPP protocol 38.211 Table 7.4.1.5.3-1.

Note: When the CSI-RS Locations Table Index is set to 1, Density = 3; when set to 4 ~ 10, Density=1; in these cases, this parameter is hidden. When the CSI-RS Locations Table Index is set to other values, Density=1 | 0.5, and this parameter is only displayed at this time.

9. Antenna Port

Options: Port_0 | Port_1 | Port_2 | Port_3, Default: Port_0.

Set the mapping of CSI-RS ports to antenna ports.

10. CSI-RS Type

Display the CDM type of CSI-RS.

11. BWP

Select the BWP for the current CSI-RS transmission.

12. Locations Table Index

Configurable range: 1 ~ 18, Default: 1.

Set the row index of the CSI-RS location table, as detailed in 3GPP protocol 38211 Table 7.4.1.5.3-1.

13. First Symbol(I0)

Configurable range: 0 ~ 13, Default: 10.

Set the I0 of the CSI-RS location table, as detailed in 3GPP protocol 38.211 Table 7.4.1.5.3-1.

14. RE Used for PDSCH

Options: On | Off, Default: Off.

Set whether the resources configured for CSI-RS can be used for PDSCH. Setting to On means PDSCH will be mapped to CSI-RS resources, and CSI-RS will cover PDSCH. Setting to Off means PDSCH mapping will skip CSI-RS resources.

3.4.1.3 Channel (Uplink)


3.4.1.3.1 PUCCH

Currently, a maximum of 10 PUCCH settings are supported per carrier. Select the carrier through the **Component Carrier** parameter, and the PUCCH page displays the configuration of the current carrier, allowing for parameter configuration and modification. The number of PUCCHs is controlled by the following buttons:

Add PUCCH: Adds a PUCCH at the end of the list, with the default list containing 1 PUCCH.

Remove PUCCH: Removes the currently selected PUCCH.

Clear All: Keeps only the first PUCCH, removing all others.



1. General Settings

1) PUCCH 1 Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUCCH channel.

2) Format

Options: Format 0 | Format 1 | Format 2 | Format 3 | Format 4,

Default: Format 0.

Select the format of the current PUCCH.

3) Power Boosting

Configurable range: -40 dB ~ 40 dB. Default: 0 dB.

Set the power of PUCCH data relative to other channels.

4) mcs

Options: 0 | 1 | 3 | 4 | 6 | 7 | 9 | 10, Default: 0.

This parameter is used for format 0 sequence generation, as a specific cyclic shift for HATRQ-ACK, with values related to bit information.

Note: Only displayed when PUCCH Format is format 0.

5) Scrambling ID0

Configurable range: -1 ~ 1023;

Default: -1 (set to -1 to use CellID).

Set the scrambling ID for scrambling sequence generation.

Note: Only displayed when PUCCH Format is format 2 | 3 | 4.

6) DMRS Power Boosting

Configurable range: -40 dB ~ 40 dB.

Default: 0 dB.

Set the power of DMRS relative to PUSCH.

7) Additional DMRS

Options: On | Off, Default: Off.

Enable or disable additional DMRS.

Note: Only displayed when PUCCH Format is format 3 | 4.

8) DMRS-UplinkTransformPrecoding-r16

Options: On | Off, Default: Off.

Set whether to provide the high-level parameter dmrsUplink-r16.

2. Resource Allocation

1) Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUCCH channel.

2) First Symbol

Configurable range: 0 ~ 13, Default: Determined by the PUCCH format.

Set the position of the first symbol for the current PUCCH.

3) Allocated Slots

Configurable range: 0 ~ $10 \cdot 2^\mu$, Default: 0.

Set the Slot number for PUCCH transmission within a frame. It can be set in the following three ways:

- If you need to configure by individual slots, use "," as a separator, e.g., 0,1,2,3.
- If you need to configure by slot range, use 2:7 to indicate the start index and the last index, for example, 2:7 represents 2,3,4,5,6,7.
- If you need to configure by different steps, use two ":" to indicate the starting slot, step, and the last slot, for example, 0:2:8 represents 0,2,4,6,8.

All three configuration methods can be combined.

4) Symbol Number

Set the number of symbols available for the current PUCCH, with the configurable range determined by the PUCCH format, as detailed in Table 3-6.

Table 3-6 PUCCH format and symbol constraints

PUCCH Format	Number of symbols
0	1 - 2
1	4 - 14
2	1 - 2
3	4 - 14
4	4 - 14

5) BWP

Options: BWP 0 ~ current total number of BWPs;

Default: BWP 0.

Switch the BWP for the current PUCCH transmission, you can select one from the currently existing BWPs for configuration.

6) Use Interlace PUCCH

Options: On | Off;

Default: On.

Enable switch for interlace transmission, which is only supported for subcarrier spacings of 15kHz and 30kHz, and conflicts with frequency hopping.

Note: When interlace transmission is On, the parameters **RB Offset** and **RB Number** will be hidden, and the parameters **RB-Set Index**, **Interlace0**, and **Interlace1** will be displayed.

7) RB Offset

Configurable range: 0 ~ current BWP RB count - 1;

Default: 0.

Set the offset RB number for the current PUCCH relative to the start of the BWP.

8) RB Number

Configurable range: Specific constraints are detailed in Table 3-7.

Set the number of RBs for the current PUCCH.

Table 3-7 PUCCH format and RB number constraints

PUCCH format	RB Number
0	1
1	1
2	1 - 16
3	1 - 16 (excluding 7, 11, 13, 14)
4	1

9) RB-Set Index

Configurable range determined by carrier settings;

Default: 0.

Set the RB set index used for the current PUCCH transmission.

10) PUCCH Interlace 0

Configurable range: -1 ~ 9 (u = 0) | 0 ~ 4 (u = 1);

Default: 0.

Set the parameter Interlace0 for the current PUCCH, as detailed in the 3GPP physical layer protocol (TS38.211).

Note: Only displayed when the parameter **Use Interlace PUCCH** is On.

11) PUCCH Interlace1

Configurable range: -1 ~ 9 (u = 0) | -1 ~ 4 (u = 1), Default: -1 (i.e., no configuration).

Set the parameter Interlace1 for the current PUCCH, as detailed in the 3GPP physical layer protocol (TS38.211).

Note: Only displayed when the parameter Use Interlace PUCCH is On and PUCCH Format is format 2 | 3.

12) Interlace 0

Options: 10 | 11 | not configured, Default: 10.

Set the number of RBs after interlace for the current PUCCH, with not configured indicating no limit on the number of RBs, distributed across the entire bandwidth.

Note: Only displayed when the parameter Use Interlace PUCCH is On.

13) Interlace 1

Options: 10 | 11 | not configured, Default: 10.

Set the number of RBs after interlace for the current PUCCH, with not configured indicating no limit on the number of RBs, distributed across the entire bandwidth.

Note: Only displayed when the parameter Use Interlace PUCCH is On and PUCCH Format is format 2 | 3.

3. PUCCH Settings

1) PUCCH 1 Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUCCH channel.

2) Hopping ID

Configurable range: -1 ~ 1023;

Default: -1 (set to -1 to use CellID).

Set the hopping ID for the current PUCCH when the format is 0 | 1 | 3 | 4.

Note: Only displayed when PUCCH Format is format 0 | 1 | 3 | 4.

3) Format

Options: Format 0 | Format 1 | Format 2 | Format 3 | Format 4;

Default: Format 0.

Select the format of the current PUCCH.

4) PUCCH-Group Hopping

Options: Neither | Enable | Disable;

Default: Neither.

Set the high-level parameter `pucch-GroupHopping` for PUCCH when the format is 0 | 1 | 3 | 4, as detailed in the 3GPP protocol.

Note: Only displayed when PUCCH Format is format 0 | 1 | 3 | 4.

5) Initial Cyclic Shift

Configurable range: 0 ~ 11;

Default: 0.

When the current PUCCH is format 0 | 1, set the initial cyclic shift (`m0`) of its sequence.

Note: Only displayed when PUCCH Format is format 0 | 1.

6) Intra-slot Frequency Hopping

Options: On | Off, Default: Off.

Enable or disable intra-slot frequency hopping. Only PUCCH format 1 is supported.

Note: Only displayed when PUCCH Format is format 1.

7) Inter-slot Frequency Hopping

When the number of slots is greater than 1, i.e., the number of slots configured by the parameter `Allocated Slots` is greater than 1, enable or disable inter-slot frequency hopping. Only PUCCH format 1 is supported.

Note: Only displayed when PUCCH Format is format 1.

8) Scrambling ID

Configurable range: -1 ~ 1023;

Default: -1 (set to -1 to use CellID).

Set the scrambling ID for scrambling sequence generation.

Note: Only displayed when PUCCH Format is format 2 | 3 | 4.

9) nRNTI

Configurable range: 0 ~ 65535;

Default: 0.

Set the n_RNTI parameter for scrambling sequence generation.

Note: Only displayed when PUCCH Format is format 2 | 3 | 4.

10) OCC Index

Set the index value of the spreading sequence, corresponding to the parameter TimeDomainOCC for PUCCH format 1 in the 3GPP protocol, and the parameter occ-Index for PUCCH formats 2 | 3 | 4.

Note: Only displayed when PUCCH Format is format 1 | 2 | 3 | 4.

11) OCC Length

Configurable range:

- format 2/3: 1 | 2 | 4;
- format 4: 2 | 4.

Default: 1.

Set the length of the spreading sequence (OCC) for formats 2/3/4, corresponding to the parameter occ-Length in the 3GPP protocol.

Note: Only displayed when PUCCH Format is format 2 | 3 | 4.

12) N PUCCH Repeat

Configurable range: 1 ~ Min (configured number of slots, 8);

Default: 1.

Set the number of slots for PUCCH transmission repetition.

Note: Only displayed when PUCCH Format is format 1 | 3 | 4.

13) $\pi/2$ BPSK

Options: On | Off;

Default: Off.

Enable or disable $\pi/2$ BPSK modulation.

Note: Only displayed when PUCCH Format is format 3 | 4.


3.4.1.3.2 PUSCH

Currently, a maximum of 20 PUSCH settings are supported per carrier. Select the carrier through the **Component Carrier** parameter, and the PUSCH page displays the configuration of the current carrier, allowing for parameter configuration and modification. The number of PUSCHs is controlled by the following buttons:

Add PUSCH: Adds a PUSCH at the end of the list, with the default list containing 1 PUSCH.

Remove PUSCH: Removes the currently selected PUSCH.

Clear All: Keeps only the first PUSCH, removing all others.



1. General Settings

1) PUSCH1Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUSCH channel.

2) Power Boosting

Configurable range: -40 dB ~ 40 dB;

Default: 0 dB.

Set the power of PUSCH data relative to other channels.

3) Transform Precoding

Options: On | Off, Default: Off.

Enable or disable transform precoding.

4) RNTI

Configurable range: 0 ~ 65535, Default: 0.

Set the n_RNTI for PUSCH data scrambling sequence, used to distinguish different UEs.

5) n_ID

Configurable range: -1 ~ 1023;

Default: -1 (set to -1 to use CellID);

Set the n_ID for PUSCH data scrambling sequence.

6) n_RAPID

Configurable range: -1 ~ 63;

Default: -1 (i.e., no configuration).

Set the n_RAPID for PUSCH data scrambling sequence.

2. Resource Allocation

1) PUSCH1Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUSCH channel.

2) Symbol Start

Configurable range: 0 ~ 13, Default: 0.

Set the position of the first symbol for the current PUSCH.

3) Allocated Slots

Configurable range: 0 ~ $10 \cdot 2^\mu$, Default: 0.

Set the Slot number for PUSCH transmission within a frame. It can be set in the following three ways:

- If you need to configure by individual slots, use "," as a separator, e.g., 0,1,2,3.
- If you need to configure by slot range, use 2:7 to indicate the start index and the last index, for

example, 2:7 represents 2,3,4,5,6,7.

- If you need to configure by different steps, use two ":" to indicate the starting slot, step, and the last slot, for example, 0:2:8 represents 0,2,4,6,8.

All three configuration methods can be combined.

4) Symbol Number

Configurable range: 0 ~ 13, Default: 0.

Set the position of the first symbol for the current PUSCH.

5) BWP

Options: BWP 0 ~ current total number of BWPs;

Default: BWP 0.

Switch the BWP for the current PUCCH transmission, you can select one from the currently existing BWPs for configuration.

6) Resource Allocation Type

Options: Type0 | Type1 | Type2, Default: Type1.

Select the frequency domain resource allocation type, as detailed in the 3GPP protocol physical layer related content.

7) RB Offset

Configurable range: 0 ~ current BWP RB count - 1, Default: 0.

Set the offset RB number for the current PUSCH relative to the start of the BWP when the type is Type1.

Note: Only displayed when Resource Allocation Type is Type1.

8) RB Number

Configurable range: 0 ~ current BWP RB count - RB Offset;

Default: maximum RB count.

Set the number of RBs for the current PUSCH when the type is Type1.

Note: Only displayed when Resource Allocation Type is Type1.

9) RBG Size

Configurable range: Select the RBG range based on the resource size of the BWP, with specific constraints detailed in Table 3-8, Default: 16.

Set the size of the RBG.

Table 3-8 BWP and RBG constraints

Bandwidth Part Size	RBG configuration 1	RBG configuration 2
1 - 36	2	4
37 - 72	4	8
73 - 144	8	16
145 - 275	16	16

10) RBG Bitmap

Setting content: One bit represents one RBG, setting 1 indicates activation.

Set the frequency domain position of the RBG, with the number of bits calculated based on the RBG size and BWP.

Note: Only displayed when the parameter Resource Allocation Type is Type0.

11) Frequency Hopping Mode

Options: Disable | Intra-slot Frequency hopping | Inter-slot Frequency hopping;

Default: Disable.

Select to disable or enable different frequency hopping modes.

Note: Only displayed when the parameter **Resource Allocation Type** is Type0.

12) Frequency Hops RB Offset

Configurable range: 0 ~ current BWP RB count - RB Number - RB Offset;

Default: 0.

When the parameter **Hopping Mode** is enabled, set the RB offset parameter for calculating the RB start of each second hop.

Note: Only displayed when the parameter **Hopping Mode** is not Disable.

3. Code & Modulation

1) MCS Table

When transform precoding is not enabled:

Options: QAM64 | QAM256 | QAM64Low SE | QAM1024.

When transform precoding is enabled:

Options: QAM64 | QAM256 | QAM64Low SE | QAM1024.

Default: QAM64.

Select the table for calculating TB size, as detailed in the 3GPP protocol physical layer protocol.

2) MCS

Default: 0.

Set the corresponding MCS index, with the specific range related to the corresponding table in the 3GPP protocol.

3) xOverhead

Options: 0 | 6 | 12 | 18, Default: 0.

Set the high-level parameter xOverhead in the 3GPP protocol, used to set the parameter N_{oh}^{PRB} for calculating TBS.

4) Coding Rate

Display the coding rate, obtained according to the MCS Table parameter.

5) Modulation

Display the modulation method, obtained according to the MCS Table parameter.

6) Transport Block Size

Display the TB Size, obtained according to the MCS Table parameter.

7) RV Index

Configurable range: 0 ~ 3, Default: 0.

Set the redundancy version RV index for rate matching.

8) LBRM

Options: On | Off, Default: Off.

Set the LBRM parameter for the encoding process.

4. DMRS

1) PUSCH1 Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUSCH channel.

2) DMRS-r16

Options: On | Off, Default: Off.

Set whether to provide the high-level parameter dmrsUplink-r16.

3) n_SCID

Configurable range: 0 ~ 1, Default: 0.

Set the parameter n_{SCID} for sequence generation.

4) Scrambling ID0

Configurable range: -1 ~ 65535;

Default: -1 (set to -1 to use CellID).

Set the N_{ID}^0 for DMRS sequence generation.

5) Scrambling ID1

Configurable range: -1 ~ 65535;

Default: -1 (set to -1 to use CellID).

Set the N_{ID}^1 for DMRS sequence generation.

6) PUSCH Mapping

Options: TypeA | TypeB, Default: TypeA.

Set the PUSCH mapping type.

7) Group Hopping

Options: On | Off, Default: Off.

Toggle the enable state of PUSCH DMRS group hopping.

8) Sequence Hopping

Options: On | Off, Default: Off.

Toggle the enable state of PUSCH DMRS sequence hopping.

9) n_{ID}^{RS}

Configurable range: -1 ~ 65535;

Default: -1 (set to -1 to use CellID).

Set the n_{ID}^{RS} for DMRS generation.

10) DMRS Power Boosting

Configurable range: -40 dB ~ 40 dB, Default: 0 dB.

Set the power of PUSCH DMRS relative to the PUSCH channel.

11) DMRS Configuration Type

Options: Type1 | Type2, Default: Type1.

Set the DMRS configuration type.

12) DMRS Length

Options: Single Symbol | Double Symbol;

Default: Single Symbol.

Set the symbol length for DMRS.

13) DMRS Additional Position

Options:

- Single symbol DMRS:
pos0 | pos1 | pos2 | pos3;
- DMRS Length is Double Symbol or Single symbol with intra-slot frequency hopping enabled:
pos0 | pos1.

Set the high-level parameter dmrs-AdditionalPosition in the 3GPP protocol.

14) PUSCH TypeA Position

Options: 2 | 3, Default: 2.

Set the high-level parameter dmrs-TypeA-Position in the 3GPP protocol.

5. PTRS

1) PUSCH1Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the current PUSCH channel.

2) PTRS Enabled

Options: On | Off, Default: Off.

Toggle the enable state of the PTRS channel.

3) PTRS Power Boosting

Configurable range: -40 dB ~ 40 dB, Default: 0 dB.

Set the power of PTRS data relative to PUSCH data.

4) PTRSK (Frequency Density)

Options: 2 | 4, Default: 2.

Set the time domain density of PTRS, as detailed in the 3GPP protocol physical layer protocol.

5) PTRS RE Offset

Options: 00 | 01 | 10 | 11, Default: 00.

Set the RE offset for PTRS.

6) PTRSL (Time Density)

Options: 1 | 2 | 4, Default: 1.

Set the frequency domain density of PTRS, as detailed in the 3GPP protocol physical layer protocol.

7) n PTRS Group

Options: 2 | 4 | 8, Default: 2.

Set the number of groups for each PT-RS group.

8) n PTRS Group Sample

Options: 2 | 4, Default: 2.

Set the number of groups for each PT-RS group.

9) n PTRS ID

Configurable range: 0 ~ 65535, Default: 0.

Set the initialization parameter N_ID for PTRS sequence generation.

6. Antenna Port**1) PUSCH1Enabled**

Options: On | Off, Default: Off.

Toggle the enable state of the current PUSCH channel.

2) DMRS Port

Configurable range: 0 ~ 4, Default: 0.

Set the port number for DMRS, which can be set to one or multiple values. Setting multiple values indicates multiple layers for PUSCH, with a maximum of 4 layers supported. Specific constraints are detailed in Table 3-9.

Table 3-9 Antenna port and DM-RS duration constraints

DM-RS duration	l'	Supported antenna ports \tilde{p}	
		Configuration type 1	Configuration type 2
single-symbol DM-RS	0	0 - 3	0 - 5
double-symbol DM-RS	0, 1	0 - 7	0 - 11

3) Antenna Port

Options: 0~Layers Number - 1, Default: port 0.

Select the DMRS port, constrained by Layers Number.

4) Layers Number

Display the current number of layers, calculated based on the number of DMRS Ports.

5) DMRS CDM Groups w.o. Data

Configurable range: 1~3, Default: 1.

Set the number of CDM groups for DMRS that do not allow mapping PUSCH data, with configuration Type1 having 2 CDM groups with a setting range of 1~2, and configuration type2 having 3 CDM groups.

6) PTRS Port

Configurable range: 0~5, Default: DMRS Port.

Set the port number for PTRS, which can be set to one or multiple values. The set values must be included within DMRS Port. If DMRS port does not include a port number that supports PTRS port, PTRS cannot be enabled.

7) Codebook Enable

Options: On | Off, Default: Off.

Enable or disable codebook transmission.

8) TPMI Index


Configurable range:

- Single layer single antenna: 0;
- Single layer 2 antennas: 0 ~ 5;
- Single layer 4 antennas: 0 ~ 27;
- 2 layers 2 antennas: 0 ~ 2;
- 2 layers 4 antennas: 0 ~ 21;
- layers 4 antennas: 0 ~ 6;
- layers 4 antennas: 0 ~ 4.

Default: 0.

When the parameter Codebook is On, set the corresponding coding matrix index based on the number of layers and antenna ports.

3.4.1.4 Meas Time



1. Search Length

Configurable range: 0 ~ 100 s, Default: 22 ms.

Unit options: ns | s | μ s | s, Default: ms.

Set the length of the collected data, which will be used for synchronization search. This length determines the data that can be demodulated.

2. Analysis Boundary

Options: Frame | SubFrame | Slot, Default: Frame.

Select the boundary to align after successful synchronization.

1) Frame

After successful synchronization, adjust the measurement data to the frame header position. This option requires the search length to exceed 2 frames to obtain a complete frame of measurement data.

2) SubFrame

After successful synchronization, adjust the measurement data to the nearest subframe boundary. In this case, at least one frame of search length is required for correct synchronization and demodulation. If the search data is less than one frame, synchronization may not always succeed, but demodulation is possible after successful synchronization.

3) Slot

After successful synchronization, adjust the measurement data to the nearest slot boundary. In this case, at least one frame of search length is required for correct synchronization and demodulation. If the search data is less than one frame, synchronization may not always succeed, but demodulation is

possible after successful synchronization.

3. Analysis Subframe

Configurable range: 0 ~ 10, Default: 10.

Set the number of subframes used for frequency offset estimation in demodulation.

4. Analysis Slot

Configurable range: 0 ~ 1, Default: 0.

Set the number of slots used for frequency offset estimation in demodulation. The current analysis length is the sum of **Analysis Subframe** and **Analysis Slot**. This parameter is constrained by Analysis Subframe. If Analysis Subframe is configured as 10, this parameter can only be set to 0.

5. Meas Interval Subframe

Configurable range: 0 ~ current **Analysis Subframe** value, Default: 10.

Set the average subframe interval of the current analysis data, used to calculate demodulation parameters. This parameter, together with **Meas Interval Slot** and **Meas Interval Symbol**, determines which part of the data's demodulation results are analyzed.

Note: The measurement length is the sum of **Meas Interval Subframe**, **Meas Interval Slot**, and **Meas Interval Symbol**. The constraints of these three parameters comply with the 3GPP protocol, and automatic carry-over occurs if conditions are met.

6. Meas Interval Slot

Configurable range: 0 ~ 1, Default: 0.

Set the slot interval of the current analysis data, used to calculate demodulation parameters. This parameter, together with **Meas Interval Subframe** and **Meas Interval Symbol**, determines which part of the data's demodulation results are analyzed.

Note: The measurement length is the sum of **Meas Interval Subframe**, **Meas Interval Slot**, and **Meas Interval Symbol**. The constraints of these three parameters comply with the 3GPP protocol, and automatic carry-over occurs if conditions are met.

7. Meas Interval Symbol

Configurable range: 0 ~ 13, Default: 0.

Set the symbol interval of the current analysis data, used to calculate demodulation parameters. This parameter, together with **Meas Interval Slot** and **Meas Interval Subframe**, determines which part of

the data's demodulation results are analyzed.

Note: The measurement length is the sum of **Meas Interval Subframe**, **Meas Interval Slot**, and **Meas Interval Symbol**. The constraints of these three parameters comply with the 3GPP protocol. When this parameter is set to 14, it automatically carries over to Meas Interval Slot.

8. Meas Offset Subframe

Configurable range: 0 ~ current Analysis Subframe value, Default: 10.

Set the offset length from the measurement boundary, used to calculate demodulation parameters. This parameter, together with **Meas Offset Slot** and **Meas Offset Symbol**, determines the starting position of the analyzed measurement data.

Note: The offset length is the sum of **Meas Offset Subframe**, **Meas Offset Slot**, and **Meas Offset Symbol**. The sum of the offset length and the measurement length cannot exceed the sum of **Analysis Subframe** and **Analysis Slot**. The constraints of these parameters comply with the 3GPP protocol, and automatic carry-over occurs if conditions are met.

9. Meas Offset Slot

Configurable range: 0 ~ current Analysis Subframe value, Default: 10.

Set the offset length from the measurement boundary, used to calculate demodulation parameters. This parameter, together with **Meas Offset Subframe** and **Meas Offset Symbol**, determines the starting position of the analyzed measurement data.

Note: The offset length is the sum of **Meas Offset Subframe**, **Meas Offset Slot**, and **Meas Offset Symbol**. The sum of the offset length and the measurement length cannot exceed the sum of **Analysis Subframe** and **Analysis Slot**. The constraints of these parameters comply with the 3GPP protocol, and automatic carry-over occurs if conditions are met.

10. Meas Offset Symbol

Configurable range: 0 ~ current **Analysis Subframe** value, Default: 10.

Set the offset length from the measurement boundary, used to calculate demodulation parameters. This parameter, together with **Meas Offset Slot** and **Meas Offset Subframe**, determines the starting position of the analyzed measurement data.

Note: The offset length is the sum of **Meas Offset Subframe**, **Meas Offset Slot**, and **Meas Offset Symbol**. The sum of the offset length and the measurement length cannot exceed the sum of **Analysis Subframe** and **Analysis Slot**. The constraints of these parameters comply with the 3GPP protocol, and automatic carry-over occurs if conditions are met.

3.4.1.5 Advanced

1. General

1) Sync Mode

Options: CP Correlation | Time Cross Correlation, Default: CP Correlation.

Select the synchronization type required for demodulation.

2) Sync Signal

Options: Auto | SSB | PDSCH DMRS | PDCCH DMRS | CSI-RS,

Default: Auto.

Select the synchronization signal required for demodulation.

3) Multicarrier Filten

Options: On | Off, Default: Off.

When multiple carriers are present in the current signal, a filter can be used to remove other carriers.

4) DC Punctured

Options: On | Off, Default: Off.

Toggle the state of DC participation in demodulation.

5) Report EVM in dB

Options: On | Off, Default: Off.

Toggle the unit display of the current EVM. When Off is selected, %rms is displayed by default. When On is selected, dB is displayed.

6) Symb Clock Err Compensation

Options: On | Off, Default: Off.

When enabled, the data before demodulation will first undergo Clock error compensation.

2. Window

1) Symbol Time Adjust

Options: Win Start | Win Center | Win End | %FFT size;

Default: Win End.

Select the windowing type.

2) %FFT Size

Configurable range: -25% ~ 0;

Default: -1.76 %.

Set the percentage relative to the FFT Size.

3. 3GPP Conformance Test

Options: On | Off;

Default: On.

Toggle the 3GPP measurement switch. When On is selected, 3GPP settings will be used for EVM calculation. When Off is selected, Equalizer and Tracking related parameters can be configured.

4. Equalizer

1) Equalizer Type

Options: Off | RS | RS+Data;

Default: RS.

Set the equalization type.

2) Time Averaging Type

Time domain averaging type: Slot | SubFrame | Frame | Measure Length, Default: Slot.

Set the length of averaging in the time domain.

3) Frequency Moving Length

Setting value: 0~65535, Default: 19.

Set the length of frequency domain smoothing.

5. Tracking

1) Tracking Mode

Options: Off | RS | RS+Data, Default: RS.

Set the tracking mode.

2) Track Amplitude

Options: On | Off, Default: Off.

Choose whether to use reference signals for amplitude correction.

3) Track Phase

Options: On | Off, Default: Off.

Choose whether to use reference signals for phase correction.


4) Track Timing

Options: On | Off, Default: Off.

Choose whether to use reference signals for timing offset correction.

3.4.2 Measurement Result

The 5G NR measurement result settings path is: **Trace** -> **Format**.



Setup steps:

- 1) Select the display window;
- 2) Select Group, different measurement results are placed in different groups;
- 3) Select the measurement result data to be displayed.

Measurement result example (Uplink):



Measurement result example (Downlink):



1. Raw Main Time

Display the modulus of the raw data input from hardware or read from a playback file, with time on the x-axis and amplitude on the y-axis.

2. Spectrum

Display the spectrum of the raw data input from hardware or read from a playback file, with frequency on the x-axis and amplitude on the y-axis.

3. IQ Meas Time

IQ measurement time displays the constellation diagram of the data within the measurement length, with amplitude (normalized amplitude) on both the x-axis and y-axis. Different channels are distinguished by different colors.

4. RMS Error Vector Spectrum

RMS error vector spectrum displays the root mean square (RMS) EVM of each subcarrier, with RMS calculation of EVM for all symbols within the measurement range on each subcarrier. The x-axis shows the subcarrier range within the entire channel bandwidth, in units of subcarrier|ksubcarrier; the y-axis shows RMS EVM, in units of %.

5. Error Vector Time

Error vector time domain displays the EVM at the subcarrier level, with time on the x-axis and EVM values on the y-axis. Each trace represents the EVM of each symbol on a subcarrier within the measurement range, and all subcarrier traces overlap.

6. Error Vector Spectrum

Error vector frequency domain displays the EVM at the subcarrier level, with subcarriers on the x-axis and EVM values on the y-axis. Each trace represents the EVM of each subcarrier on a symbol, and all symbol traces within the measurement range overlap.

7. RE Allocation

Display the resource allocation of each channel within the measurement range, equivalent to a resource grid view, with symbols on the x-axis and subcarriers on the y-axis. Different channels are distinguished by different colors.

8. Error Summary

Error summary displays the following error items of the measurement data:

Channel Power: Display the average power of the carrier;

EVM (RMS/Peak): Display the RMS EVM and peak EVM of all measured channels;

Freq Error: Frequency offset relative to the carrier center;

Clock Error: Clock deviation between the measured signal and the reference signal, in ppm; this parameter may not be displayed if the number of RBs of the signal is too small to calculate.

Time Offset: Display the time deviation from the start position of the collected data to the start position of the measurement interval (Meas Interval);

Sync Correlation: Display the correlation between the measured synchronization signal and the ideal reference synchronization signal;

Magnitude Error: Display the amplitude error between the measured signal and the reference signal;

Phase Error: Display the phase error between the measured signal and the reference signal.

9. Frame Summary

Frame summary parameters are calculated from the measurement data within the measurement length range, including the following parameters of the measurement data:

Channel: Display the name of the currently enabled channel;

- Uplink: PUCCH | PUSCH | PTRS | PUCCH_DMRS | PUSCH_DMRS;
- Downlink: PDCCH | PDSCH | PTRS | PDCCH-DMRS | PDSCH-DMRS | SSB
P-SS | S-SS | PBCH | PBCH-DMRS | CSI-RS

EVM (%rms): Display the RMS EVM of the current channel;

Power Per RE (dBm): Display the power of each subcarrier of the current channel, averaged over all subcarriers of the current channel;

Modulation: The modulation scheme of the current channel, if there is no modulation scheme, it will not be displayed;


Num.RB: Display the total number of RBs occupied by the current channel. PUCCH | PUSCH | PDCCH | PDSCH and their corresponding reference signals calculate the number of RBs together.

3.5 LTE

LTE demodulation is compatible with the LTE standard: 3GPP TS36 V17.3.0.


3.5.1 Configuration

The path to access LTE settings is: **Meas Setup** -> **4G LTE Properties**.



3.5.1.1 Config Carrier

Currently, only single-carrier is supported.



1. Direction

Options: Downlink | Uplink, Default: Downlink.

Toggles the carrier state and related configurations.

2. Duplex Mode

Options: TDD | FDD, Default: FDD.

Toggles the carrier duplex type and related configurations.

3. BandWidth

Options: 1.4MHz | 3MHz | 5MHz | 10MHz | 15MHz | 20MHz, Default: 10MHz.

Toggles the carrier bandwidth.

4. Mirror Freq Spectrum

Options: On | Off, Default: Off.

Enables or disables mirror frequency spectrum.

5. TDD Config (TDD)

Options: Config 0 ~ 6,

Default: Config 0.

Sets the TDD configuration option.

TDD Config	Uplink/Downlink Subframe Allocation
0	D.S.U.U.U.D.S.U.U.U
1	D.S.U.U.D.D.S.U.U.D
2	D.S.U.D.D.D.S.U.D.D
3	D.S.U.U.U.D.D.D.D.D
4	D.S.U.U.D.D.D.D.D.D
5	D.S.U.D.D.D.D.D.D.D
6	D.S.U.U.U.D.S.U.U.D

Where: D = Downlink subframe, U = Uplink subframe, S = Special subframe.

6. Special Subframe Config (TDD)

Options:

- Config 0 ~ 10 (normal CP),

- Config 0 ~ 7 (extended CP).

Default: Config 0.

Sets the DwPTS/UpPTS configuration option for special subframes. For more information, refer to 3GPP TS 36.211 Table 4.2-1.

7. Sync Type

Options: PSS | CRS, Default: PSS.

Toggles the synchronization method.

8. Sync Slot

Options: 0 ~ 19, Default: 0.

Configures the slot number used for CRS synchronization.

9. Cell ID Auto

Options: Auto | Manual, Default: Manual.

Sets the method for obtaining the Cell ID.

10. Cell ID

Configurable range: 0 ~ 503.

Sets the value of the Cell ID.

11. CRS Port Num

Options: 1 | 2 | 4, Default: 1.

Sets the number of CRS ports.

12. CRS Ref

Options: 0 ~ CRS Port Num - 1, Default: 0.

Selects the CRS reference port.

13. CP Length

Options: Auto | Normal | Extended, Default: Auto.

Selects the CP length type, where Auto automatically detects the CP type.

14. Test Mode

Options:

- TEST_MODE_OFF | TM_1_1 | TM_1_2 |
- TM_2 | TM_2_A | TM_2_B |
- TM_3_1 | TM_3_1_A | TM_3_1_B |
- TM_3_2

Default: TEST_MODE_OFF.

Toggles the test mode.

3.5.1.2 Channel (Downlink)

1. Power Boost


Configurable range: -20dB ~ 20dB, Default: 0dB.

Sets the power of the corresponding channel.

2. Auto Detect

Options: On | Off, Default: On.

Enables or disables automatic search for control channel power. When disabled, you can configure the power of the channel by clicking the power window of the corresponding channel under Power Boost.




3. PA Enable

Options: On | Off, Default: On.

Toggles the enable state of the data channel PA.

4. PDCCH



1) Power Boost


Configurable range: -20dB ~ 20dB, Default: 0dB.

Sets the power of PDCCH.

2) Auto Detect

Options: On | Off, Default: On.

Enables or disables automatic search for the number of symbols occupied by PDCCH in each subframe. When disabled, you can configure the number of symbols occupied by PDCCH by clicking the Symbol item under the corresponding subframe number.




3) Symbol

Configurable range: 1 ~ 3, Default: 1.

Sets the number of symbols occupied by PDCCH in each subframe.

5. PDSCH



1) Auto Detect

Options: On | Off, Default: On.

Enables or disables automatic search for PDSCH modulation type and power.

2) Precoding

Options: Off | Sp.Mux | Tx.Div, Default: Off.

Sets the precoding type for PDSCH data.

3) Include

Options: On | Off,

Default:

- On (QPSK/16QAM/64QAM),
- Off (256QAM/1024QAM).

Sets the modulation types included during PDSCH auto-detection.

4) Add

Used to manually add a new PDSCH channel, with a maximum of 5 PDSCH channels supported. Click the corresponding **User** in the table to configure this PDSCH channel in detail below.

The screenshot shows the PDSCH configuration window. At the top, there are tabs for PDCCH, PDSCH, and PHICH. The PDSCH tab is active. Below the tabs, there are two dropdown menus: 'Auto Detect' set to 'On' and 'Precoding' set to 'Off'. Underneath, there is an 'Include' section with a list of modulation types: QPSK, 16QAM, 64QAM, 256QAM, and 1024QAM. Each type has a checkbox: QPSK, 16QAM, and 64QAM are checked, while 256QAM and 1024QAM are unchecked. Below the list are 'Add' and 'Remove' buttons. A table below the buttons lists the configured PDSCH channels:

Name	RB Num	RB Offset	Allocation	Power	Mod Type
User0	6	0	1111111111	0 dB	QPSK
User1	50	0	1111111111	0 dB	QPSK

Below the table, there are input fields for the selected 'User1' channel:

- RB Num: 50 RB
- RB Offset: 0 RB
- Power: 0 dB
- Mod Type: QPSK
- Allocation: 1111111111

5) Remove

Used to remove manually added PDSCH channels.

6) RB Num

Configurable range: 1RB ~ (BandWidth RB count - 1), Default: 6RB.

Sets the number of RBs occupied by the PDSCH channel in one subframe.

7) RB Offset

Configurable range: 0RB ~ (BandWidth RB count - RB Num), Default: 0RB.

Sets the RB offset within the subframe.

8) Power

Configurable range: -20dB ~ 20dB, Default: 0dB.

Sets the power of PDSCH.

9) Mode Type


Options: QPSK | 16QAM | 64QAM | 256QAM | 1024QAM, Default: QPSK.

Sets the modulation scheme for PDSCH data.


10) Allocation

Options: On | Off, Default: On.

Sets the enable state of PDSCH subframes. Clicking this configuration item opens a sub-window to configure the enable state of each subframe.



6. PHICH



1) Ng

Options: Auto | 1/6 | 1/2 | 1 | 2, Default: Auto.

Sets the value of the Ng parameter. Auto enables automatic search for the Ng value.

2) Duration


Options: Auto | Normal | Extended, Default: Auto.

Sets the duration of PHICH. Auto enables automatic search for the PHICH duration.

3.5.1.3 Channel (Uplink)

3.5.1.3.1 Common

Set common parameters that apply to all uplink channels.



1. Sequence Hopping

Options: On | Off, Default: Off.

Toggle the enable state of sequence hopping, uniformly setting PUCCH-DMRS and PUSCH-DMRS with this parameter.

2. Group Hopping

Options: On | Off, Default: Off.

Toggle the enable state of group hopping, uniformly setting PUCCH-DMRS and PUSCH-DMRS with

this parameter.


3. RNTI

Range: 0 ~ 65535, Default: 1.

Set the RNTI value, uniformly configuring PUCCH and PUSCH with this parameter.

3.5.1.3.2 PUSCH

LTE uplink supports only a single PUSCH configuration.



1. PUSCH State

Options: On | Off, Default: On.

Toggle the enable state of the PUSCH channel.

2. Power Boosting

Range: -40 dB ~ 40 dB,

Default: 0 dB.

Set the power of the PUSCH channel relative to other channels.

3. Auto Sync

Options: On | Off, Default: On.

Toggle the enable state of PUSCH auto-sync. When On, the current channel uses auto-sync; if Off, manual selection of the first slot for current sync is supported.

4. Sync Slot

Range: 0 ~ slot length-1, Default: 0.

Set the starting slot for PUSCH demodulation sync.

Note: Configurable only when Auto Sync is set to Off.

5. Freq Hopping

Options: Off | Inter-Subframe | Intra and Inter-Subframe,

Default: Off.

Turn off or select different hopping modes for PUSCH.

Intra and inter-subframe hopping: Hopping occurs both within the same subframe and between different subframes.

Inter-subframe hopping: Hopping occurs between subframes, not between the two slots within the same subframe.

6. Hop Mode

Options: Type1 +1/4 | Type1 -1/4 | Type1 +1/2 | Type2,

Default: Type1 +1/2.

Select the hopping type for PUSCH.

Note: This option is not configurable when Hopping Mode is Off, with different Hopping Mode having different selectable ranges.

7. N_HO_RB

Range: 0 ~ maximum RB number for current bandwidth - 1,

Default: 0.

Set the hopping offset for the current PUSCH, with this parameter and other RB-related parameters constrained by 3GPP protocol.

Note: This option is not configurable when Hopping Mode is Off.

8. Nsb

Range: 1 ~ 4, Default: 1.

Set the number of subbands for PUSCH.

Note: This option is not configurable when Hopping Mode is Off.

9. Delta ss

Range: 0 ~ 29, Default: 0.

Set DMRS sequence parameters for calculating sequence shift.

10. nDMRS (1)

Range: 0 ~ 1, Default: 0.

Set DMRS sequence-related parameters (for PUCCH formats 4 and 5, range as per Table 3-10), calculating the cyclic shift for intra-frame demodulation reference signals (DMRS).

Table 3-10 (TS36.211 Table 5.5.2.1.1-2) Mapping of cyclic Shift to $n_{\text{DMRS}}^{(1)}$ values

cyclicShift	$n_{\text{DMRS}}^{(1)}$
0	0
1	2
2	3
3	4
4	6
5	8
6	9
7	10

11. PUSCH ID

Range: 0 ~ 509, Default: -1 (no configuration).

Set the PUSCH ID value.

12. DMRS PUSCH CSH ID

Range: 0 ~ 509, Default: -1 (no configuration).

Set the initial value for cyclic shift hopping used in PUSCH DMRS pseudo-random sequence generation.

13. Layer Number

Options: 1(1 Antenna) | 2(2 Antennas) | 4 (4 Antennas), Default: 1.

Set the number of layers for PUSCH, with the range depending on the number of antennas.

14. Activate DMRS with OCC

Options: On | Off, Default: Off.

Determine whether DMRS uses orthogonal cover code (OCC).

15. PUSCH Transmission Table

Click to enter the subframe configuration interface for PUSCH, supporting individual parameter configuration for each subframe.

Frame	Subframe	State	DMRS Power	RA Type	RB Offset	RB Size	RBG Start 1	RBG End 1	RBG Start 2	RBG End 2	MCS Index	CS Field Index
0	0											
0	1											
0	2	On	0.00 dB	Type 0	0	25	1	8	10	16	0	0
0	3	On	0.00 dB	Type 0	0	25	1	8	10	16	0	0
0	4	On	0.00 dB	Type 0	0	25	1	8	10	16	0	0
0	5											
0	6											
0	7	On	0.00 dB	Type 0	0	25	1	8	10	16	0	0
0	8	On	0.00 dB	Type 0	0	25	1	8	10	16	0	0
0	9	On	0.00 dB	Type 0	0	25	1	8	10	16	0	0

1) Frame

Display the frame number corresponding to each frame.

2) Subframe

Display the subframe number corresponding to each subframe.

3) State

Options: On | Off, Default: On.

Toggle the enable switch for each subframe.

4) DMRS Power

Range: -40 dB ~ 40 dB, Default: 0 dB.

Set the power of PUSCH DMRS relative to the PUSCH channel for each subframe.

5) RA Type

Options: Type 0 | Type 1, Default: Type 0.

Set the mapping type for PUSCH.

6) RB Offset

Range: 0 ~ maximum RB number for current bandwidth - PUSCH RB Size, Default: 0.

Set the RB offset for the current subframe of PUSCH, with the range constrained by the maximum RB number for current bandwidth and RB Size.

Note: Configurable only when PUSCH's RA Type is set to Type 0.

7) RB Size

Range: 0 ~ maximum RB number for current bandwidth, Default: 25.

Set the number of RBs occupied by the current subframe of PUSCH, with RB Size and RB Offset not exceeding the maximum RB number for current bandwidth.

8) RBG Start 1

Range: 1 ~ RBG End 1 - 1, Default: 1.

Set the starting position 1 of RBG for the current subframe of PUSCH when RA Type is Type 1.

Note: Configurable only when PUSCH's RA Type is set to Type 1.

9) RBG End 1

Range: RBG Start 1 + 1 ~ RBG End 2 - 1, Default: 8.

Set the ending position 1 of RBG for the current subframe of PUSCH when RA Type is Type 1.

Note: Configurable only when PUSCH's RA Type is set to Type 1.

10) RBG Start 2

Range: RBG End 1 + 1 ~ RBG Start 2 - 1, Default: 10.

Set the starting position 2 of RBG for the current subframe of PUSCH when **RA Type** is Type 1.

Note: Configurable only when PUSCH's **RA Type** is set to Type 1.

11) RBG End 2

Range: **RBG End 1** + 1 ~ maximum RBG number for current bandwidth;

Default: 18.

Set the ending position 2 of RBG for the current subframe of PUSCH when **RA Type** is Type 1.

Note: Configurable only when PUSCH's RA Type is set to Type 1.

12) MCS Index

Range: 0~28, Default: 0.

Set the MCS index for the current subframe, affecting modulation mode and TBS index, refer to 3GPP TS 36213 for more information.


13) CS Field Index

Range: 0 ~ 7, Default: 0.

Set the cyclic shift index for the current subframe.

3.5.1.3.3 PUCCH

LTE uplink supports only a single PUCCH configuration.



1. PUCCH State

Options: On | Off, Default: On.

Toggle the enable switch for the PUCCH channel.

2. Power Boosting

Range: -40 dB ~ 40 dB, Default: 0 dB.

Set the power of PUCCH data relative to other channels.

3. Auto Sync

Options: On | Off, Default: On.

Toggle the enable state of PUCCH auto-sync. When On, the current channel uses auto-sync; if Off, manual selection of the first slot for current sync is supported.

4. Sync Slot

Range: 0 ~ slot length-1, Default: 0.

Set the starting slot for PUSCH demodulation sync.

Note: Configurable only when Auto Sync is set to Off.

5. NRB (2)

Range: 0 ~ maximum RB number for current bandwidth, Default: 0.

Set the number of RBs used for PUCCH format 2/2a/2b resources (nPUCCH2).

6. N_CS(1)

Range: 0 ~ 7, Default: 0.

Set the number of resources for format 1 in mixed resources of PUCCH format 1/1a/1b and format 2/2a/2b.

7. Delta Shift PUCCH

Range: 1 ~ 3, Default: 1.

Set the cyclic shift interval $\Delta_{\text{shift}}^{\text{PUCCH}}$ for PUCCH format 1/1a/1b.

8. PUCCH ID

Range: -1 ~ 509, Default: -1.

Set the PUCCH parameter n_{ID}^{PUCCH} .

9. PUCCH Transmission Table

Click to enter the subframe configuration interface for PUCCH, supporting individual parameter configuration for each subframe.

Frame	Subframe	Subframe State	DMRS Power	PUCCH Format	Data Size	nPUCCH(1,0)	nPUCCH(1,1)	nPUCCH(2,0)	nPUCCH(2,1)	nPUCCH(3,0)	nPUCCH(3,1)	nPUCCH(4,0)	nPUCCH(5,0)	nPUCCH(4,b)	noc	ndmrs1	mid_dmrs	D	
0	0	Off																	
0	1	Off																	
0	2	On	0.00 dB	Format1	1	0	0	0	0	0	0	0	0	1	0	0		-1	
0	3	On	0.00 dB	Format1	1	0	0	0	0	0	0	0	0	1	0	0		-1	
0	4	On	0.00 dB	Format1	1	0	0	0	0	0	0	0	0	1	0	0		-1	
0	5	Off																	
0	6	Off																	
0	7	On	0.00 dB	Format1	1	0	0	0	0	0	0	0	0	1	0	0		-1	
0	8	On	0.00 dB	Format1	1	0	0	0	0	0	0	0	0	1	0	0		-1	
0	9	On	0.00 dB	Format1	1	0	0	0	0	0	0	0	0	1	0	0		-1	

1) Subframe

Display the subframe number corresponding to each subframe.

2) State

Options: On | Off, Default: On.

Toggle the enable switch for each subframe.

3) DMRS Power

Range: -40 dB ~ 40 dB, Default: 0 dB.

Set the power of PUCCH DMRS relative to the PUCCH channel.

4) PUCCH Format

Options:

Format 1 | Format 1a | Format 1b | Format 2 | Format 2a

Format 2b | Format 3 | Format 4 | Format 5.

Default: Format 1.

Set the PUCCH format for the current subframe.

5) Data Size

Range: 1 ~ 13, Default: varies by format.

Set the number of bits for the current subframe.

6) nPUCCH (1,0)

Range: maximum value constrained by CP Type, maximum RB number for current bandwidth, and Delta Shift PUCCH,

Default: 0.

Set the resource index for PUCCH Format 1 | 1a | 1b, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 1 | 1a | 1b.

7) nPUCCH (1,1)

Range: maximum value constrained by CP Type, maximum RB number for current bandwidth, and Delta Shift PUCCH,

Default: 0.

Set the resource index for PUCCH Format 1 | 1a | 1b with 2 antennas, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 1 | 1a | 1b.

8) nPUCCH (2,0)

Range: maximum value constrained by N_RB(2) and N_CS(1), Default: 0.

Set the resource index for PUCCH Format 2 | 2a | 2b, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 2 | 2a | 2b.

9) nPUCCH (2,1)

Range: maximum value constrained by N_RB(2) and N_CS(1), Default: 0.

Set the resource index for PUCCH Format 2 | 2a | 2b with 2 antennas, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 2 | 2a | 2b.

10) nPUCCH (3,0)

Range: maximum value constrained by maximum RB number for current bandwidth, Default: 0.

Set the resource index for PUCCH Format 3, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 3.

11) nPUCCH (3,1)

Range: maximum value constrained by maximum RB number for current bandwidth, Default: 0.

Set the resource index for PUCCH Format 3 with 2 antennas, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 3.

12) nPUCCH (4,0)

Range: 0 ~ maximum RB number for current bandwidth / 2, Default: 0.

Set the resource index for PUCCH Format 4, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 4.

13) nPUCCH (5,0)

Range: 0 ~ maximum RB number for current bandwidth, Default: 0.

Set the resource index for PUCCH Format 5, refer to 3GPP protocol 36211 for details.

Configurable only when **PUCCH Format** is set to 5.

14) nPUCCH(4,rb)

Display the number of RBs for PUCCH Format 4 in the current subframe, corresponding to the parameter.

Displayed only when **PUCCH Format** is set to 4.

15) noc

Range: 0 | 1, Default: 0.

Set the spreading sequence index for PUCCH Format 5 in the current subframe.


Configurable only when **PUCCH Format** is set to 5.

16) Delta SS

Range: 0 ~ 29, Default: 0.

Set DMRS sequence parameters for calculating sequence shift.

3.5.1.4 Meas Time



1. Meas Offset

1) Slot Offset

Range: 0~19, Default: 0.

Set the offset for measurement slots.

2) Symbol Offset

Range:

- 0 ~ 6 (normal CP),
- 0 ~ 5 (extended CP);

Default: 0.

Set the offset for measurement symbols.

2. Meas Length

1) Slot Length

Range: 0~20, Default: 20.

Set the measurement length (in slots).

2) Symbol Length

Range:

- 0 ~ 6 (normal CP),

- 0 ~ 5 (extended CP);

Default: 0.

Set the measurement length (in symbols).

3.5.1.5 Advanced

1. Equalizer

1) Equalizer Type

Options: Off | RS | RS+DATA, Default: RS.

Select the type of equalizer.

2) Moving Avg Filter

Range: 1 ~ Number of RBs set by BandWidth - 1,

Default:

- 19 (3MHz | 5MHz | 10MHz | 15MHz | 20MHz),
- 5 (1.4 MHz).

Set the length of the moving average filter.

2. EVM window

1) Window Type

Options: 3GPP | CUSTOM, Default: 3GPP.

Set the type of EVM window.

2) Window Length

Range: 1~512, Default: 32.

Set the length of the EVM window. Not configurable when the window type is 3GPP, as it is defined by the protocol. For more information, refer to 3GPP TS 36101 Section F.5.

3) EVM Window Adjust Type

Options: Start | Center | End, Default: Center.

Set the position of the EVM window.

3. EVM Minimization

1) EVM Minimization Type

Options: OFF | 3GPP | Tracking, Default: 3GPP.

Set the type of EVM minimization.

2) Timing

Options: On | Off, Default: On.

Toggle the enable state of timing compensation.

3) Amplitude

Options: On | Off, Default: Off.

Toggle the enable state of amplitude compensation.


4) Freq And Phs

Options: On | Off, Default: On.

Toggle the enable state of frequency and phase compensation.

3.5.2 Measurement Result

LTE measurement results setup path: **Trace** -> **Format**.



Setup steps:

- 1) Select the display window;
- 2) Select Group, different measurement results are placed in different groups;
- 3) Select the measurement result data to display.

Example of measurement results (Downlink):



Example of measurement results (Uplink):



1. Raw Main Time

Display the magnitude of raw data input from hardware or read from a playback file, with time on the x-axis and amplitude on the y-axis.

2. Spectrum

Display the spectrum of raw data input from hardware or read from a playback file, with frequency on the x-axis and amplitude on the y-axis.

3. IQ Meas Time

IQ Measurement Time displays the constellation diagram of data within the measurement length, with amplitude (normalized amplitude) on both the x-axis and y-axis. Different channels are distinguished by different colors.

4. RMS Error Vector Spectrum

RMS Error Vector Spectrum displays the Root Mean Square (RMS) EVM for each subcarrier, calculating the RMS EVM for all symbols within the measurement range on each subcarrier. The x-axis shows the subcarrier range across the entire channel bandwidth, in units of subcarrier/subcarrier; the y-axis shows the RMS EVM, in units of %.

5. RMS Error Vector Time

RMS Error Vector Time displays the Root Mean Square (RMS) EVM for each symbol, calculating the RMS EVM for all subcarriers within the measurement range on each symbol. The x-axis shows the symbol range across the entire channel bandwidth, in units of symbol; the y-axis shows the RMS EVM value, in units of %.

6. Error Vector Time

Error Vector Time displays the EVM at the subcarrier level, with time on the x-axis and EVM values on the y-axis. Each trace represents the EVM of each symbol within the measurement range on a subcarrier, with traces of all subcarriers overlapping each other.

7. Error Vector Spectrum

Error Vector Spectrum displays the EVM at the subcarrier level, with subcarriers on the x-axis and EVM values on the y-axis. Each trace represents the EVM of each subcarrier on a symbol, with traces of all symbols within the measurement range overlapping each other.

8. RE Allocation

Display the resource allocation of each channel within the measurement range, equivalent to a resource grid view, with symbols on the x-axis and subcarriers on the y-axis. Different channels are distinguished by different colors.

9. Error Summary

Error Summary includes the following error items of the measurement results:

Channel Power: Display the average power of the carrier, in units of dBm;

EVM (RMS/Peak): Display the RMS EVM and peak EVM of all current measurement channels;

RS Tx. Power (Downlink): Display the average power of the CRS signal, in units of dBm;

OFDM Sym. Tx. Power (Downlink): Display the average power of data subcarriers, in units of dBm;

Frequency Error: Frequency offset relative to the carrier center, in units of Hz;

Sync Correlation: Display the correlation between the measured synchronization signal and the ideal reference synchronization signal;

Common Tracking Error: RMS average of corrections applied to each symbol through EVM minimization;

Time Offset: Distance from the start of the search time trace to the measurement frame header, in units of s;

CP Length Mode: CP type of the signal (normal CP or extended CP);

Cell ID: Cell ID of the signal.

10. Frame Summary

Frame Summary parameters are calculated from the measurement data within the measurement length, including the following parameters of the measurement data:

Channel :

- Downlink channels: CRS/PBCH/PCFICH/PDCCH/PDSCH/PHICH/P-SS/S-SS;
- Uplink channels: PUCCH/PUSCH/PUCCH_DMRS/PUSCH_DMRS.

Power Per RE(dBm): Display the power of each subcarrier of the current channel, averaged over all subcarriers of the current channel;

EVM: RMS EVM of the current channel;


Mod.Format: Modulation scheme of the current channel, not displayed if there is no modulation scheme;

Num.RB: Number of RBs occupied by the current channel.

3.6 NB-IoT

3.6.1 Configuration

The path to enter the NB-IoT configuration interface is: Meas Setup -> NB-IoT Properties.



3.6.1.1 Config Carrier

1. Direction

Uplink/downlink type of the carrier. Default value is Downlink.

2. Duplex Mode

Duplex mode of the carrier. Default is FDD.

1. Operation Mode

NB-IoT signal mode. Options: Standalone | In-band | Guard Band. Default value is Standalone.

Operation mode. Double-click or use the drop-down menu to set the operation mode, which specifies the deployment mode of the NB-IoT downlink carrier.

- Stand-Alone: Independent deployment mode. The system bandwidth is set to 200 kHz.
- Guard-Band: Guard band deployment mode. The system bandwidth is set to the same as that of the coupled E-UTRA carrier.
- In-Band: In-band deployment mode.

4. Half-subcarrier Shift

Half-subcarrier shift, used to control whether the uplink transmission subcarrier is shifted by half the subcarrier spacing (i.e., 7.5 kHz). For downlink, this parameter is only used as a test configuration parameter, setting the instrument's downlink demodulation algorithm to "comply with LTE standards regarding subcarrier shift."

For more information, see 3GPP TS 36.331, Section 6.7.2.

5. Center Frequency

Carrier center frequency.

6. Bandwidth

Carrier bandwidth. Not visible under Standalone Operation Mode.

Options: 1.4 MHz (6 RB) | 3 MHz (15 RB) | 5 MHz (25 RB) | 10 MHz (50 RB) | 15 MHz (75 RB) | 20 MHz (100 RB).

Default value: 10 MHz (50 RB).

7. Frequency Offset

Frequency offset.

- Stand-Alone: Sets the frequency offset of the carrier relative to the signal generator's current frequency setting.
- The value range of this parameter is affected by the following factors: oversampling ratio, base sampling rate, system bandwidth, and the maximum arbitrary waveform sampling clock of the connected signal generator.
- Guard-Band: The frequency offset is calculated from the following parameters: coupled E-UTRA carrier, position relative to the coupled E-UTRA carrier, and offset from the edge of the coupled E-UTRA carrier.
- In-Band Same PCI / In-Band Different PCI: The frequency offset is calculated from the following parameters: coupled E-UTRA carrier and in-band resource block offset (In-Band RB Offset).

8. PRB Index

Physical Resource Block index. The PRB Index identifies the specific physical resource block number allocated to the NB-IoT carrier (especially in in-band deployment). This index is used in conjunction with parameters such as system bandwidth and In-Band RB Offset to determine the precise frequency position of the NB-IoT carrier within the LTE band.

9. Δf to DC

Frequency offset relative to the DC subcarrier. Only visible in Guard Band operation mode.

9. Num. of NRS Ports

Number of NRS antenna ports. Displays the number of antenna ports for the Narrowband Reference Signal (NRS), which is the same as the total number of antennas.

10. Reference NRS Port

Reference NRS port. This parameter specifies on which antenna port the NRS is transmitted.

11. Carrier Type

Downlink carrier narrowband configuration. Options: Anchor Carrier | Non-Anchor Carrier. Default value: Anchor Carrier.

Double-click or use the drop-down menu to set the downlink carrier narrowband configuration.

- Anchor Carrier: In NB-IoT, the UE assumes that NPSS/NSSS/NPBCH/SIB-NB are transmitted on this carrier.
- Non-Anchor Carrier: In NB-IoT, the UE does not assume that NPSS/NSSS/NPBCH/SIB-NB are transmitted on this carrier. This carrier is used for all unicast transmissions. For more information, see 3GPP TS 36.331, Section 6.7.3.2.

12. Sync Type

Synchronization signal source. Options: NPSS | NRS. Default value: NPSS.

13. CellID Detect

Cell ID detection mode. Options: Auto | Manual. Default value: Auto.

14. CellID

Cell ID setting. Only configurable when CellID Detect mode is Manual.

15. Data Sample Rate

Base sampling rate. Displays the base sampling rate for each system bandwidth or multi-carrier

condition. When the system bandwidth is 200 kHz, the base sampling rate is 1.92 MHz.

16. Multicarrier Filter

Multi-carrier filter.

3.6.1.2 Channel

1. NB downlink channel enable

Enables detection of NPSS, NSSS, NPBCH, and NPDCCH channels.

2. NPDCCH

Number of subframes to start detecting NPDCCH signals.

3. NPDSCH

Number of repetitions for NPDCCH signal detection.

3.6.1.3 Meas Time

1. Search Length

Search Length is the amount of data used to acquire and search for NB-IoT frames. Search and demodulation are performed within the Search Length range. Unit: seconds (s).

2. Meas Offset

Sets the starting position of the measurement signal. Slot Offset is the starting slot position. Symbol Offset is the starting symbol position.

3. Meas Length

Sets the length of the measurement signal. Slot Offset is the slot length of the signal. Symbol Offset is the symbol length of the signal.

3.6.1.4 Advanced

1. Equalizer

Equalizer settings.

Equalizer Type: Reference equalization signal type. Options: off | RS | RS + Data. Default value: RS.

Moving Avg. Filter: Moving average filter. The main function of this parameter is to smooth the measurement results.

2. EVM window

Error Vector Magnitude window.

Window Type: Method for measuring and calculating EVM. Options: 3GPP | Custom. Default value: 3GPP.

Window Length: Window length.

EVM Window Adjust Type: Flexibly selects the FFT snapshot position for calculation based on the test objective. Options: EVM Window Start | EVM Window End | EVM Window Center. Default value: EVM Window Center.

3. EVM Mimimization

Error Vector Magnitude minimization. Compensates for common signal impairments during transmission through algorithms to minimize the measured EVM.

EVM Mimimization Type: Three options: off | 3GPP | Tracking. Default value: off.

Timing: When enabled, the instrument analyzes the phase slope of the reference signal in the frequency domain (reflecting time-domain delay) and adjusts the sampling point position accordingly to compensate for sampling point offset caused by symbol timing deviation.

Amplitude: When enabled, measures the amplitude error between the received reference signal and the ideal signal, and applies reverse compensation.


Frequency/Phase: When enabled, it eliminates the measured residual frequency offset and phase noise in real time, "tightening" the constellation diagram to accurately evaluate phase noise and PLL performance, preventing them from being incorrectly counted in the EVM results.

4. Sacle Conversion

Scale conversion.

3.6.2 Measurement Results


The path for setting NB-IoT measurement results is: Trace -> Format.



Setup Steps:

- 1) Select the display window.
- 2) Select Group to place different measurement results into different groups.
- 3) Select the measurement result data to be displayed.

Measurement Result Example (Downlink):



1. Raw Main Time

Displays the magnitude of the raw data read from hardware input or played from a file. X-axis shows time, Y-axis shows amplitude.

2. Spectrum

Displays the spectrum of raw data read from hardware input or played from a file. X-axis shows

frequency, Y-axis shows amplitude.

3. IQ Meas Time

IQ measurement time displays a constellation diagram of the data within the measurement length. Both X and Y axes show amplitude (normalized amplitude). Different colors are used to distinguish different channels.

4. RMS Error Vector Spectrum

RMS error vector spectrum displays the root mean square (RMS) EVM for each subcarrier. RMS calculation of EVM is performed over all symbols within the measurement range for each subcarrier. X-axis shows the subcarrier range across the entire channel bandwidth (unit: subcarrier | ksubcarrier). Y-axis shows RMS EVM (unit: %).

5. RMS Error Vector Time

RMS error vector time displays the RMS EVM for each symbol. RMS calculation of EVM is performed over all subcarriers within the measurement range for each symbol. X-axis shows the symbol range across the entire channel bandwidth (unit: symbol). Y-axis shows RMS EVM (unit: %).

6. Error Vector Time

Error vector time domain displays EVM at the subcarrier level. X-axis is time, Y-axis is EVM value. Each trace represents the EVM for individual symbols on a specific subcarrier within the measurement range. Traces for all subcarriers overlap each other.

7. Error Vector Spectrum

Error vector frequency domain displays EVM at the subcarrier level. X-axis is subcarrier, Y-axis is EVM value. Each trace represents the EVM for subcarriers on a specific symbol within the measurement range. Traces for all symbols overlap each other.

8. RE Allocation

Displays resource allocation for various channels within the measurement range, essentially a resource grid view. X-axis is symbol, Y-axis is subcarrier. Different channels are distinguished by different colors.

9. Error Summary

The error summary includes the following error terms in the measurement results:

Channel Power: Displays the average power of the carrier (unit: dBm).

EVM (RMS/Peak): Displays the RMS EVM and peak EVM for all measured channels.

RS Tx. Power (Downlink): Displays the average power of the CRS signal (unit: dBm).

OFDM Sym. Tx. Power (Downlink): Displays the average power of data subcarriers (unit: dBm).

RSSI: Received Signal Strength Indicator.

Freq Error: Frequency offset relative to the carrier center (unit: Hz).

SynCorr: Displays the correlation between the measured synchronization signal and the ideal reference synchronization signal.

Common Tracking Error: RMS average of corrections applied per symbol through EVM minimization.

Time Offset: Distance from the start of the search time trace to the measurement frame header (unit: s).

Cell ID: Cell ID of the signal.

10. Frame Summary

Frame summary parameters are calculated from the measurement data within the measurement length and include the following:

Channel :

- Downlink channels: NPSS/NRS/NSSS/NPBCH/NPDCCH/NPDSCH-QPSK/NPDSCH-16QAM;

Power(dB): Displays the relative power per subcarrier for the current channel, averaged over all subcarriers of that channel.


EVM(%rms): RMS EVM of the current channel.

EVM(%pk): Peak EVM of the current channel.

3.7 WLAN

3.7.1 Configuration

The path to enter the WLAN configuration interface is: **Meas Setup** -> **WIFI Properties**.



3.7.1.1 Base

1. Standard

Options: IEEE 802.11b/g | IEEE 802.11a/g | IEEE 802.11n | IEEE 802.11ac | IEEE 802.11ax | IEEE 802.11be.

Default: IEEE 802.11ax.

Select the demodulated signal protocol type.

2. Data Modulation Format

Options: Barker 1 | Barker 2 | CCK 5.5 | CCK11.

Default: Barker 1.

Select the demodulated signal modulation rate.

3. Bandwidth

Options: 20MHz | 40MHz | 80MHz | 160MHz | 320MHz.

Default: 20MHz.

Select the demodulated signal bandwidth.

4. Frame Format

Options: HE SU | HE ER SU | HE MU | HE TB | EHT MB | EHT TB.

Default: HE SU (Wi-Fi 6) | EHT MB (Wi-Fi 7).

Select the demodulated signal PHY-layer PPDU frame type.

5. SIG Compression Field

Options: On | Off.

Default: Off.

When enabled, indicates full-bandwidth transmission (as opposed to OFDMA, which divides bandwidth into multiple RUs).

6. Compression Mode(Non-OFDMA)

Options: On | Off.

Default: Off.

When enabled, indicates full-bandwidth transmission (as opposed to OFDMA, which divides bandwidth into multiple RUs).

7. HE PPDU RU Allocation

Configure HE PPDU RU allocation mode.

1) SU

Options: On | Off; Default: On.

When HE SU PPDU mode is enabled, MU and Trigger Based options are grayed out.

2) MU

Options: Off | From SIG Symbols | Manual; Default: Off.

When HE MU PPDU mode is enabled, SU and Trigger Based options are grayed out.

3) Trigger Based

Options: Off | Automatic (1 RU) | Manual.

Default: Off.

When HE Trigger Based PPDU mode is enabled, SU and MU options are grayed out.

8. ETH PPDU RU Allocation

Configure EHT PPDU RU allocation mode.

1) SU

Options: On | Off.

Default: On.

When EHT SU PDU mode is enabled, MU and Trigger Based options are grayed out.

2) MU

Options: Off | From SIG Symbols | Manual.

Default: Off.

When EHT MU PDU mode is enabled, SU and Trigger Based options are grayed out. If Manual mode is selected, the Allocate Signal settings dialog will appear.

3) Trigger Based

Options: Off | Automatic (1 RU) | Manual.

Default: Off.

When EHT Trigger Based PDU mode is enabled, SU and MU options are grayed out.

9. Data Subcarrier Modulation Format

Specify the modulation format for data subcarriers.

1) From Sig Symbols

Options: On | Off.

Default: On.

2) Manual

Options: Off | BPSK | QPSK | 16-QAM | 64-QAM | 256-QAM | 1024-QAM | 4096-QAM.

Default: Off.

10. Guard Interval

The Guard Interval is the ratio of the cyclic prefix (CP) time to the IFFT time (T_{IFFT}), used to eliminate inter-symbol and inter-carrier interference.

1) From SIG Symbols

Options: On | Off.

Default: On.

2) Manual

Options: On | Off.

Default: Off.

3) Manual Value

Options: 0–1.

Default: 0.25.

11. HE-LTF Duration

Select the HE-LTF type parameter to adjust HE-LTF symbols.

1) From SIG Symbols

Options: On | Off.

Default: On.

2) Manual

Options: Off | 1x | 2x | 4x.

Default: Off.

12. EHT-LTF Duration

Select the EHT-LTF type parameter to adjust EHT-LTF symbols.

1) From SIG Symbols

Options: On | Off.

Default: On.

2) Manual

Options: Off | 1x | 2x | 4x.

Default: Off.

3.7.1.2 Filter

1. Reference Filter

Options: Gaussian | Raised Cosine | Rectangular.

Select the reference filter type.

2. Alpha BT

Configure the Alpha/BT parameter.

3. Alpha

When specifying the Gaussian filter as the reference filter, the BT (bandwidth–time product) of the filter can be set to a value between 0.05 and 100. Default value: 0.5.

4. BT

When specifying the Raised Cosine filter as the reference filter, the Alpha of the filter can be set to a value between 0.05 and 1. Default value: 0.5.

3.7.1.3 Time

1. Search Length

Minimum: 60 μ s; Default: 1.5 ms.

Defines the time duration for pulse search.

2. Result Length Mode

Options: Auto | Manual; Default: Auto.

Specifies the demodulated chip pattern available for analysis.

3. Result Length Value

Range: 1 – 250,000 Chips.

Default: 60 Chips.

Specifies the number of demodulated chips available for analysis.

4. Automatic Result Length

Options: On | Off; Default: On.

When enabled, the measurement result length is determined automatically by comparing the detected symbol count with the **Maximum Result Length** parameter and using the smaller value.

5. Maximum Result Length

Minimum: 0 Symbols.

Default: 60 Symbols.

User–defined maximum number of symbols.

6. Manual Result Length

Options: On | Off.

Default: Off.

When enabled, the measurement result length can be set manually.

7. Measurement Offset

Minimum: 0 Chips.

Default: 0 Chips.

Sets the measurement offset (in chips) relative to the **Result Length** start position.

8. Measurement Interval

Minimum: 0 Chips.

Default: 60 Chips.

Defines the interval of demodulated and analyzed data within the Result Length.

9. Meas Interval

Minimum: 0 Symbols.

Default: 0 Symbols.

Defines the time duration of Result Length data used for computing and displaying trace results.

10. Meas Offset

Minimum: 0 Symbols.

Default: 0 Symbols.

Sets the symbol offset (from the first data symbol) relative to the Result Length start position.

3.7.1.4 Advanced

1. Chip Rate

Minimum: 0 Hz.

Default: 11 MHz.

Configures the chip rate for the VSA demodulator.

2. Clock Adjustment

Minimum: 0 Chips.

Default: 0 Chips.

Determines when the VSA digital demodulator samples the I/Q trace.

3. Normalize IQ Traces

Options: On | Off; Default: On.

Normalizes I/Q data when enabled.

4. Equalize

Options: On | Off; Default: Off.

Applies the VSA equalization filter to the measurement. The filter length can be specified in the Filter Length field.

5. Filter Length

Range: 3 to 99 chips (odd numbers only).

Default: 5 Chips.

Sets the length of the VSA equalization filter.

6. Descramble Mode

Options: On | Off | Preamble Only | Preamble & Header Only.

Configures the WLAN 802.11b/g descramble.

1) ON

Descrambles preamble, header, and payload.

2) Off

No descrambling.

3) Preamble Only

Descrambles only preamble.

4) Preamble & Header Only

Descrambles preamble and header (payload remains scrambled).

7. Mirror Frequency Spectrum

Options: On | Off; Default: Off.

Allows the VSA to correctly demodulate a frequency spectrum mirrored (flipped) around the center frequency.

8. Compensate Sampling Clock Error

Options: On | Off; Default: Off.

Compensates for sampling clock errors by adjusting for the difference between ideal and actual sampling clock frequencies (applied before demodulation).

9. Remove Equalizer Phase Ramp

Options: On | Off; Default: Off.

If enabled, the VSA normalizes the phase and phase ramp of each stream/channel's frequency response individually. If disabled, normalization is based on Stream 1 Channel 1.

10. Display EVM in Percent

Options: On | Off; Default: Off.

Displays EVM in percentage (%) when enabled; otherwise, in dB.

11. Display Sync Correlation in Percent

Options: On | Off; Default: Off.

Displays synchronization correlation in percentage (%) when enabled.

12. Symbol Time Adjustment

Adjusts the FFT window start point within the CP (Cyclic Prefix) region to ensure a clean FFT period (avoiding interference from the falling edge).

1) Mode

Options: Auto | Manual.

Default: Manual.

Auto: VSA finds the optimal EVM value, Manual: User-defined adjustment.

2) Adjustment

Range: $-GI/100$ to 0.

Default: -3.125%.

Configurable only in Manual mode.

13. Subcarrier Selection

Specifies which subcarrier types are analyzed and displayed.

1) Display Data Subcarriers

Options: On | Off.

Default: Off.

2) Display Pilot Subcarriers

Options: On | Off.

Default: On.

14. Sample Rate Mode

Options: Auto | Manual.

Default: Auto.

Auto: Automatically selects the demodulation sample rate, Manual: Allows manual setting.

15. Pilot Tracking

Pilot subcarriers transmit known sequences to determine errors between ideal and received signals. The VSA calculates phase, amplitude, and timing errors for correction.

Options: Track Amplitude | Track Phase | Tracking Timing.

1) Track Amplitude

Options: On | Off.

Default: Off.

If enabled, averaged pilot amplitude scales the expected amplitude of other subcarriers.

2) Track Phase

Options: On | Off.

Default: On.

If enabled, selects which subcarrier types are used for phase error correction.

3) Track Timing

Options: On | Off.

Default: On.

If enabled, the average phase slope of pilots removes symbol-to-symbol timing errors.

16. Frequency Estimation Mode

Options: Preamble Only | Preamble & Pilots | Preamble, Pilots & Data.

Default: Preamble & Pilots.

Selects the signal segment used for frequency offset estimation.

1) Preamble Only

Frequency offset estimation is performed using only the preamble.

2) Preamble & Pilots

Use the preamble and pilot signals.

3) Preamble, Pilots & Data

Use the preamble, pilot signals, and data subcarriers.

17. Equalizer Training

For 802.11n/ac/ax/be signals, the VSA uses an equalizer to correct linear impairments (e.g., multipath).

Options: Preamble Only | Preamble, Pilots & Data.

Default: Preamble Only.

1) Preamble Only

Uses only the preamble's channel estimation sequence.

2) Preamble, Pilots & Data

Uses preamble, pilots, and data subcarriers.

18. Equalizer Smoothing

Options: None (Linear) | Triangular.

Default: Triangular.

Configures smoothing during equalization.

19. Length

Visible when Triangular smoothing is selected.


Range: 3–117 subcarriers.

Default: 5.

Sets the triangular filter length (in subcarriers).

3.7.2 Measurement Results


The WLAN measurement results configuration path is: **Trace** -> **Format**.



Setup Steps:

- 1) Select the display window;
- 2) Select Group (different measurement results are grouped separately);
- 3) Select the measurement result data to display.

Example Measurement Results (IEEE 802.11b/g):



1. Raw Main Time

Displays the magnitude of raw data from hardware input or playback files.

- X-axis: Time
- Y-axis: Amplitude

2. Error Summary

Includes the following error metrics:

EVM: Average EVM of all pilots, preambles, and data;

EVM Peak: Peak EVM of all pilots, preambles, and data;

Mag Err: Magnitude error (difference between measured and reference signal magnitudes, as a percentage of the ideal signal's RMS power);

Mag Err Peak: Peak magnitude error;

Phase Err: Phase error (difference between measured and reference signal phases);

Phase Err Peak: Peak phase error;

Freq Err: Carrier frequency offset relative to the VSA center frequency;

Sync Corr: Cross-correlation between the measured preamble and the ideal Barker sequence.

3. Spectrum

Displays the spectrum of raw data from hardware input or playback files.

- X-axis: Frequency
- Y-axis: Amplitude

4. IQ Meas Time

Displays demodulated time-domain IQ data sampled at chip intervals.

- X & Y axes: Normalized amplitude.

5. Error Vector Time

Displays error vector time-domain trace data within the specified measurement interval.


- X-axis: Time
- Y-axis: EVM

6. Phase Error Vector Time

Displays phase error vector time-domain trace data within the specified measurement interval.

- X-axis: Time
- Y-axis: Phase error

Example Measurement Results (IEEE 802.11a/g/n/ac):



1. Raw Main Time

Displays the magnitude of raw data from hardware input or playback files.

- X-axis: Time
- Y-axis: Amplitude

2. Error Summary

Includes:

- EVM: Average EVM of all subcarriers and OFDM symbols (dB);
- EVM Peak: Peak EVM of all subcarriers and OFDM symbols (dB);
- Pilot EVM: EVM of pilot subcarriers across all symbols (dB);
- Data EVM: Average EVM of data subcarriers across all symbols (dB);
- Freq Error: Frequency offset relative to carrier center (Hz);
- CPE: Common phase error between received and ideal pilots (% RMS);

Sync Corr: Correlation between measured and reference sync signals (%);

Sym Time Adj: Symbol timing adjustment (default: -3.125%, range: [-GI/100, 0]).

3. Spectrum

Displays the spectrum of raw data from hardware input or playback files.

- X-axis: Frequency

- Y-axis: Amplitude

4. IQ Meas Time

Displays constellation plot of measured data.

- X & Y axes: Normalized amplitude.

5. Burst Info

Displays PLCP (PHY Layer Convergence Protocol) summary data for the analyzed data burst, including modulation type, symbol length, power (dBm), and EVM (dB).

6. Error Vector Spectrum

Displays error vector per subcarrier.

- X-axis: Subcarrier index

- Y-axis: EVM

Example Measurement Results (IEEE 802.11ax/be):



1. Raw Main Time

Displays the magnitude of raw data from hardware input or playback files.

- X-axis: Time
- Y-axis: Amplitude

2. Error Summary

Includes:

- EVM: Average EVM of all subcarriers and OFDM symbols (dB);
- EVM Peak: Peak EVM of all subcarriers and OFDM symbols (dB);
- Pilot EVM: EVM of pilot subcarriers across all symbols (dB);
- Data EVM: Average EVM of data subcarriers across all symbols (dB);
- Freq Error: Frequency offset relative to carrier center (Hz);
- CPE: Common phase error between received and ideal pilots (% RMS);
- Sync Corr: Correlation between measured and reference sync signals (%);
- Sym Time Adj: Symbol timing adjustment (default: -3.125%, range: [-GI/100, 0]).

3. Spectrum

Displays the spectrum of raw data from hardware input or playback files.

- X-axis: Frequency

- Y-axis: Amplitude

4. IQ Meas Time

Displays constellation plot of measured data.

- X & Y axes: Normalized amplitude

5. Burst Info

Displays summarized burst information grouped by frame segments (e.g., L-STF, L-LTF, L-SIG), including EVM, power, and modulation.

6. Error Vector Spectrum

Displays error vector per subcarrier.

- X-axis: Subcarrier index

- Y-axis: EVM

7. RU Info

Displays demodulation information per RU (Resource Unit), such as size, power, and EVM.


8. User Info

Displays per-user information, including modulation, MCS, EVM, power, and STA-ID.

3.8 Bluetooth

3.8.1 Configuration

The path to enter the Bluetooth configuration interface is: Meas Setup -> Bluetooth Properties.



3.8.1.1 General

1. Search Length

Search Length is the data length for acquiring and searching Bluetooth frames. Searching and demodulation are performed within the Search Length range. The unit is seconds (s).

2. Waveform Type

Set the type of Bluetooth packet to be demodulated. Options are: Basic Rate | Enhanced Data Rate | Low Energy. The default value is Basic Rate.

3. I/Q Map

IQ image flip switch. Options are: Normal | Invert. The default value is Normal.

4. Manual Sample Rate

Manual sampling rate setting switch. Options are: Auto | Manual. The default value is Auto. When set to Manual, the demodulation sampling rate can be changed manually.

3.8.1.2 Result

1. Packet ID

Set the broadcast packet ID of the signal to be demodulated.

2. Averaging

Used to specify the number of data acquisitions to be averaged. After the specified average count is reached, turn on the averaging switch via "Averaging". Options are: Off | On. The default value is Off.

3. Avg Hold Number

The number of data acquisitions to be averaged. Can be set after Averaging is enabled.

3.8.1.3 Tx Power

1. Output Power Start Marker

Used to determine the point at which power averaging begins. Defined as a percentage of the burst length relative to a specific starting point. The difference between the output power stop and start markers must be at least 1%.

2. Output Power Stop Marker

Used to determine the point at which power averaging stops. Defined as a percentage of the burst length relative to a specific starting point. The difference between the output power stop and start markers must be at least 1%.

3. GFSK Start Marker

Used to determine the point at which power averaging begins. Defined as a percentage of the EDR GFSK length relative to a specific starting point. The difference between the EDR GFSK average power stop marker and start marker must be at least 1%.

4. GFSK Stop Marker

Used to determine the point at which power averaging stops. Defined as a percentage of the EDR GFSK length relative to a specific starting point. The difference between the EDR GFSK average power stop marker and start marker must be at least 1%.

5. DPSK Start Marker

Used to determine the point at which power averaging begins. Defined as a percentage of the EDR DPSK length relative to a specific starting point. The difference between the EDR DPSK average power stop marker and start marker must be at least 1%.

6. DPSK Stop Marker

Used to determine the point at which power averaging stops. Defined as a percentage of the EDR DPSK length relative to a specific starting point. The difference between the EDR DPSK average power stop marker and start marker must be at least 1%.

3.8.1.4 Limit

3.8.1.4.1 BR

1. Limit Test

Turn parameter limits on or off.

2. DH Type

Specify the packet type. Options are: DH1 | DH3 | DH5. The default value is DH1.

3. Average Power Lower

GFSK average power lower limit.

4. Average Power Upper

GFSK average power upper limit.

5. Peak Power Upper

GFSK peak power upper limit.

6. Relative Peak Upper

GFSK peak power upper limit.

7. Δf_1 Avg Lower

f1 average lower limit.

8. Δf_1 Avg Upper

f1 average upper limit.

9. Δf_2 Max Lower

Lower limit of the maximum value of Δf_2 .

10. Δf_2 Avg/ Δf_1 Avg Lower

Lower limit of the $\Delta f_2/\Delta f_1$ ratio.

11. Freq Drift Lower

Lower limit of frequency drift.

12. Freq Drift Upper

Upper limit of frequency drift.

13. Max Drift Rate Lower

Lower limit of the maximum frequency drift rate.

14. Max Drift Rate Upper

Upper limit of the maximum frequency drift rate.

15. ICFT Lower

Lower limit of the initial carrier frequency tolerance.

16. ICFT Upper

Upper limit of the initial carrier frequency tolerance.

3.8.1.4.2 LE

1. Limit Test

Enable or disable parameter limits.

2. Limit Type

Set the symbol rate. Options: 1M | 2M | 1M CTE | 2M CTE | Coded. Default value is 1M.

3. Average Power Lower

Lower limit of GFSK average power.

4. Average Power Upper

Upper limit of GFSK average power.

5. Peak Power Upper

Upper limit of GFSK peak power.

6. Relative Peak Upper

Upper limit of GFSK peak power (relative).

7. $\Delta f1$ Avg Lower

Lower limit of the average value of $\Delta f1$.

8. $\Delta f1$ Avg Upper

Upper limit of the average value of $\Delta f1$.

9. $\Delta f2$ Max Lower

Lower limit of the maximum value of $\Delta f2$.

10. $\Delta f2$ Avg/ $\Delta f1$ Avg Lower

Lower limit of the $\Delta f2$ Avg/ $\Delta f1$ Avg ratio.

11. Freq Drift Lower

Lower limit of frequency drift.

12. Freq Drift Upper

Upper limit of frequency drift.

13. Freq Offset Lower

Lower limit of frequency offset.

14. Freq Offset Upper

Upper limit of frequency offset.

15. Max Drift Rate Lower

Lower limit of the maximum frequency drift rate.

16. Max Drift Rate Upper

Upper limit of the maximum frequency drift rate.

17. Intial Freq Drift Lower

Lower limit of initial frequency drift.

18. Intial Freq Drift Upper

Upper limit of initial frequency drift.

3.8.1.4.3 EDR

1. Limit Test

Enable or disable parameter limits.

2. Relative Power Lower

Lower limit of relative power.

3. Relative Power Upper

Upper limit of relative power.

4. Initial Freq Lower

Lower limit of initial frequency.

5. Initial Freq Upper

Upper limit of initial frequency.

1. Block Freq Lower

Lower limit of block frequency.

2. Block Freq Upper

Upper limit of block frequency.

3. Total Freq Lower

Lower limit of total frequency.

4. Total Freq Upper

Upper limit of total frequency.

5. RMS DEVM (DQPSK) Upper

Upper limit of the mean DEVM.

6. Peak DEVM (DQPSK) Upper

Upper limit of the peak DEVM.

7. RMS DEVM (8PSK) Upper

Upper limit of the mean DEVM.

8. Peak DEVM (8PSK) Upper

Upper limit of the peak DEVM.

9. 99% DEVM (DQPSK) Upper

The maximum DEVM value not exceeded at 99% of the symbol points.

10. 99% DEVM (8PSK) Upper

The maximum DEVM value not exceeded at 99% of the symbol points.


3.8.1.5 Advanced

1. Scale Conversion

Range conversion.

3.8.2 Measurement Results

The path for setting Bluetooth measurement results is: Trace -> Format.



Setup Steps:


1. Select the display window.
2. Select Result to switch the measurement result data to be displayed.

Measurement Result Examples:

BR Signal Demodulation Results



EDR Signal Demodulation Results



LE Signal Demodulation Results



1. Rf Envelope

Power image of the data. X-axis: time, Y-axis: signal strength (dBm).

2. Demod Waveform/IQ Measured Polar

When demodulating BR/LE signals: frequency image of the data. X-axis: time, Y-axis: kHz.

When demodulating EDR signals: constellation diagram of the data within the measurement length, displayed as IQ measurement over time. Both X and Y axes show amplitude (normalized amplitude).

3. Rf Spectrum

Frequency image of the data. X-axis: time, Y-axis: frequency.

1. Quad Metrics

Data indicators have the same meaning as in Result Summary.

2. Small-size Metrics

Data indicators have the same meaning as in Result Summary.

3. Result Summary

Displays the demodulation data table.

When demodulating BR Bluetooth signals, the following indicators are shown:

- 1) Standard: Displays the demodulation Bluetooth mode.
- 2) Packet Type: Displays the packet format.

Payload Length: Packet length.

- 4) Payload: Packet format.
- 5) Average Power: GFSK average power.
- 6) Peak Power: GFSK peak power.
- 7) $\Delta f1$ Max: Maximum value of $\Delta f1$.
- 8) $\Delta f1$ Avg: Average value of $\Delta f1$.
- 9) $\Delta f2$ Max: Maximum value of $\Delta f2$.
- 10) $\Delta f2$ Avg: Average value of $\Delta f2$.
- 11) $\Delta f2 > 115$ kHz: Proportion of $\Delta f2$ exceeding 115 kHz.
- 12) $\Delta f2/\Delta f1$: Ratio of $\Delta f2$ to $\Delta f1$.
- 13) Freq Drift: Frequency drift.
- 14) Max Drift Rate: Maximum frequency drift rate.
- 15) ICFT: Initial carrier frequency tolerance.

When demodulating EDR Bluetooth signals, the following indicators are shown:

- 1) Standard: Displays the demodulation Bluetooth mode.
- 2) Packet Type: Packet type.
- 3) Payload Length: Payload length.
- 4) Payload: Payload data format.
- 5) Freq Offset ω_i : Frequency offset ω_i .
- 6) Freq Offset ω_o : Frequency offset ω_o .
- 7) $\omega_i + \omega_o$: Frequency offset $\omega_i + \omega_o$.
- 8) RMS DEVM: Root mean square DEVM.
- 9) Peak DEVM: Peak DEVM.
- 10) GFSK Avg Power: GFSK average power.
- 11) DPSK Avg Power: DPSK average power.
- 12) Rel Avg Power: Relative average power.
- 13) Ber: Bit error rate.
- 14) Bit Errors: Number of bit errors.
- 15) Guard Interval: Guard interval.

When demodulating LE Bluetooth signals, the following indicators are shown:

- 1) Standard: Displays the demodulation Bluetooth mode.
- 2) Packet Type: Packet type.
- 3) Coding: Coding.
- 4) Payload Length: Payload length.
- 5) Payload: Payload.
- 6) Average Power: Average power.
- 7) Peak Power: Peak power.
- 8) $\Delta f1$ Max: Maximum value of $\Delta f1$.
- 9) $\Delta f1$ Avg: Average value of $\Delta f1$.
- 10) $\Delta f2$ Max: Maximum value of $\Delta f2$.
- 11) $\Delta f2$ Avg: Average value of $\Delta f2$.
- 12) $\Delta f2 > 185$ kHz: Proportion of $\Delta f2$ exceeding 185 kHz.
- 13) $\Delta f2 > 370$ kHz: Proportion of $\Delta f2$ exceeding 370 kHz.
- 14) $\Delta f1/\Delta f2$: Ratio of $\Delta f1$ to $\Delta f2$.
- 15) Freq Drift: Frequency drift.
- 16) Max Drift Rate: Maximum frequency drift rate.
- 17) Freq Offset: Frequency offset.
- 18) Initial Freq Drift: Initial frequency drift.
- 19) CTE Freq Drift: CTE (Constant Tone Extension) frequency drift.
- 20) CTE Max Drift Rate: Maximum CTE frequency drift rate.
- 21) CTE Freq Offset: CTE frequency offset.
- 22) CTE Initial Freq Drift: CTE initial frequency drift.
- 23) CTE Time: CTE duration.
- 24) RFU: Reserved for future use.
- 25) CTE Type: CTE type.

3.9 UWB

3.9.1 Configuration

The path to access the UWB configuration interface is: **Meas Setup** -> **UWB Properties**.



3.9.1.1 Format

1. Channel

Range: Ch0–Ch15, default: Ch0.

Set the channel number.

2. PHY Mode

Select the PHY mode. Options: 'HPRF' | 'BPRF' | '802.15.4a', default: Non-ERDEV.

3. STS Packet Configuration

Options: No STS (0); After SFD (1); After PHR/Payload (2); After SFD, no data (3)

Default: No STS (0)

When the PHY Mode is set to ERDEV-BPRF or ERDEV-HPRF, the STS Packet Configuration takes effect, used to specify the position of the STS packet.

4. MMS Packet

MMS Packet (BETA) supports the analysis of 802.11ab MMS (Multi-Millisecond) data packets. In this mode, there are no PSDU or PHR sections within the frame, and thus the corresponding parameters are not visible. The MMS mode consists of an SHR, several RSFs, and several RIFs. There can be 0–5 RSFs or RIFs. Each part of the frame starts on a millisecond boundary.

The MMS Packet (BETA) checkbox becomes effective when the PHY Mode is set to ERDEV HPRF and the STS Packet Configuration is set to After SFD, no data (3).

Default: Disabled (unchecked).

5. Data Power Analysis

Frame Data Field (PHR + PSDU) parsing checkbox. When checked, the demodulation algorithm will demodulate the Data field, calculate parameters such as power, and display them in the Syms/Errs table.

6. Modulation Analysis

Modulation analysis checkbox, used to control whether modulation analysis is performed during demodulation. This Modulation Analysis checkbox takes effect only when Data Power Analysis is checked. Once selected, demodulation analysis data will be displayed in the IQ Meas Time, IQ Ref Time, Err Vect Time, Decoded Bits, and Demodulated Bits graph frames, and NRMSE will be calculated.

If this option is not checked, modulation analysis will not be performed, which can speed up the measurement process.

Default: Checked.

7. Code Index

Range: 1–32 (depending on the configuration of Channel and PHY Mode)

Default: 1

Select the ternary code sequence to be used. There are 32 ternary code sequences: Code Index 1–8 have a length of 31 (suitable for Non-ERDEV and HPRF modes), Code Index 9–24 have a length of 127 (suitable for all modes), and Code Index 25–32 have a length of 91 (suitable for HPRF mode). The Code Index options are also related to the Channel, with each Channel having corresponding Code Index options.

8. Code Index

Range: 1–32 (depending on the configuration of Channel and PHY Mode)

Default: 1

Select the ternary code sequence to be used. There are 32 ternary code sequences: Code Index 1–8 have a length of 31 (applicable to Non-ERDEV and HPRF modes), Code Index 9–24 have a length of 127 (applicable to all modes), and Code Index 25–32 have a length of 91 (applicable to HPRF mode). The Code Index options are also related to the Channel, with each Channel having corresponding Code Index options.

9. Delta Length (L)

Options: 4, 16, 64 (related to Code Index and Channel)

Default: 16

Used to specify the length L of the Delta function that expands the preamble sequence (Code Sequence) into the preamble symbol (Si Symbol). Insert L-1 zeros between each pair of symbols.

Code sequences with lengths of 127 or 91 (corresponding to Code Index 9-32) can only use L=4. Code sequences with a length of 31 (corresponding to Code Index 1-8) can use L=16 or L=64, but wide-bandwidth channels (Channel 4/7/11/15) can only use L=16.

10. SYNC Length

Default: 64 symbols

The number of symbols in the SYNC segment (i.e., the repetition count of the preamble Si symbols).

The actual protocol (IEEE Std 802.15.4-2024) content has some differences:

When the PHY Mode is Non-ERDEV or BPRF, the SYNC Length can be 16, 64, 1024, or 4096;

When the PHY Mode is HPRF, the SYNC Length can be 16, 24, 32, 48, 64, 96, 128, or 256.

11. SFD Parameters

Used to configure the parameters of the SFD section, which are dependent on the PHY Mode.

When the PHY Mode is Non-ERDEV, configure the Length parameter: the number of Si Symbols, with options Short (8 symbols) and Long (64 symbols). Default: Long (64 symbols).

When the PHY Mode is BPRF or HPRF, configure the SFD sequence number. For BPRF, options are 0 (default) or 2; for HPRF, options are 1-4 (default 1).

12. Hop Bursts

The number of hopping burst positions within each half of a BPM-BPSK symbol. This option takes effect when the PHY Mode is Non-ERDEV and is hidden for other PHY modes. When the PHY Mode is BPRF, this value is fixed at 2. When the PHY Mode is HPRF, this option is invalid.

Default: 8

13. Chips per Burst

The number of chips within each burst. This setting takes effect only when the PHY Mode is Non-ERDEV and is hidden for other PHY modes. When the PHY Mode is BPRF, this value is fixed at 8. When the PHY Mode is HPRF, this setting is invalid.

Default: 128

14. Constraint Length

Option: CL3 | CL7

Default: CL3

Effective and visible when PHY Mode is HPRF. Set the length of the convolutional encoder used.

15. Data Rate

Option: Low / High;

Default: Low

Set the ERDEV data rate. When the PHY Mode is Non-ERDEV, this option is hidden and invalid. It takes effect for other PHY modes.

16. Frame Length (Octets)

Range: 0-127 (Non-ERDEV), 0-4095 (ERDEV)

Default: 20

Set the number of bytes for the Payload section.

17. FCS Type

Option: When PHY Mode is Non-ERDEV or BPRF, the only option is '2-octet'.

When PHY Mode is HPRF, the options are '2-octet' and '4-octet'.

Default: '2-octet'.

Select the FCS type.

18. Decoding Level

Configure the scope of decoding. The decoded data is displayed in the Decoded Bits graph frame.

Options:

No Decoding: No decoding of bit data; the Decoded Bits graph frame remains empty.

PHR+PSDU bits with FEC: Bit data after convolutional decoding (but still retains SECDED for PHR and RS coding for PSDU).

PSDU Bits: PSDU bit data after RS decoding.

Default: No Decoding.

19. Segment Length

Option: 16/32/64/128/256

Default: 64

Length of the STS segment (measured in units of 512 chips).

For BPRF, the Segment Length is fixed at 64. For HPRF, the Segment Length can be 16, 32, 64, 128, or 256.

20. Number of Segments

Option: 1/2/3/4

Default: 1

Configure the number of STS segments.

For BPRF, the Number of Segments is fixed at 1. For HPRF, the Number of Segments can be 1, 2, 3, or 4.

21. Extra Gap

Range: 0–127

Default: 0

The length of the additional Gap (measured in units of 4 chips) inserted between the Payload and the STS start point. This option is only effective and visible when the STS Packet Configuration is set to After PHR/Payload (2).

22. Key (128 bits)

The AES-128 encryption key is a 32-digit hexadecimal number represented as a hexadecimal string (optionally prefixed with "0x"). It is used together with the Upper Part of V and Initial Count to configure the DRBG (Deterministic Random Bit Generator), which is used to generate the STS signal.

23. Upper Part of V (96 bits)

V is a value used for AES-128 encryption to iterate the given DRBG sequence. The Upper Part of V is a 24-digit hexadecimal number represented as a hexadecimal string (optionally prefixed with "0x").

24. Initial Count (32 bits)

Specifies the lower part of V. It increments with each DRBG iteration. The Initial Count is an 8-digit hexadecimal number represented as a hexadecimal string (optionally prefixed with "0x").

3.9.1.2 Time

1. Search Time

Search Length refers to the amount of data captured and used for searching and demodulating HRP-UWB frames. Demodulation search is performed within the range of the Search Length.

The unit is seconds (s).

2. Delay Time

Delay time.

3. Number of Waveform Samples

Number of Waveform Samples

3.9.1.3 Advanced

1. Frequency Error Compensation

The frequency offset compensation checkbox is used to determine whether frequency offset estimation and correction should be performed. The frequency offset estimation range is locked at +/-1 MHz. When this parameter is unchecked, frequency offset estimation and correction are still performed, but the lock range is much smaller.

Default: Checked.

2. Estimate From

Option: Entire Frame | SYNC

Default: Entire Frame

Select the range for frequency offset estimation, either the entire frame or only the SYNC section. This option only takes effect when the **Frequency Error Compensation** checkbox is checked first.

3. Phase Tracking

Phase tracking performs per-chunk phase correction to compensate for residual frequency error (the remaining frequency error after applying Frequency Error Compensation).

The length of each chunk is 36,576 chips.

The incremental phase correction for each chunk is displayed in the Syms/Errs table.

Default: Checked.

4. Chip Clock Error Compensation

Clock error compensation checkbox. Select to enable or disable internal adjustment of the clock timing.

When enabled, the VSA estimates the clock error and then internally adjusts the system clock to match the estimated value.

Default: Checked.

5. Equalization Source

Specify the equalization filter to be applied to the signal.

Options: None | Inverse Measured Pulse

None: The demodulator does not compensate for the channel response of the measured signal (as shown in IQ Meas).

Inverse Measured Pulse: The demodulator takes the measured pulse from the EQ Impulse Response trace, truncates it to the length specified by Delay Spread, calculates the LMS (Least Mean Square) inverse of the filter, and applies it to the IQ Meas Time trace. This option should be selected for accurate NRMSE calculation. Set the Reference Filter to Measured Pulse to obtain the Err Vect Time trace (error vector similar to other VSA measurement types).

6. Delay Spread

When Equalization Source is set to Inverse Measured Pulse, the LMS equalization matrix is truncated so that the EQ Impulse Response trace is used within a range of +/- a specified number of chips. Use Delay Spread to specify the +/- number of chips to be utilized.

Default: 8 Chips

7. Reference Filter

Specifies the filter used for the reference signal.

Options: None | Measured Pulse

Default: None

None: No filter is applied. This option should be selected for error vector calculations to match the

NRMSE metric.

Measured Pulse: To obtain the Err Vect Time result (error vector similar to other VSA demodulation types), set Reference Filter to Measured Pulse and Equalization Source to None.

8. Data Sample Rate

Set the data sampling rate.

9. From NRMSE Computation

The duration of the portion removed when calculating the NRMSE result for the SHR.

Default: 0s.

This does not affect the SHR data used for the subsequent Impairment Estimation.


10. From Impairment Estimation

The duration of the initial portion of the SHR that is removed when calculating results such as frequency error, phase offset, chip clock error, and phase tracking corrections.

Default: 15 μ s.

3.9.2 Measurement Results

The UWB measurement result settings path is: **Trace -> Format**.




Setup Steps:

- 1) Select the display window.
- 2) Choose a Group to organize different measurement results into separate categories.

- 3) Select the data format for the measurement results to be displayed.

Example of Measurement Results (ERDEV-HPRF):



1. Baseband Pulse Mask

The pulse shape from -3 ns to 5 ns is displayed, with upper/lower masks applied to the real part of the data.

The X-axis of this curve represents time, ranging from -3 ns to 5 ns, and the Y-axis represents the pulse shape amplitude.

This curve is applicable only to channels with a bandwidth of 499.2 MHz.

2. Ch Freq Response

Displays the channel frequency response calculated based on the SYNC section of the SHR. Ch Frequency Response is the DFT of the Eq Impulse Response trace.

The X-axis represents frequency, and the Y-axis represents amplitude (dBm).

3. Eq Impulse Response

Displays the impulse response calculated based on the SYNC section of the SHR. All Si symbols except the first and the last are averaged. The number of Si symbols used for averaging is shown in the Vect: NNN annotation above the graph frame, where NNN represents the number of Si symbols used for averaging.

The X-axis represents time, and the Y-axis represents the impulse response amplitude.

4. Error Vector Time

Displays the difference between IQ Meas Time and IQ Ref Time. The X-axis represents the symbol sequence number, and the Y-axis represents the normalized vector error (%).

This curve is normalized using the overall average pulse amplitude.

5. Frame Info

Displays the demodulation information for the current frame, including the demodulation status (PASS or FAIL) of each section: SHR, PHR, and PSDU.

6. IQ Meas Time

Displays the measured pulse waveform, with 2 points per pulse. The length of IQ Meas Time is the same as that of IQ Ref Time. The Equalization Source option is applied to the data used in this curve. When Equalization Source is set to Inverse Measured Pulse, non-pulse points are zeroed out. This curve is normalized using the overall average pulse amplitude.

Note: When Equalization Source is set to Inverse Measured Pulse, the equalizer will zero out any positions in IQ Meas that do not correspond to pulses in the IQ Ref trace. If the data is not demodulated correctly, some pulses in IQ Meas may be zeroed out. To view these pulses, set Equalization Source to None.

7. IQ Ref Time

Displays the reference pulses of the frame, with 2 points per pulse.

IQ Ref Time has the same length as IQ Meas Time. The reference filter to be used can be specified by configuring the Reference Filter parameter.

Normalization is applied using the overall average pulse amplitude.

8. RRC Correlated

Displays the cross-correlation function between the measured UWB pulse and a root-raised cosine (RRC) pulse.

To calculate this trace, the pulse response is correlated with the reference RRC pulse and normalized by the energy of both the reference and measured pulse responses, so a value of 1 indicates perfect correlation.

The X-axis represents time, and the Y-axis represents the correlation value.

The parameters Min Main Lobe Width, Max Side Lobe, Side Lobe Pk, and Side Lobe Pk Loc are all calculated from this trace.

9. Error Summary

Displays the demodulated data table.

Freq Err: Average carrier frequency error (Hz and ppm). It represents the difference between the VSA center frequency and the UWB signal center frequency, displayed in Hz and ppm. A positive value indicates that the signal center frequency is higher than the VSA center frequency.

SYNC Power: Average power of the SYNC portion of the 802.15.4 HRP UWB signal. The SYNC segment is generated by repeating Si symbols multiple times. The average channel power is calculated by averaging the middle portion of the SYNC segment, excluding the first and last repeated Si symbols.

Time Offset: Offset from the trigger point (0 ms in Raw Main Time) to the beginning of the frame. Displays the time offset (in seconds) between the start of the Search Time and the start of the SHR.

RMARKER: Location of the first chip after the SFD. The relative time position is calculated from the start of the recording signal or the trigger point when acquiring data from the hardware.

Chip Clk Err: Error between the standard chip clock (499.2 MHz) and the signal chip clock. The clock error is calculated by averaging the middle portion of the SYNC segment, excluding the first and last repeated Si symbols. It is expressed in ppm, so the actual clock error is: $(1 + \text{Chip Clk Err}/1\text{E}6) * 499.2$ MHz.

Main Lobe Pk: Amplitude of the peak lobe (%), measured from the RRC Correlated trace.

Main Lobe Width: Width of the main lobe, defined as the portion where the main lobe exceeds 0.8.

Side Lobe Pk: Amplitude of the highest sidelobe (%), measured from the RRC Correlated trace.

Side Lobe Pk Loc: Location of the highest sidelobe relative to the main lobe, expressed as the time offset (in ns) from the main lobe peak position.

Min Main Lobe Width: PASS/FAIL indicator for the minimum main lobe width requirement. The protocol requires the main lobe to be ≥ 0.8 and maintained for at least TW duration.

Max Side Lobe: PASS/FAIL indicator for the maximum sidelobe height requirement. The protocol requires the sidelobe peak to be ≤ 0.3 .

Pulse Monotonic Increase: Indicates whether the pulse shape increases monotonically (PASS/FAIL). It checks if the pulse shape monotonically increases to its peak after exceeding 0.015.

NRMSE: Normalized Root Mean Square Error, expressed as a percentage of the pulse amplitude averaged over the entire frame. NRMSE is calculated using only pulse points, excluding inactive points, and is the RMS error between the IQ Meas Time and IQ Ref Time traces.

SHR NRMSE: NRMSE computed and averaged over the SHR part of the frame. Each domain's NRMSE is calculated using only that portion, expressed as a percentage of the pulse amplitude averaged over that part.

Data NRMSE: NRMSE computed and averaged over the Data part of the frame.

STS NRMSE: NRMSE computed and averaged over the STS part of the frame.

SHR Avg Power: Average Synchronization Header (SHR) power. It is the RMS average power of the SHR, calculated from the resampled version of the input time-domain data.

SHR Peak Power: Peak Synchronization Header (SHR) power. It is the power of the peak sample in the SHR, calculated from the resampled (2x499.2 MHz) version of the input time-domain data.

Data Avg Power: Average data (PHR + Payload) power. It is the RMS average power of the Data portion, calculated from the resampled version of the input time-domain data.

Data Peak Power: Peak data (PHR + Payload) sample power. It is the peak power of the Data portion, calculated from the resampled version of the input time-domain data.

STS Avg Power: Average Scrambled Timestamp Sequence (STS) power. It is the RMS average power of the STS domain, calculated from the resampled version of the input time-domain data.

STS Peak Power: Peak Scrambled Timestamp Sequence (STS) power. It is the peak power of the STS portion, calculated from the resampled version of the input time-domain data.

SHR Avg Pulse Amplitude: Average SHR pulse amplitude. It is the average pulse amplitude level of the Synchronization Header (SHR), calculated from the IQ Meas trace. Only pulse positions (where IQ Ref is -1 or 1) are included in the average.

PHR Avg Pulse Amplitude: Average PHR pulse amplitude. It is the average pulse amplitude level of the PHR portion, expressed in dB relative to the SHR average pulse amplitude.

PSDU Avg Pulse Amplitude: Average PSDU pulse amplitude. It is the average pulse amplitude level of the PSDU portion, expressed in dB relative to the SHR average pulse amplitude.

STS Avg Pulse Amplitude: Average STS pulse amplitude. It is the average pulse amplitude level of the STS portion, expressed in dB relative to the SHR average pulse amplitude.

10. Transmit Mask

The Transmit Mask trace displays the signal spectrum with standard-defined limit lines (0 dB is set to the maximum value within $|f| \leq 0.65/T_p$).

It is calculated from the data in the Time trace, and the spectrum is averaged to simulate a video bandwidth (VBW) of ≤ 1 kHz. The window used for spectrum calculation is the Gaussian Top window.

Note: A single measurement may not contain enough data to achieve a 1 kHz VBW. The VBW annotation in the graph indicates the actual video bandwidth. To simulate the required VBW, the time length is increased by analyzing longer signals (e.g., SYNC Length = 1024).

11. Raw Main Time

Displays the magnitude of the captured raw IQ data, with demodulated data positions marked. The

horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

12. Spectrum

Displays the spectrogram of IQ data before demodulation, which is the FFT of Raw Main Time. The horizontal axis is in frequency units (Hz, kHz, MHz, depending on the data format), and the vertical axis units are determined by the data format.

Example of Measurement Results (ERDEV-BPRF):



1. Baseband Pulse Mask

The pulse shape from -3 ns to 5 ns is displayed, with upper/lower masks applied to the real part of the data.

The X-axis of this curve represents time, ranging from -3 ns to 5 ns, and the Y-axis represents the pulse shape amplitude.

This curve is applicable only to channels with a bandwidth of 499.2 MHz.

2. Ch Freq Response

Displays the channel frequency response calculated based on the SYNC section of the SHR. Ch Frequency Response is the DFT of the Eq Impulse Response trace.

The X-axis represents frequency, and the Y-axis represents amplitude (dBm).

3. Eq Impulse Response

Displays the impulse response calculated based on the SYNC section of the SHR. All Si symbols except the first and the last are averaged. The number of Si symbols used for averaging is shown in the Vect: NNN annotation above the graph frame, where NNN represents the number of Si symbols used for averaging.

The X-axis represents time, and the Y-axis represents the impulse response amplitude.

4. Error Vector Time

Displays the difference between IQ Meas Time and IQ Ref Time. The X-axis represents the symbol sequence number, and the Y-axis represents the normalized vector error (%).

This curve is normalized using the overall average pulse amplitude.

5. Frame Info

Displays the demodulation information for the current frame, including the demodulation status (PASS or FAIL) of each section: SHR, PHR, and PSDU.

6. IQ Meas Time

Displays the measured pulse waveform, with 2 points per pulse. The length of IQ Meas Time is the same as that of IQ Ref Time. The Equalization Source option is applied to the data used in this curve. When Equalization Source is set to Inverse Measured Pulse, non-pulse points are zeroed out. This curve is normalized using the overall average pulse amplitude.

Note: When Equalization Source is set to Inverse Measured Pulse, the equalizer will zero out any positions in IQ Meas that do not correspond to pulses in the IQ Ref trace. If the data is not demodulated correctly, some pulses in IQ Meas may be zeroed out. To view these pulses, set Equalization Source to None.

7. IQ Ref Time

Displays the reference pulses of the frame, with 2 points per pulse.

IQ Ref Time has the same length as IQ Meas Time. The reference filter to be used can be specified by configuring the Reference Filter parameter.

Normalization is applied using the overall average pulse amplitude.

8. RRC Correlated

Displays the cross-correlation function between the measured UWB pulse and a root-raised cosine

(RRC) pulse.

To calculate this trace, the pulse response is correlated with the reference RRC pulse and normalized by the energy of both the reference and measured pulse responses, so a value of 1 indicates perfect correlation.

The X-axis represents time, and the Y-axis represents the correlation value.

The parameters Min Main Lobe Width, Max Side Lobe, Side Lobe Pk, and Side Lobe Pk Loc are all calculated from this trace.

9. Error Summary

Displays the demodulated data table.

Freq Err: Average carrier frequency error (Hz and ppm). It represents the difference between the VSA center frequency and the UWB signal center frequency, displayed in Hz and ppm. A positive value indicates that the signal center frequency is higher than the VSA center frequency.

SYNC Power: Average power of the SYNC portion of the 802.15.4 HRP UWB signal. The SYNC segment is generated by repeating Si symbols multiple times. The average channel power is calculated by averaging the middle portion of the SYNC segment, excluding the first and last repeated Si symbols.

Time Offset: Offset from the trigger point (0 ms in Raw Main Time) to the beginning of the frame. Displays the time offset (in seconds) between the start of the Search Time and the start of the SHR.

RMARKER: Location of the first chip after the SFD. The relative time position is calculated from the start of the recording signal or the trigger point when acquiring data from the hardware.

Chip Clk Err: Error between the standard chip clock (499.2 MHz) and the signal chip clock. The clock error is calculated by averaging the middle portion of the SYNC segment, excluding the first and last repeated Si symbols. It is expressed in ppm, so the actual clock error is: $(1 + \text{Chip Clk Err}/1E6) * 499.2$ MHz.

Main Lobe Pk: Amplitude of the peak lobe (%), measured from the RRC Correlated trace.

Main Lobe Width: Width of the main lobe, defined as the portion where the main lobe exceeds 0.8.

Side Lobe Pk: Amplitude of the highest sidelobe (%), measured from the RRC Correlated trace.

Side Lobe Pk Loc: Location of the highest sidelobe relative to the main lobe, expressed as the time offset (in ns) from the main lobe peak position.

Min Main Lobe Width: PASS/FAIL indicator for the minimum main lobe width requirement. The protocol requires the main lobe to be ≥ 0.8 and maintained for at least TW duration.

Max Side Lobe: PASS/FAIL indicator for the maximum sidelobe height requirement. The protocol requires the sidelobe peak to be ≤ 0.3 .

Pulse Monotonic Increase: Indicates whether the pulse shape increases monotonically (PASS/FAIL). It checks if the pulse shape monotonically increases to its peak after exceeding 0.015.

NRMSE: Normalized Root Mean Square Error, expressed as a percentage of the pulse amplitude averaged over the entire frame. NRMSE is calculated using only pulse points, excluding inactive points, and is the RMS error between the IQ Meas Time and IQ Ref Time traces.

SHR NRMSE: NRMSE computed and averaged over the SHR part of the frame. Each domain's NRMSE is calculated using only that portion, expressed as a percentage of the pulse amplitude averaged over that part.

Data NRMSE: NRMSE computed and averaged over the Data part of the frame.

STS NRMSE: NRMSE computed and averaged over the STS part of the frame.

SHR Avg Power: Average Synchronization Header (SHR) power. It is the RMS average power of the SHR, calculated from the resampled version of the input time-domain data.

SHR Peak Power: Peak Synchronization Header (SHR) power. It is the power of the peak sample in the SHR, calculated from the resampled (2x499.2 MHz) version of the input time-domain data.

Data Avg Power: Average data (PHR + Payload) power. It is the RMS average power of the Data portion, calculated from the resampled version of the input time-domain data.

Data Peak Power: Peak data (PHR + Payload) sample power. It is the peak power of the Data portion, calculated from the resampled version of the input time-domain data.

STS Avg Power: Average Scrambled Timestamp Sequence (STS) power. It is the RMS average power of the STS domain, calculated from the resampled version of the input time-domain data.

STS Peak Power: Peak Scrambled Timestamp Sequence (STS) power. It is the peak power of the STS portion, calculated from the resampled version of the input time-domain data.

SHR Avg Pulse Amplitude: Average SHR pulse amplitude. It is the average pulse amplitude level of the Synchronization Header (SHR), calculated from the IQ Meas trace. Only pulse positions (where IQ Ref is -1 or 1) are included in the average.

PHR Avg Pulse Amplitude: Average PHR pulse amplitude. It is the average pulse amplitude level of the PHR portion, expressed in dB relative to the SHR average pulse amplitude.

PSDU Avg Pulse Amplitude: Average PSDU pulse amplitude. It is the average pulse amplitude level of the PSDU portion, expressed in dB relative to the SHR average pulse amplitude.

STS Avg Pulse Amplitude: Average STS pulse amplitude. It is the average pulse amplitude level of the STS portion, expressed in dB relative to the SHR average pulse amplitude.

10. Transmit Mask

The Transmit Mask trace displays the signal spectrum with standard-defined limit lines (0 dB_r is set to the maximum value within $|f| \leq 0.65/T_p$).

It is calculated from the data in the Time trace, and the spectrum is averaged to simulate a video bandwidth (VBW) of ≤ 1 kHz. The window used for spectrum calculation is the Gaussian Top window.

Note: A single measurement may not contain enough data to achieve a 1 kHz VBW. The VBW annotation in the graph indicates the actual video bandwidth. To simulate the required VBW, the time length is increased by analyzing longer signals (e.g., SYNC Length = 1024).


11. Raw Main Time

Displays the magnitude of the captured raw IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.

12. Spectrum

Displays the spectrogram of IQ data before demodulation, which is the FFT of Raw Main Time. The horizontal axis is in frequency units (Hz, kHz, MHz, depending on the data format), and the vertical axis units are determined by the data format.

Example of Measurement Results (Non-ERDEV):



1. Baseband Pulse Mask

The pulse shape from -3 ns to 5 ns is displayed, with upper/lower masks applied to the real part of the data.

The X-axis of this curve represents time, ranging from -3 ns to 5 ns, and the Y-axis represents the pulse shape amplitude.

This curve is applicable only to channels with a bandwidth of 499.2 MHz.

2. Ch Freq Response

Displays the channel frequency response calculated based on the SYNC section of the SHR. Ch Frequency Response is the DFT of the Eq Impulse Response trace.

The X-axis represents frequency, and the Y-axis represents amplitude (dBm).

3. Eq Impulse Response

Displays the impulse response calculated based on the SYNC section of the SHR. All Si symbols except the first and the last are averaged. The number of Si symbols used for averaging is shown in the Vect: NNN annotation above the graph frame, where NNN represents the number of Si symbols used for averaging.

The X-axis represents time, and the Y-axis represents the impulse response amplitude.

4. Error Vector Time

Displays the difference between IQ Meas Time and IQ Ref Time. The X-axis represents the symbol sequence number, and the Y-axis represents the normalized vector error (%).

This curve is normalized using the overall average pulse amplitude.

5. Frame Info

Displays the demodulation information for the current frame, including the demodulation status (PASS or FAIL) of each section: SHR, PHR, and PSDU.

6. IQ Meas Time

Displays the measured pulse waveform, with 2 points per pulse. The length of IQ Meas Time is the same as that of IQ Ref Time. The Equalization Source option is applied to the data used in this curve. When Equalization Source is set to Inverse Measured Pulse, non-pulse points are zeroed out. This curve is normalized using the overall average pulse amplitude.

Note: When Equalization Source is set to Inverse Measured Pulse, the equalizer will zero out any positions in IQ Meas that do not correspond to pulses in the IQ Ref trace. If the data is not demodulated correctly, some pulses in IQ Meas may be zeroed out. To view these pulses, set Equalization Source to None.

7. IQ Ref Time

Displays the reference pulses of the frame, with 2 points per pulse.

IQ Ref Time has the same length as IQ Meas Time. The reference filter to be used can be specified by

configuring the Reference Filter parameter.

Normalization is applied using the overall average pulse amplitude.

8. RRC Correlated

Displays the cross-correlation function between the measured UWB pulse and a root-raised cosine (RRC) pulse.

To calculate this trace, the pulse response is correlated with the reference RRC pulse and normalized by the energy of both the reference and measured pulse responses, so a value of 1 indicates perfect correlation.

The X-axis represents time, and the Y-axis represents the correlation value.

The parameters Min Main Lobe Width, Max Side Lobe, Side Lobe Pk, and Side Lobe Pk Loc are all calculated from this trace.

9. Error Summary

Displays the demodulated data table.

Freq Err: Average carrier frequency error (Hz and ppm). It represents the difference between the VSA center frequency and the UWB signal center frequency, displayed in Hz and ppm. A positive value indicates that the signal center frequency is higher than the VSA center frequency.

SYNC Power: Average power of the SYNC portion of the 802.15.4 HRP UWB signal. The SYNC segment is generated by repeating Si symbols multiple times. The average channel power is calculated by averaging the middle portion of the SYNC segment, excluding the first and last repeated Si symbols.

Time Offset: Offset from the trigger point (0 ms in Raw Main Time) to the beginning of the frame. Displays the time offset (in seconds) between the start of the Search Time and the start of the SHR.

RMARKER: Location of the first chip after the SFD. The relative time position is calculated from the start of the recording signal or the trigger point when acquiring data from the hardware.

Chip Clk Err: Error between the standard chip clock (499.2 MHz) and the signal chip clock. The clock error is calculated by averaging the middle portion of the SYNC segment, excluding the first and last repeated Si symbols. It is expressed in ppm, so the actual clock error is: $(1 + \text{Chip Clk Err}/1\text{E}6) * 499.2$ MHz.

Main Lobe Pk: Amplitude of the peak lobe (%), measured from the RRC Correlated trace.

Main Lobe Width: Width of the main lobe, defined as the portion where the main lobe exceeds 0.8.

Side Lobe Pk: Amplitude of the highest sidelobe (%), measured from the RRC Correlated trace.

Side Lobe Pk Loc: Location of the highest sidelobe relative to the main lobe, expressed as the time offset (in ns) from the main lobe peak position.

Min Main Lobe Width: PASS/FAIL indicator for the minimum main lobe width requirement. The protocol requires the main lobe to be ≥ 0.8 and maintained for at least TW duration.

Max Side Lobe: PASS/FAIL indicator for the maximum sidelobe height requirement. The protocol requires the sidelobe peak to be ≤ 0.3 .

Pulse Monotonic Increase: Indicates whether the pulse shape increases monotonically (PASS/FAIL). It checks if the pulse shape monotonically increases to its peak after exceeding 0.015.

NRMSE: Normalized Root Mean Square Error, expressed as a percentage of the pulse amplitude averaged over the entire frame. NRMSE is calculated using only pulse points, excluding inactive points, and is the RMS error between the IQ Meas Time and IQ Ref Time traces.

SHR NRMSE: NRMSE computed and averaged over the SHR part of the frame. Each domain's NRMSE is calculated using only that portion, expressed as a percentage of the pulse amplitude averaged over that part.

Data NRMSE: NRMSE computed and averaged over the Data part of the frame.

STS NRMSE: NRMSE computed and averaged over the STS part of the frame.

SHR Avg Power: Average Synchronization Header (SHR) power. It is the RMS average power of the SHR, calculated from the resampled version of the input time-domain data.

SHR Peak Power: Peak Synchronization Header (SHR) power. It is the power of the peak sample in the SHR, calculated from the resampled (2x499.2 MHz) version of the input time-domain data.

Data Avg Power: Average data (PHR + Payload) power. It is the RMS average power of the Data portion, calculated from the resampled version of the input time-domain data.

Data Peak Power: Peak data (PHR + Payload) sample power. It is the peak power of the Data portion, calculated from the resampled version of the input time-domain data.

STS Avg Power: Average Scrambled Timestamp Sequence (STS) power. It is the RMS average power of the STS domain, calculated from the resampled version of the input time-domain data.

STS Peak Power: Peak Scrambled Timestamp Sequence (STS) power. It is the peak power of the STS portion, calculated from the resampled version of the input time-domain data.

SHR Avg Pulse Amplitude: Average SHR pulse amplitude. It is the average pulse amplitude level of the Synchronization Header (SHR), calculated from the IQ Meas trace. Only pulse positions (where IQ Ref is -1 or 1) are included in the average.

PHR Avg Pulse Amplitude: Average PHR pulse amplitude. It is the average pulse amplitude level of the PHR portion, expressed in dB relative to the SHR average pulse amplitude.

PSDU Avg Pulse Amplitude: Average PSDU pulse amplitude. It is the average pulse amplitude level of the PSDU portion, expressed in dB relative to the SHR average pulse amplitude.

STS Avg Pulse Amplitude: Average STS pulse amplitude. It is the average pulse amplitude level of the STS portion, expressed in dB relative to the SHR average pulse amplitude.

10. Transmit Mask

The Transmit Mask trace displays the signal spectrum with standard-defined limit lines (0 dB_r is set to the maximum value within $|f| \leq 0.65/T_p$).

It is calculated from the data in the Time trace, and the spectrum is averaged to simulate a video bandwidth (VBW) of ≤ 1 kHz. The window used for spectrum calculation is the Gaussian Top window.

Note: A single measurement may not contain enough data to achieve a 1 kHz VBW. The VBW annotation in the graph indicates the actual video bandwidth. To simulate the required VBW, the time length is increased by analyzing longer signals (e.g., SYNC Length = 1024).

11. Raw Main Time

Displays the magnitude of the captured raw IQ data, with demodulated data positions marked. The horizontal axis is in time units (s, ms, us, ns, depending on the data format), and the vertical axis units are determined by the data format.


12. Spectrum

Displays the spectrogram of IQ data before demodulation, which is the FFT of Raw Main Time. The horizontal axis is in frequency units (Hz, kHz, MHz, depending on the data format), and the vertical axis units are determined by the data format.

3.10 FHSS

3.10.1 Configuration

The path to enter the FHSS configuration interface is: **Meas Setup** -> **FHSS Properties**.



3.10.1.1 Signal

1. Bandwidth

Set the system bandwidth.

2. Power

Set the power.

3. Hop Id

Select the hop state with this ID to view the demodulation results.

4. Sample Rate

Set the sampling rate.

5. Mode

In manual mode, hop state detection is based on the configured minimum/maximum dwell time. In auto mode, hop states are automatically detected.

6. Min Dwell Time

Minimum detectable dwell time.

7. Max Dwell Time

Maximum detectable dwell time.

3.10.1.2 Measurement

2. FM Settling Tolerance

FM fluctuations below this tolerance are considered settled.

3. PM Settling Tolerance

PM fluctuations below this tolerance are considered settled.

3.10.1.3 Acquisition

4. Analysis Regions Mode

In manual mode, hop demodulation is based on the configured analysis region start and length. In auto mode, the detection length is automatically matched.

5. Analysis Regions Start

Start of the analysis region.

6. Acquisition Length

Acquisition length.

3.10.1.4 Result

1. Auto Range

Automatically match the statistical region for hop demodulation results.

2. Reference Point

Reference point for the statistical region of hop demodulation results.

3. Reference Offset

Offset from the Reference Point.

4. Result Range

Position of the statistical region for hop demodulation results relative to the Reference Point.

5. Result Length


Length of the statistical region for hop demodulation results.

6. Table

Select parameters to display in the table.

3.10.2 Measurement Results

The path to set FHSS measurement results is: **Trace -> Format**.



Setup Steps:

- 1) Select the display window.
- 2) Choose Result to switch the measurement result data to be displayed.

Example of Measurement Results:



11. Rf Spectrum

Spectrum image/raw image of the data (optional region). Horizontal axis: Hz, vertical axis: dBm.

12. Fm Time

FM frequency image, reflecting frequency hopping. Horizontal axis: time, vertical axis: Hz.

13. Spectrogram

Power spectrum waterfall plot. Horizontal axis: length of the analysis region, vertical axis: analysis results, with color distinguishing power levels.

14. Freq Dev Time

Frequency image of the data. Horizontal axis: time, vertical axis: frequency.

15. Results

Summary table of frequency-hopping signal information:


- 1) **ID:** Overall frequency-hopping number, starting from 1.
- 2) **HOP NO:** The number of the hop state within the configured analysis cycle, starting from 1.
- 3) **State Index:** State index, the number in the hop state table.
- 4) **Hop Begin:** Start time of the current hop (relative time when the signal first enters the hop tolerance region).
- 5) **Dwell Time:** Dwell time of the current hop (duration the signal remains within the hop tolerance range).
- 6) **Switching Time:** Hop switching time (time difference between the previous end point and the next start point).
- 7) **State Frequency:** Nominal frequency of the current hop state.
- 8) **Avg Frequency:** Average frequency within the measurement range of the current hop.
- 9) **Hop State Deviation:** Deviation between the average frequency and the nominal frequency.
- 10) **Relative Frequency:** Difference between the average frequency of the current hop and the previous hop.
- 11) **FM Settling Point:** Coordinates of the FM curve settling point (the point where frequency deviation no longer exceeds tolerance). Units: sec.
- 12) **FM Settling Time:** Time difference between the detected hop point and the settling point. Units: sec.
- 13) **FM Settled Length:** Duration of FM curve settlement for the current hop (time difference between the settling point and the hop end point).
- 14) **Freq Dev Peak:** Maximum difference between the instantaneous frequency of the measured signal and the ideal frequency trajectory. Units: Hz.
- 15) **Freq Dev RMS:** RMS value of Freq Dev Peak. Units: Hz.
- 16) **Freq Dev Avg:** Average value of Freq Dev Peak. Units: Hz.

- 17) **PM Settling Point:** PM settling point. Units: sec.
- 18) **PM Settling Time:** Time difference between the detected hop point and the settling point. Units: sec.
- 19) **PM Settled Length:** Duration of maintained settlement (time interval from the settling point to when the deviation exceeds tolerance, i.e., the hop end point).
- 20) **Phase Dev Peak:** Maximum deviation between the measured phase and the ideal value. Units: deg.
- 21) **Phase Dev RMS:** RMS value of Phase Dev Peak. Units: deg.
- 22) **Phase Dev Avg:** Average value of Phase Dev Peak. Units: deg.
- 23) **Min Power:** Minimum power level measured during the hop. Units: dBm.
- 24) **Max Power:** Maximum power level measured during the hop. Units: dBm.
- 25) **Avg Power:** Average power level measured during the hop. Units: dBm.
- 26) **Power Ripple:** Ratio of maximum power level to minimum power level, expressed as the difference in dBm. Units: dB.

3.11 FMCW

3.11.1 Configuration

The path to enter the FMCW configuration interface is: Meas Setup -> FMCW Properties.



3.11.1.1 General

3.11.1.1.1 Signal

1. Signal Mode

Signal type. Option: Chirp. Default value: Chirp (linear frequency modulation signal).

2. Frequency Center

Center frequency.

3. IQ Map

IQ image switch. Options: Normal | Invert. Default value: Normal.

4. Data Sample Rate

Manual sampling rate setting switch. Options: Auto | Manual. Default value: Auto. When set to Manual, the demodulation sampling rate can be changed manually.

3.11.1.1.2 Window

1. Window Length

Window length.

2. Window Overlap

Window overlap.

3.11.1.1.3 Chirp

1. Chirp Detection

Linear frequency modulation signal detection.

2. Chirp Setting

Chirp mode setting. Options: Manual | Auto. Default value: Manual.

3. Chirp Count

Number of chirp signals.

3.11.1.2 Time

1. Time Auto Detect

Time auto-detection.

2. Meas Time

Measurement time.

3. Time Gate Length

Measurement window time.

4. Time Gate Start

Measurement window start time.

5. Min Chirp Length

Minimum chirp time length.

6. Max Chirp Length

Maximum chirp time length.

7. From Start

From the start point.

8. From End

From the end point.

9. Switch Timing Config

Switching timing configuration.

10. Analysis Exclude

Exclude from analysis.

3.11.1.3 Advanced

3.11.1.3.1 Deviation Length

Deviation Length.

1. Reference

Reference position.

2. Length

Length.

3. Offset Begin

Start offset.

4. Offset End

End offset.

3.11.1.3.2 Deviation Setting

Deviation Setting.

1. Chirp State Deviation

Chirp state deviation.

2. FM Settling Tolerance

FM settling tolerance.

3. PM Settling Tolerance

PM settling tolerance.

3.11.1.3.3 Display Region

Display Region.

1. Display Region

Display region. Options: Region | Chirp | All. Default value: Region.

2. Scale Conversion

Scale conversion.

3.11.1.4 Result

1. ID

Identifier.

2. Chirp No.

Chirp signal index number.

3. Start Time

Chirp signal start time.

4. End Time

Chirp signal end time.

5. Chirp Length

Chirp signal time length.

6. Switching Time

Chirp signal switching time.

7. Slope

Chirp signal slope.

8. Slope Deviation

Chirp signal slope deviation.

9. Slope Deviation(Peak)

Chirp signal slope deviation (peak).

10. Slope Deviation(RMS)

Chirp signal slope deviation (RMS).

11. Slope Deviation(Average)

Chirp signal slope deviation (average).

12. Bandwidth

Bandwidth.

13. FM Settling Point

FM settling point.

14. FM Settling Time

FM settling time.

15. FM Settling Length

FM settling length.

16. Frequency INL(Peak)

Frequency Integral Non-Linearity (peak).

17. Frequency INL(RMS)

Frequency Integral Non-Linearity (RMS).

18. Frequency INL(Average)

Frequency Integral Non-Linearity (average).

19. Average Frequency

Average frequency.

20. Frequency Deviation(Peak)

Frequency deviation (peak).

21. Frequency Deviation(RMS)

Frequency deviation (RMS).

22. Frequency Deviation(Average)

Frequency deviation (average).

23. PM Settling Point

Phase modulation settling point.

24. PM Settling Time

Phase modulation settling time.

25. PM Settling Length

Phase modulation settling length.

26. Phase Deviation(Peak)

Phase deviation (peak).

27. Phase Deviation(RMS)

Phase deviation (RMS).

28. Phase Deviation(Average)

Phase deviation (average).

29. Minimum Power

Minimum power.

30. Maximum Power

Maximum power.

31. Average Power


Average power.

32. Power Ripple

Power ripple.

3.11.2 Measurement Results

The path for setting FMCW measurement results is: Trace -> Format.



Setup Steps:

- 1) Select the display window.
- 2) Select Result to switch the measurement result data to be displayed.

Measurement Result Example:



1. Rf Spectrum

Frequency image of the data. X-axis: time, Y-axis: frequency.

2. Fm Time

FM frequency image, showing frequency hopping. X-axis: time, Y-axis: Hz.

3. Spectrogram

Power spectrum waterfall plot. X-axis shows the length of the analysis region, Y-axis shows the analysis results, and power is distinguished by color.

4. Spectrum

Frequency spectrum image/raw image of the data (selectable region). X-axis: Hz, Y-axis: dBm.

5. Results

Frequency hopping signal information summary table:

- 1) ID: Total chirp point number, starting from 1.
- 2) Chirp No.: Reference chirp point number, starting from 0.
- 3) Start Time: Chirp signal start time, unit: μs.

- 4) End Time: Chirp signal end time, unit: μs .
- 5) Chirp Length: Chirp time length, unit: μs .
- 6) Switching Time: Chirp switching time, unit: μs .
- 7) Slope: Chirp signal slope, unit: $\text{kHz}/\mu\text{s}$.
- 8) Slope Dev: Chirp signal slope deviation, unit: $\text{kHz}/\mu\text{s}$.
- 9) Slope Dev Peak: Chirp signal slope deviation (peak), unit: $\text{kHz}/\mu\text{s}$.
- 10) Slope Dev RMS: Chirp signal slope deviation (RMS), unit: $\text{kHz}/\mu\text{s}$.
- 11) Slope Dev Avg: Chirp signal slope deviation (average), unit: $\text{kHz}/\mu\text{s}$.
- 12) Bandwidth: Bandwidth, unit: kHz .
- 13) FM Settling Point: FM settling point, unit: μs .
- 14) FM Settling Time: FM settling time, unit: μs .
- 15) FM Settling Length: FM settling length, unit: μs .
- 16) Frequency INL Peak: Frequency Integral Non-Linearity (peak).
- 17) Frequency INL RMS: Frequency Integral Non-Linearity (RMS).
- 18) Frequency INL Avg: Frequency Integral Non-Linearity (average).
- 19) Avg Frequency: Average frequency, unit: kHz .
- 20) Freq Dev Peak: Frequency deviation peak, unit: kHz .
- 21) Freq Dev RMS: Frequency deviation RMS, unit: kHz .
- 22) Freq Dev Avg: Frequency deviation average, unit: kHz .
- 23) PM Settling Point: Phase modulation settling point, unit: μs .
- 24) PM Settling Time: Phase modulation settling time, unit: μs .
- 25) PM Settling Length: Phase modulation settling length, unit: μs .
- 26) Phase Dev Peak: Phase deviation peak, unit: deg .
- 27) Phase Dev RMS: Phase deviation RMS, unit: deg .
- 28) Phase Dev Avg: Phase deviation average, unit: deg .
- 29) Min Power: Minimum power, unit: dBm .
- 30) Max Power: Maximum power, unit: dBm .
- 31) Avg Power: Average power, unit: dBm .
- 32) Power Ripple: Power ripple, unit: dB .

Ordering Information

Standard configuration

Serial Number	Name	Description	Order Number
1	Basic Vector Signal Analysis Signal analysis software	Provides measurement functions such as spectrum analysis and IQ analysis.	SIGV-VSAA1
2	Custom OFDM modulation analysis	Provides an option for general OFDM signal demodulation analysis.	SIGV-VSAO1
3	Digital modulation analysis	Provides options for general digital modulation signal demodulation analysis.	SIGV-VSAD1

Options

Serial Number	Name	Description	Order Number
1	32 Measurement vector signal analysis	Provides an option for running up to 32 measurements simultaneously.	SIGV-VSAA2
2	LTE/LTE-A FDD modulation analysis	Provides options for LTE/LTE-A FDD demodulation analysis.	SIGV-VSAL1
3	LTE/LTE-A TDD modulation analysis	Provides options for LTE/LTE-A TDD demodulation analysis.	SIGV-VSAL2
4	5G NR/NR-A Modulation Analysis	Provides options for NR/NR-A demodulation analysis.	SIGV-VSAN1
5	5G NR-NTN modulation analysis	Provides options for NR-NTN demodulation analysis.	SIGV-VSAN2
6	WLAN 802.11b/a/g/n/ac/ax modulation analysis	Provides options for WLAN 802.11b/a/g/n/ac/ax demodulation analysis.	SIGV-VSAW1
7	WLAN 802.11be	Provides options for WLAN	SIGV-VSAW2

	modulation analysis	802.11be demodulation analysis.	
8	HRP-UWB modulation analysis	Provides options for HRP-UWB with various bandwidths demodulation analysis.	SIGV-VSAU1
9	Bluetooth modulation analysis	Provides options for Bluetooth demodulation analysis.	SIGV-VSAB1
10	Frequency-Hopping Signal analysis	Provides options for frequency-hopping signal analysis.	SIGV-VSAF1

More options coming soon! Follow us for updates.

Serial Number	Name	Description	Order Number
1	NB-lot downlink modulation analysis	Provides options for NB-lot demodulation analysis.	SIGV-VSAG3
2	FMCW Signal analysis	Provides options for linear frequency modulation (chirp) signal analysis.	SIGV-VSAF2
3	GSM/EDGE modulation analysis	Provides options for GSM demodulation analysis.	SIGV-VSAG1
4	WCDMA/HSPA modulation analysis	Provides options for WCDMA demodulation analysis.	SIGV-VSAG2
5	Pulse Signal analysis	Provides options for Pulse signal analysis.	SIGV-VSAP1
6	DVB-S2\S2X modulation analysis	Provides options for DVB-S2\S2X analysis.	SIGV-VSAV1



About SIGLENT

SIGLENT is an international high-tech company, concentrating on R&D, sales, production and services of electronic test & measurement instruments.

SIGLENT first began developing digital oscilloscopes independently in 2002. After more than a decade of continuous development, SIGLENT has extended its product line to include digital oscilloscopes, isolated handheld oscilloscopes, function/arbitrary waveform generators, RF/MW signal generators, spectrum analyzers, vector network analyzers, digital multimeters, DC power supplies, electronic loads and other general purpose test instrumentation. Since its first oscilloscope was launched in 2005, SIGLENT has become the fastest growing manufacturer of digital oscilloscopes. We firmly believe that today SIGLENT is the best value in electronic test & measurement.

Headquarters:

SIGLENT Technologies Co., Ltd

Add: Bldg No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China

Tel: + 86 755 3688 7876

Fax: + 86 755 3359 1582

Email: sales@siglent.com

Website: int.siglent.com

North America:

SIGLENT Technologies NA, Inc

Add: 6557 Cochran Rd Solon, Ohio 44139

Tel: 440-398-5800

Toll Free: 877-515-5551

Fax: 440-399-1211

Email: support@siglentna.com

Website: www.siglentna.com

Europe:

SIGLENT Technologies Germany GmbH

Add: Staetzlinger Str. 70

86165 Augsburg, Germany

Tel: +49(0)-821-666 0 111 0

Fax: +49(0)-821-666 0 111 22

Email: info-eu@siglent.com

Website: www.siglenteu.com

Malaysia:

SIGLENT Technologies (M) Sdn.Bhd

Add: NO.6 Lorong Jelawat 4

Kawasan Perusahaan Seberang Jaya

13700, Perai Pulau Pinang

Tel: 006-04-3998964

Email: sales@siglent.com

Website: int.siglent.com

Follow us on
Facebook: SiglentTech

